

PARTS MANUAL

MODEL
Parts
Manual

EH650DC2910

10/12



SUBARU

Industrial Power Products

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047 - Phone 847-540-7300 - Fax 847-438-5012


e-mail: sales@subarupower.com - www.subarupower.com

© 2012 Subaru Industrial Power Products

Group Index

Group Name	Page
100 Crankcase.....	4
200 Crankshaft.....	8
300 Intake & Exhaust.....	10
315 Intake & Exhaust.....	12
400 Governor.....	14
500 Cooling & Starting.....	16
600 Fuel & Lubricant.....	18
640 Fuel & Lubricant.....	20
700 Electric Device.....	22
730 Electric Device.....	24
900 Accessory.....	26
 Part Number Index.....	 28
Part Description Index.....	29

100 Crankcase



100 Crankcase

Ref	Part Number.	Description	Qty	Remark
10	263-10112-01	CRANK CASE CP	1	
20	263-14211-03	VALVE GUIDE	2	
21	056-51000-50	CLIP	1	
22	263-14211-03	VALVE GUIDE	2	
23	056-51000-50	CLIP	1	
26	132-07AA0-50	SEAL-INT VALVE	1	
27	132-07AA0-50	SEAL-INT VALVE	1	
28	263-35341-03	RETAINER PLATE	1	
29	263-35341-03	RETAINER PLATE	1	
40	263-15805-03	MAIN BEARING	1	
50	031-00801-10	DOWEL PIN	2	
55	263-55601-03	PIPE	2	
60	010-50802-90	STUD	4	
61	010-50802-90	STUD	4	
75	044-00800-10	OIL SEAL	1	
80	040-11400-30	PLUG	1	
85	235-15421-03	BLIND PLUG	1	
90	021-11400-20	GASKET	2	
120	263-65009-A3	OIL DRAIN VALVE	1	
130	263-15701-01	PIPE(PULSE)	1	
195	263-15901-03	UNION	1	
200	263-76001-A1	SWITCH OIL PRESSURE	1	
210	263-11103-21	MAINBEARING COVER CP	1	
220	044-04200-30	OIL SEAL	1	
230	263-15805-03	MAIN BEARING	1	
250	263-45003-11	GOVERNOR GEAR CP	1	
255	263-46215-A3	THRUST BEARING	1	
257	263-46214-A3	WASHER	2	
260	277-41902-03	GOVERNOR SLEEVE	1	
290	263-16002-A3	GASKET (M.B COVER)	1	
300	011-00802-20	FLANGE BOLT	10	
610	263-13213-01	CYLINDER HEAD 1 CP	1	
615	263-13313-01	CYLINDER HEAD 2 CP	1	
620	263-15021-41	GASKET 1 (CYL HEAD)	1	
621	263-15121-31	GASKET 2 (CYL HEAD)	1	
630	011-01000-70	FLANGE BOLT	8	
680	263-15503-03	ROCKER COVER	1	
681	263-15504-03	ROCKER COVER	1	
690	263-16101-A3	GASKET(ROCKER COVER)	2	


100 Crankcase

Ref	Part Number.	Description	Qty	Remark
700	031-00600-20	DOWEL PIN	4	
710	011-00601-01	FLANGE BOLT	8	
800	280-19001-03	HOOK	2	
810	263-14301-03	BREATHER COVER	1	
820	280-14401-A1	BREATHER PLATE CP	1	
830	263-16006-03	GASKET(BREATHERPLATE	2	
860	011-00600-30	FLANGE BOLT	2	
960	263-99001-27	GASKET SET	1	

This Page Intentionally Left Blank

200 Crankshaft

FIG. 200




EH65/64/63

263020000W01

200 Crankshaft

Ref	Part Number.	Description	Qty	Remark
10	263-21311-11	CRANK SHAFT CP	1	
40	263-25012-A3	SPACER	1	
41	263-25013-A3	SPACER	1	
42	263-25014-A3	SPACER	1	
50	018-01800-10	FLANGE NUT	1	
65	003-10180-00	WASHER	1	
70	005-32054-01	WOODRUFF KEY	1	
80	207-26001-03	KEY	1	
310	263-22601-30	CONNECTING ROD AY	2	
320	001-05084-00	FLANGE BOLT	2	
350	263-23301-23	PISTON PIN	2	
360	263-23421-J3	PISTON	2	
370	263-23501-17	PISTON RING SET	2	
380	056-52100-20	CLIP	4	

300 Intake & Exhaust




300 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
10	280-31801-03	CAM SHAFT	1	
50	263-33301-A3	TAPPET	4	
60	246-33611-03	VALVE SPRING	4	
70	246-33711-13	SPRING RETAINER	4	
80	263--33401-H3	INTAKE VALVE	2	
90	263-33502-H3	EXHAUST VALVE	2	
95	246-35501-03	COLLET-VALVE	8	
210	263-35322-A1	PUSH ROD CP	4	
220	267-36102-03	ROCKER ARM	4	
230	261-35801-13	BOLT(PIVOT)	4	
235	267-35701-03	PIVOT	4	
240	017-00601-10	NUT	4	
260	263-37002-A3	GUIDE PLATE	2	
350	018-00800-10	FLANGE NUT	4	
500	280-33001-C3	INTAKE MANIFOLD	1	
555	263-35503-A3	GASKET(IN MANIFOLD)	2	
580	011-00600-20	FLANGE BOLT	3	
590	002-38080-00	FLANGE NUT	4	
850	263-18003-03	RUBBER PIPE	1	
853	056-12000-20	HOSE CLAMP	2	
920	263-91724-03	LABEL(TRADE MARK)	1	

315 Intake & Exhaust

FIG. 315




EH65/64/63

263031500W01

315 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
510	280-32602-00	AIR CLEANER AY	1	
512	280-32625-01	CLEANER BASE CP	1	
514	263-32630-03	CLEANER COVER	1	
516	263-32640-01	WING NUT	1	
520	263-32610-A1	CLEANER ELEMENT CP	1	

400 Governor




400 Governor

Ref	Part Number.	Description	Qty	Remark
10	263-42301-B3	GOVERNOR LEVER	1	
20	263-42201-A3	GOVERNOR SHAFT	1	
25	X23-00801-50	SPACER	1	
26	003-10080-00	WASHER	2	
30	263-42701-A3	GOVERNOR ROD	1	
40	263-42801-03	ROD SPRING	1	
50	005-11060-01	SNAP PIN	1	
60	001-14063-00	BOLT AND WASHER AY	1	
70	018-60600-20	NUT	1	
80	263-42509-A3	GOVERNOR SPRING	1	
130	263-46011-A3	CHOKE CONTROL ROD	1	
140	261-45201-03	RETURN SPRING	2	
170	263-46021-B3	CHOKE LEVER	1	
173	004-31040-80	SCREW	1	
180	226-43101-01	LINK PIVOT CP	1	
310	263-43311-A3	SPEED CONTROL LEV	1	
360	011-50500-20	BOLT	1	
370	002-27050-00	NUT	1	
381	002-38060-00	FLANGE NUT	1	
395	261-43901-03	CLAMP	1	
396	001-17052-00	BOLT & WASHER AY	1	
435	263-45021-A2	BRACKET(SPD CTL)	1	
465	X84-14320-00	RUBBER FOAM	1	
485	011-00600-20	FLANGE BOLT	2	

500 Cooling & Starting

FIG. 500




EH65/64/63

263050001W00

500 Cooling & Starting

Ref	Part Number.	Description	Qty	Remark
10	263-51121-B2	BLOWER HOUSING UN	1	
26	073-20057-60	LABEL(WARNING)	1	
35	263-91864-03	LABEL(ENGINE NAME)	1	
40	011-00600-30	FLANGE BOLT	8	
41	011-00600-10	FLANGE BOLT	2	
60	263-52612-A1	CYLINDER BAFFLE 1 CP	1	
61	263-52704-A1	CYLINDER BAFFLE 2 CP	1	
62	263-52801-03	CYLINDER BAFFLE 3	1	
63	263-52912-A2	CYLINDER BAFFLE 4 UN	1	
80	011-00600-20	FLANGE BOLT	6	
110	263-54101-A2	COOLING BLOWER UN	1	
113	001-14061-60	BOLT AND WASHER AY	4	


600 Fuel & Lubricant



600 Fuel & Lubricant

Ref	Part Number.	Description	Qty	Remark
80	X85-10616-60	RUBBER PIPE	1	
81	X85-10617-80	RUBBER PIPE	1	
90	056-11100-20	HOSE CLAMP	2	
183	056-61000-21	CLAMP	1	
230	085-10301-10	RUBBER PIPE	1	
235	206-75501-01	CLAMP CP	2	
270	263-63604-11	OIL GAUGE CP	1	
290	263-66201-A3	GASKET(CARBURETOR)	1	
510	267-62201-10	FUEL PUMP AY	1	
515	263-65002-A3	BRACKET(FUEL PUMP)	1	
520	263-62657-01	PULSE PIPE CP	1	
522	263-68008-B3	RUBBER PIPE	1	
523	263-68501-03	HOSE CLAMP	2	
540	011-00600-20	FLANGE BOLT	5	
573	011-00801-10	FLANGE BOLT	2	
610	263-63901-03	INNER ROTOR	1	
615	263-63902-03	OUTER ROTOR	1	
620	263-64002-01	OIL PUMP COVER CP	1	
623	044-03501-70	OIL SEAL	1	
625	024-01000-20	O RING	1	
640	011-00600-30	FLANGE BOLT	4	
650	263-64302-02	OIL PUMP FILTER UN	1	
653	263-65011-A3	FLANGE BOLT	1	
660	248-65801-00	OIL FILTER AY	1	
670	263-65001-13	PLUG(OIL RELIEF)	1	
673	003-70140-00	GASKET,ALUMINUM	1	
677	263-66001-03	SPRING(RELIEF VALVE)	1	
680	006-90308-00	STEEL BALL	1	
715	280-63602-A1	OIL FILLER CAP CP	1	
718	263-64414-A3	O RING	1	

FIG. 640




640 Fuel & Lubricant

Ref	Part Number.	Description	Qty	Remark
210	263-62393-00	CARBURETOR AY	1	
-1	263-62535-08	VALVE,THROTTLE	1	
-2	261-62352-08	SCREW,VALVE SET	2	
-3	258-62525-08	VALVE,CHOKE	1	
-4	258-62555-08	SCREW SET(VALVE)	2	
-5	258-62420-08	JET(SLOW)	1	
-8	263-62520-08	SHAFT ASSY,CHOKE	1	
-11	263-62530-08	SHAFT ASSY,THROTTLE	1	
-13	258-62551-08	RING(CHOKE LEVER)	1	
-14	226-62501-08	VALVE,FLOAT	1	
-15	258-62515-08	FLOAT PIN	1	
-18	280-62545-08	GASKET,AIR HORN	1	
-19	280-62505-08	FLOAT	1	
-22	280-62401-08	JET,MAIN	1	
-28	215-62353-08	SCREW,DRAIN	1	
-29	215-62446-08	SPRING,DRAIN	1	
-38	258-62556-08	SCREW SET(FLOAT PIN)	1	
-40	263-62451-08	SCREW,THRO.ADJUST	1	
-41	258-62445-08	SPRING(ADJUST SCREW)	1	
-57	258-62450-08	SCREW SET(AIR HORN)	4	
-59	263-62560-08	O-RING,AIR HORN	1	
-61	280-62551-08	COLLAR,CHOKE	1	
-62	258-62554-08	FILTER(CHOKE SHAFT)	1	
-93	263-62524-08	LEVER ASSY,CHOKE	1	
-94	263-62445-08	SPRING,CHOKE	1	
-102	226-62580-08	FILTER,AIR	1	
-103	258-62570-08	COLLAR(THRO.SHAFT)	1	
-125	263-62556-08	VALVE CP,(SOLENOID)	1	
-126	258-62546-08	GASKET,MAIN PASSAGE	1	
-129	258-62566-08	CLAMP(SOLENOID)WIRE	1	
-136	263-62555-08	GASKET	1	
-195	263-62552-08	PLUG	1	

700 Electric Device

FIG. 700



EH65/64/63


263070001W00

700 Electric Device

Ref	Part Number.	Description	Qty	Remark
10	263-77202-11	FLYWHEEL CP	1	
11	263-78203-01	IGNITION COIL CP	2	
15	263-79411-A1	CHARGE COIL CP	1	
20	263-71002-h3	RING GEAR	1	
30	001-14062-50	BOLT AND WASHER AY	4	
35	001-16052-00	BOLT AND WASHER AY	4	
50	263-73126-H1	WIRE CP(IG.COIL)	1	
61	KU3-11052-21	STOP DIODE CP	1	
70	011-00600-10	FLANGE BOLT	1	
95	065-90000-10	PLUG TERMINAL	2	
100	065-01407-30	SPARK PLUG	2	
110	X65-51000-10	SPARK PLUG CAP	2	
112	279-55201-03	GROMMET, PLUGCAP	1	
130	011-00801-00	FLANGE BOLT	2	
291	263-71901-01	REGULATOR CP	1	
301	011-00601-40	FLANGE BOLT	2	
330	263-73118-C1	WIRING HARNESS CP	1	
384	056-30000-10	WIRE BAND	5	
770	206-75501-01	CLAMP CP	2	

730 Electric Device

FIG. 730



EH65/64/63


263073000W01

730 Electric Device

Ref	Part Number.	Description	Qty	Remark
120	263-70504-H0	STARTING MOTOR AY	1	
-1	255-70580-08	YOKE AY	1	
-2	255-70551-08	BRUSH SET	1	
-3	228-70516-08	BRUSH SPRING	4	
-4	255-70531-08	BRUSH HOLDER AY	1	
-6	263-70510-08	ARMATURE ASS'Y	1	
-7	255-70521-08	PINION AY	1	
-8	210-70534-08	PINION STOPPER SET	1	
-9	263-70500-08	GEAR CASE ASS'Y	1	
-10	228-70514-08	BRUSH (-)	2	
-11	263-70505-08	REAR COVER ASS'Y	1	
-14	243-70525-08	SHIFT LEVER KIT	1	
-15	263-70515-08	MAGNETIC SWITCH AY	1	
-17	207-70524-08	THROUGH BOLT	2	
-25	263-70550-08	THRUST WASHER KIT	1	
-30	255-70570-08	DUST COVER KIT	1	
-32	263-70551-08	06 BOLT(M6X37)	2	
-77	207-70526-08	RUBBER CAP BS	1	

900 Accessory

FIG. 900



EH65/64/63

263090000W01

900 Accessory

Ref	Part Number.	Description	Qty	Remark
10	227-90301-10	ACCESSORY TOOL KIT	1	

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
001-05084-00	9	246-35501-03	11	263-46021-B3	15	280-62545-08	21
001-14061-60	17	248-65801-00	19	263-46214-A3	5	280-62551-08	21
001-14062-50	23	255-70521-08	25	263-46215-A3	5	280-63602-A1	19
001-14063-00	15	255-70531-08	25	263-51121-B2	17	KU3-11052-21	23
001-16052-00	23	255-70551-08	25	263-52612-A1	17	X23-00801-50	15
001-17052-00	15	255-70570-08	25	263-52704-A1	17	X65-51000-10	23
002-27050-00	15	255-70580-08	25	263-52801-03	17	X84-14320-00	15
002-38060-00	15	258-62420-08	21	263-52912-A2	17	X85-10616-60	19
002-38080-00	11	258-62445-08	21	263-54101-A2	17	X85-10617-80	19
003-10080-00	15	258-62450-08	21	263-55601-03	5		
003-10180-00	9	258-62515-08	21	263-62393-00	21		
003-70140-00	19	258-62525-08	21	263-62445-08	21		
004-31040-80	15	258-62546-08	21	263-62451-08	21		
005-11060-01	15	258-62551-08	21	263-62520-08	21		
005-32054-01	9	258-62554-08	21	263-62524-08	21		
006-90308-00	19	258-62555-08	21	263-62530-08	21		
010-50802-90	5	258-62556-08	21	263-62535-08	21		
011-00600-10	17, 23	258-62566-08	21	263-62552-08	21		
011-00600-20	11, 15, 17, 19	258-62570-08	21	263-62555-08	21		
011-00600-30	6, 17, 19	261-35801-13	11	263-62556-08	21		
011-00601-01	6	261-43901-03	15	263-62560-08	21		
011-00601-40	23	261-45201-03	15	263-62657-01	19		
011-00801-00	23	261-62352-08	21	263-63604-11	19		
011-00801-10	19	263-33401-H3	11	263-63901-03	19		
011-00802-20	5	263-10112-01	5	263-63902-03	19		
011-01000-70	5	263-11103-21	5	263-64002-01	19		
011-50500-20	15	263-13213-01	5	263-64302-02	19		
017-00601-10	11	263-13313-01	5	263-64414-A3	19		
018-00800-10	11	263-14211-03	5	263-65001-13	19		
018-01800-10	9	263-14301-03	6	263-65002-A3	19		
018-60600-20	15	263-15021-41	5	263-65009-A3	5		
021-11400-20	5	263-15121-31	5	263-65011-A3	19		
024-01000-20	19	263-15503-03	5	263-66001-03	19		
031-00600-20	6	263-15504-03	5	263-66201-A3	19		
031-00801-10	5	263-15701-01	5	263-68008-B3	19		
040-11400-30	5	263-15805-03	5	263-68501-03	19		
044-00800-10	5	263-15901-03	5	263-70500-08	25		
044-03501-70	19	263-16002-A3	5	263-70504-H0	25		
044-04200-30	5	263-16006-03	6	263-70505-08	25		
056-11100-20	19	263-16101-A3	5	263-70510-08	25		
056-12000-20	11	263-18003-03	11	263-70515-08	25		
056-30000-10	23	263-21311-11	9	263-70550-08	25		
056-51000-50	5	263-22601-30	9	263-70551-08	25		
056-52100-20	9	263-23301-23	9	263-71002-h3	23		
056-61000-21	19	263-23421-J3	9	263-71901-01	23		
065-01407-30	23	263-23501-17	9	263-73118-C1	23		
065-90000-10	23	263-25012-A3	9	263-73126-H1	23		
073-20057-60	17	263-25013-A3	9	263-76001-A1	5		
085-10301-10	19	263-25014-A3	9	263-77202-11	23		
132-07AA0-50	5	263-32610-A1	13	263-78203-01	23		
206-75501-01	19, 23	263-32630-03	13	263-79411-A1	23		
207-26001-03	9	263-32640-01	13	263-91724-03	11		
207-70524-08	25	263-33301-A3	11	263-91864-03	17		
207-70526-08	25	263-33502-H3	11	263-99001-27	6		
210-70534-08	25	263-35322-A1	11	267-35701-03	11		
215-62353-08	21	263-35341-03	5	267-36102-03	11		
215-62446-08	21	263-35503-A3	11	267-62201-10	19		
226-43101-01	15	263-37002-A3	11	277-41902-03	5		
226-62501-08	21	263-42201-A3	15	279-55201-03	23		
226-62580-08	21	263-42301-B3	15	280-14401-A1	6		
227-90301-10	27	263-42509-A3	15	280-19001-03	6		
228-70514-08	25	263-42701-A3	15	280-31801-03	11		
228-70516-08	25	263-42801-03	15	280-32602-00	13		
235-15421-03	5	263-43311-A3	15	280-32625-01	13		
243-70525-08	25	263-45003-11	5	280-33001-C3	11		
246-33611-03	11	263-45021-A2	15	280-62401-08	21		
246-33711-13	11	263-46011-A3	15	280-62505-08	21		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

0

06 BOLT(M6X37).....25

A

ACCESSORY TOOL KIT.....27
AIR CLEANER AY.....13
ARMATURE ASS'Y.....25

B

BLIND PLUG.....5
BLOWER HOUSING UN.....17
BOLT.....15
BOLT & WASHER AY.....15
BOLT AND WASHER AY.....15, 17, 23
BOLT(PIVOT).....11
BRACKET(FUEL PUMP).....19
BRACKET(SPD CTL).....15
BREATHER COVER.....6
BREATHER PLATE CP.....6
BRUSH (-).....25
BRUSH HOLDER AY.....25
BRUSH SET.....25
BRUSH SPRING.....25

C

CAM SHAFT.....11
CARBURETOR AY.....21
CHARGE COIL CP.....23
CHOKE CONTROL ROD.....15
CHOKE LEVER.....15
CLAMP.....15, 19
CLAMP CP.....19, 23
CLAMP(SOLENOID)WIRE.....21
CLEANER BASE CP.....13
CLEANER COVER.....13
CLEANER ELEMENT CP.....13
CLIP.....5, 9
COLLAR(THRO.SHAFT).....21
COLLAR,CHOKE.....21
COLLET-VALVE.....11
CONNECTING ROD AY.....9
COOLING BLOWER UN.....17
CRANK CASE CP.....5
CRANK SHAFT CP.....9
CYLINDER BAFFLE 1 CP.....17
CYLINDER BAFFLE 2 CP.....17
CYLINDER BAFFLE 3.....17
CYLINDER BAFFLE 4 UN.....17
CYLINDER HEAD 1 CP.....5
CYLINDER HEAD 2 CP.....5

D

DOWEL PIN.....5-6
DUST COVER KIT.....25

E

EXHAUST VALVE.....11

F

FILTER(CHOKE SHAFT).....21
FILTER,AIR.....21
FLANGE BOLT.....5-6, 9, 11, 15, 17, 19, 23
FLANGE NUT.....9, 11, 15
FLOAT.....21
FLOAT PIN.....21
FLYWHEEL CP.....23
FUEL PUMP AY.....19

G

GASKET.....5, 21
GASKET (M.B COVER).....5
GASKET 1 (CYL HEAD).....5
GASKET 2 (CYL HEAD).....5
GASKET SET.....6
GASKET(BREATHERPLATE).....6
GASKET(CARBURETOR).....19
GASKET(IN MANIFOLD).....11
GASKET(ROCKER COVER).....5
GASKET,AIR HORN.....21
GASKET,ALUMINUM.....19
GASKET,MAIN PASSAGE.....21
GEAR CASE ASS'Y.....25
GOVERNOR GEAR CP.....5
GOVERNOR LEVER.....15
GOVERNOR ROD.....15
GOVERNOR SHAFT.....15
GOVERNOR SLEEVE.....5
GOVERNOR SPRING.....15
GROMMET, PLUGCAP.....23
GUIDE PLATE.....11

H

HOOK.....6
HOSE CLAMP.....11, 19

I

IGNITION COIL CP.....23
INNER ROTOR.....19
INTAKE MANIFOLD.....11
INTAKE VALVE.....11

J

JET(SLOW).....21
JET,MAIN.....21

K

KEY.....9

L

LABEL(ENGINE NAME).....17

LABEL(TRADE MARK).....11
LABEL(WARNING).....17
LEVER ASSY,CHOKE.....21
LINK PIVOT CP.....15

M

MAGNETIC SWITCH AY.....25
MAIN BEARING.....5
MAINBEARING COVER CP.....5

N

NUT.....11, 15

O

O RING.....19
O-RING,AIR HORN.....21
OIL DRAIN VALVE.....5
OIL FILLER CAP CP.....19
OIL FILTER AY.....19
OIL GAUGE CP.....19
OIL PUMP COVER CP.....19
OIL PUMP FILTER UN.....19
OIL SEAL.....5, 19
OUTER ROTOR.....19

P

PINION AY.....25
PINION STOPPER SET.....25
PIPE.....5
PIPE(PULSE).....5
PISTON.....9
PISTON PIN.....9
PISTON RING SET.....9
PIVOT.....11
PLUG.....5, 21
PLUG TERMINAL.....23
PLUG(OIL RELIEF).....19
PULSE PIPE CP.....19
PUSH ROD CP.....11

R

REAR COVER ASS'Y.....25
REGULATOR CP.....23
RETAINER PLATE.....5
RETURN SPRING.....15
RING GEAR.....23
RING(CHOKE LEVER).....21
ROCKER ARM.....11
ROCKER COVER.....5
ROD SPRING.....15
RUBBER CAP BS.....25
RUBBER FOAM.....15
RUBBER PIPE.....11, 19

S

SCREW.....15
SCREW SET(AIR HORN).....21

Part Description Index (continued)

SCREW SET(FLOAT PIN).....21
SCREW SET(VALVE).....21
SCREW,DRAIN.....21
SCREW,THRO.ADJUST.....21
SCREW,VALVE SET.....21
SEAL-INT VALVE.....5
SHAFT ASSY,CHOKE.....21
SHAFT ASSY,THROTTLE.....21
SHIFT LEVER KIT.....25
SNAP PIN.....15
SPACER.....9, 15
SPARK PLUG.....23
SPARK PLUG CAP.....23
SPEED CONTROL LEV.....15
SPRING RETAINER.....11
SPRING(ADJUST SCREW).....21
SPRING(RELIEF VALVE).....19
SPRING,CHOKE.....21
SPRING,DRAIN.....21
STARTING MOTOR AY.....25
STEEL BALL.....19
STOP DIODE CP.....23
STUD.....5
SWITCH OIL PRESSURE.....5

T

TAPPET.....11
THROUGH BOLT.....25
THRUST BEARING.....5
THRUST WASHER KIT.....25

U

UNION.....5

V

VALVE CP(SOLENOID).....21
VALVE GUIDE.....5
VALVE SPRING.....11
VALVE,CHOKE.....21
VALVE,FLOAT.....21
VALVE,THROTTLE.....21

W

WASHER.....5, 9, 15
WING NUT.....13
WIRE BAND.....23
WIRE CP(IG.COIL).....23
WIRING HARNESS CP.....23
WOODRUFF KEY.....9

Y

YOKE AY.....25

This Page Intentionally Left Blank

PRINTED IN THE USA

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047

Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com