

PARTS MANUAL

MODEL
EH650DC

EH650DC2791

05/15



SUBARU

Industrial Power Products

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047 - Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com

© 2012 Subaru Industrial Power Products

Group Index

Group Name	Page
1000 Ship Loose.....	4
101 Crankcase.....	6
200 Crankshaft.....	10
301 Intake & Exhaust.....	12
315 Intake & Exhaust.....	14
330 Intake & Exhaust.....	16
400 Governor.....	18
500 Cooling & Starting.....	20
600 Fuel & Lubricant.....	22
610 Fuel & Lubricant.....	24
630 Fuel & Lubricant.....	26
642 Carburetor.....	28
700 Electric Device.....	32
731 Electric Device.....	34
900 Accessory.....	36
 Part Number Index.....	 38
Part Description Index.....	39

FIG. 1000

(Illustrations are excluded.)

(**FIG 1000**は単独発送部品につき、
イラストは省略します。)

EH65/64/63

263100000W01

1000 Ship Loose


Ref	Part Number.	Description	Qty	Remark
1	31F-35004-01	MOUNT CP	4	
2	31G-39501-00	STOPPER AY	1	
3	056-30000-60	WIRE BAND	5	4.7BX1.3TX120L
4	056-60001-70	CLAMP	1	8.5DX10BX95LX0.7T
5	978-21611-20	ROD(BATTERY)	2	
6	31F-33001-01	BATTERY STAY CP	1	
7	002-41060-00	WING NUT	2	
8	31F-32001-13	BATTERY TERMINAL	1	
9	KU3-11062-51	ECU(O/S & R/C) CP	1	
10	KU3-11055-01	IDLE CONTROL UN CP	1	
11	085-10619-41	RUBBER PIPE	1	
12	085-10620-51	RUBBER PIPE	1	
13	056-11100-30	HOSE CLAMP	4	11.5DX8BX0.7T
14	31F-39002-03	PURSE LOCK	3	
15	31G-49501-03	CONNECTOR CAP	1	
16	391-48301-01	RELAY(CA) AY	1	
17	023-00603-30	SPACER	1	6.5DX12DX12T
18	420-35AE0-10	CANISTER AY	1	
19	001-04081-60	FLANGE BOLT	3	M8X1.25X16DX16L
20	002-38080-00	FLANGE NUT	3	M8X1.25X17DX7.5H
21	31G-36501-00	RUBBER PIPE	1	
22	056-11100-20	HOSE CLAMP	1	11.5DX8BX0.7T
23	056-11100-30	HOSE CLAMP ¹	1	11DX8BX0.7T
24	085-10613-40	RUBBER PIPE	1	6DX11DX350L
25	056-11100-20	HOSE CLAMP	2	11.5DX8BX0.7T
26	085-11000-00	RUBBER PIPE ²	1	
27	056-11300-10	HOSE CLAMP	1	13.2DX10BX0.8T
28	056-61500-20	CLAMP(15)	1	
29	001-04061-20	FLANGE BOLT	1	M6X1.0X13DX12L
30	073-20050-80	LABEL(F.STRAINER)	1	25X35
31	073-20045-10	LABEL(SYMBOL-TANK)	1	50X71
32	073-20048-60	LABEL(HOT & GAS)	1	24X88
33	073-20058-60	LABEL(WARNING)	1	

Footnotes

1: INTERCHANGEABLE W/056-11100-40

2: INTERCHANGEABLE W/085-11000-00

101 Crankcase



101 Crankcase


Ref	Part Number.	Description	Qty	Remark
10	263-10111-21	CRANK CASE CP	1	
20	263-14211-03	VALVE GUIDE	2	6DX11DX32.5L
21	056-51000-50	CLIP	1	10.7DX0.9D
22	263-14211-03	VALVE GUIDE	2	6DX11DX32.5L
23	056-51000-50	CLIP	1	10.7DX0.9D
26	132-11AA1-10	SEAL-INT VALVE	1	
27	132-11AA1-10	SEAL-INT VALVE	1	
28	263-35341-03	RETAINER PLATE	1	11DX17.3DX27DX4.7H
29	263-35341-03	RETAINER PLATE	1	11DX17.3DX27DX4.7H
40	263-15805-03	MAIN BEARING	1	45DX50DX23B
50	031-00801-10	DOWEL PIN	2	
55	263-55601-03	PIPE	2	11DX8.8DX8L
60	010-50802-90	STUD	4	M8X1.25X30L
61	010-50802-90	STUD	4	M8X1.25X30L
75	044-00800-10	OIL SEAL	1	8DX14DX4B
80	040-11400-30	PLUG	2	
85	235-15421-03	BLIND PLUG	1	
90	021-11400-20	GASKET	2	
130	159-65401-03	PIPE(PULSE)	1	4DX6DX25L
195	263-15901-03	UNION	1	3/4X16UNFX30L
200	248-76102-H1	SWITCH OIL PRESSURE	1	
210	263-11101-71	MAINBEARING COVER CP	1	
220	044-04200-30	OIL SEAL	1	42DX60DX9B
230	263-15805-03	MAIN BEARING	1	45DX50DX23B
250	263-45004-11	GOVERNOR GEAR CP	1	
255	263-46215-A3	THRUST BEARING	1	
257	263-46214-03	WASHER	2	
260	277-41902-01	GOVERNOR SLEEVE	1	
290	263-16002-A3	GASKET (M.B COVER)	1	T=0.5
300	011-00802-20	FLANGE BOLT	10.00	M8X1.25X17DX45L
610	263-13211-11	CYLINDER HEAD 1 CP	1	
615	263-13311-11	CYLINDER HEAD 2 CP	1	
620	263-15021-41	GASKET 1 (CYL HEAD)	1	
621	263-15121-31	GASKET 2 (CYL HEAD)	1	
630	011-01000-70	FLANGE BOLT	8	M10X1.25X19DX65L
680	263-15505-03	ROCKER COVER	1	
681	263-15503-03	ROCKER COVER	1	
690	263-16111-03	GASKET(ROCKER COVER)	2	
700	031-00600-20	DOWEL PIN	4	6DX14.5L

101 Crankcase

Ref	Part Number.	Description	Qty	Remark
710	011-00601-01	FLANGE BOLT	8	M6X1.0X13DX28L
800	280-19001-03	HOOK	2	
810	263-14301-03	BREATHER COVER	1	
820	280-14411-01	BREATHER PLATE CP	1	
830	263-16007-03	GASKET(BREATHERPLATE	2	
860	011-00600-30	FLANGE BOLT	2	M6X1.0X14DX14L
960	263-99001-47	GASKET SET	1	Start Date: 12/31/9999 0:00:00.

This Page Intentionally Left Blank


200 Crankshaft



200 Crankshaft

Ref	Part Number.	Description	Qty	Remark
10	263-21211-11	CRANK SHAFT CP	1	
40	263-25012-A3	SPACER	1	45.3DX58DX0.8T
41	263-25013-A3	SPACER	1	45.3DX58DX1.0T
42	263-25014-A3	SPACER	1	45.3DX58DX1.2T
50	018-01800-10	FLANGE NUT	1	M18X1.5X31DX14H
65	003-10180-00	WASHER	1	19DX32DX2.6T
70	005-32054-01	WOODRUFF KEY	1	5BX7.5HX19D
310	263-22601-30	CONNECTING ROD AY	2	
311	263-22602-20	CONNECTING ROD AY	2	0.25 U.S.
320	001-05084-00	FLANGE BOLT	4	M8X1.25X16DX40L
350	263-23301-33	PISTON PIN	2	21DX15DX64.2L
360	263-23421-J3	PISTON	2	STD (80DX55H)
361	263-23422-J3	PISTON	2	0.25 O.S.(80DX55H)
362	263-23423-J3	PISTON	2	0.50 O.S.(80DX55H)
370	263-23501-37	PISTON RING SET	2	STD (80D)
371	263-23502-37	PISTON RING SET	2	0.25 O.S.(80D)
372	263-23503-37	PISTON RING SET	2	0.50 O.S.(80D)
380	056-52100-20	CLIP	4.00	22.1DX1.4D

301 Intake & Exhaust




263030102W00

301 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
10	280-31701-13	CAM SHAFT	1	L=169 133DX12B N=66
50	263-33301-A3	TAPPET	4	27DX9DX48L
60	246-33611-03	VALVE SPRING	4	22.2DX2.9DX37L N=6.5
70	246-33711-13	SPRING RETAINER	4	7.6DX26DX8T
80	263-33401-H3	INTAKE VALVE	2	
90	263-33502-H3	EXHAUST VALVE	2	
95	246-35501-03	COLLET-VALVE	8	
210	263-35333-01	PUSH ROD CP	4	
220	267-36102-03	ROCKER ARM	4	
230	263-35801-03	BOLT(PIVOT)	4	
235	267-35701-03	PIVOT	4	
240	017-00601-10	NUT	4	M6X0.75X3.6H
260	263-37002-A3	GUIDE PLATE	2	
330	263-37001-H1	BRACKET(MUFFLER)	1	
340	270-35201-01	GASKET CP (MUFFLER)	2	T=0.4 30D 8.5DX52P
350	002-38080-00	FLANGE NUT	4	M8X1.25X17DX7.5H
370	001-14082-00	BOLT AND WASHER AY	2	M8X1.25X20L W/W,SW
375	011-00600-30	FLANGE BOLT	2	M6X1.0X14DX14L
500	280-33001-J3	INTAKE MANIFOLD	1	
555	263-35513-03	GASKET(IN MANIFOLD)	2	
580	011-00600-20	FLANGE BOLT	3	M6X1.0X14DX12L
590	002-38080-00	FLANGE NUT	4	M8X1.25X17DX7.5H
850	263-18003-03	RUBBER PIPE	1	14.5DX20.5D FORMED
853	056-12000-20	HOSE CLAMP	2	20DX10BX1T
920	263-91721-03	LABEL(TRADE MARK)	1	50X95

315 Intake & Exhaust




EH65/64/63

263031500W01

315 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
510	280-32602-00	AIR CLEANER AY	1	
512	280-32625-01	CLEANER BASE CP	1	
514	263-32630-03	CLEANER COVER	1	
516	263-32640-01	WING NUT	1	
520	263-32610-A1	CLEANER ELEMENT CP	1	


330 Intake & Exhaust



330 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
310	263-30102-L1	MUFFLER CP	1	
315	263-37321-H2	SPARK ARRESTER	1	
390	263-37302-H3	CLAMP AY	1	

400 Governor



EH65/64/63


263040001W01

400 Governor

Ref	Part Number.	Description	Qty	Remark
10	263-42301-B3	GOVERNOR LEVER	1	
20	263-42201-A3	GOVERNOR SHAFT	1	
25	X23-00801-50	SPACER	1	8.3DX11.9DX6.4T
26	003-10080-00	WASHER	2	8.5DX16DX1.2T.
30	263-42701-13	GOVERNOR ROD	1	
40	263-42801-13	ROD SPRING	1	
50	005-11060-01	SNAP PIN	1	
60	001-14063-00	BOLT AND WASHER AY	1	M6X1.0X30L W/W,SW
70	018-60600-20	NUT	1	M6X1.0X4.9H SQUARE
80	263-42505-13	GOVERNOR SPRING	1	11DX1.2DX137L N=31
310	263-43301-A3	SPEED CONTROL LEVER	1	
340	227-43501-13	STOP PLATE	1	
350	277-45002-03	SPRING WASHER	1	T=0.4
355	021-70600-30	FRICTION WASHER	2	6.5DX33DX0.6T FIBER
360	011-50500-20	BOLT	1	M5X0.8X35L
370	002-27050-00	NUT	1	
381	002-35060-00	SELF LOCK NUT	1	M6X1.0X13DX6.9H
435	263-45011-A2	BRACKET UN(SPD CTL)	1	
485	011-00600-20	FLANGE BOLT	2	M6X1.0X14DX12L

500 Cooling & Starting

FIG. 500




EH65/64/63

263050001W00

500 Cooling & Starting

Ref	Part Number.	Description	Qty	Remark
10	263-51121-H2	BLOWER HOUSING UN	1	
40	011-00600-30	FLANGE BOLT	7	M6X1.0X14DX14L
42	011-00603-50	FLANGE BOLT	1	
60	263-52622-01	CYLINDER BAFFLE 1 CP	1	
61	263-52724-01	CYLINDER BAFFLE 2 CP	1	
62	263-52802-A3	CYLINDER BAFFLE 3	1	
63	263-52922-02	CYLINDER BAFFLE 4 UN	1	
80	011-00600-20	FLANGE BOLT	8	M6X1.0X14DX12L
110	263-54101-H2	COOLING BLOWER UN	1	
113	001-14061-60	BOLT AND WASHER AY	4	M6X1.0X16L W/W,SW
130	056-60002-50	CLAMP	1	6.5DX10BX95LX0.6T

600 Fuel & Lubricant





263060002W00

600 Fuel & Lubricant

Ref	Part Number.	Description	Qty	Remark
80	X85-10616-60	RUBBER PIPE	1	6.4DX12.7DX430L
90	263-68501-03	HOSE CLAMP	2	11.4DX7.9BX0.7T
230	085-10301-10	RUBBER PIPE	1	3DX6DX350L
235	206-75501-01	CLAMP CP	2	10DXM6X12BX0.6T
270	263-63603-01	OIL GAUGE CP	1	
290	263-66201-A3	GASKET(CARBURETOR)	1	T=0.4 34D 8.5DX84.5P
510	267-62201-10	FUEL PUMP AY	1	
515	263-65002-A3	BRACKET(FUEL PUMP)	1	
520	263-62653-B1	PULSE PIPE CP	1	
522	X85-10616-30	RUBBER PIPE	1	6.4DX12.7DX160L
523	263-68501-03	HOSE CLAMP	2	11.4DX7.9BX0.7T
540	011-00600-20	FLANGE BOLT	5	M6X1.0X14DX12L
573	011-00801-10	FLANGE BOLT	2	M8X1.25X14DX80L
610	263-63904-H3	INNER ROTOR	1	
615	263-63905-H3	OUTER ROTOR	1	
620	263-64002-01	OIL PUMP COVER CP	1	
623	044-03501-70	OIL SEAL	1	35DX48DX8B
625	X24-08900-30	O RING	1	
640	011-00600-30	FLANGE BOLT	4	M6X1.0X14DX14L
650	263-64302-02	OIL PUMP FILTER UN	1	
653	263-65011-A3	FLANGE BOLT	1	
660	248-65801-10	OIL FILTER AY	1	
670	263-65001-13	PLUG(OIL RELIEF)	1	M14X1.5X20DX12L.
673	003-70140-00	GASKET,ALUMINUM	1	
677	263-66001-03	SPRING(RELIEF.VALVE)	1	7.8DX1DX25L N=8.5
680	006-90308-00	STEEL BALL	1	
714	280-63602-A1	OIL FILLER CAP CP	1	
718	263-64414-A3	O RING	1	26.6DX31.9D

610 Fuel & Lubricant



263061001W00


610 Fuel & Lubricant

Ref	Part Number.	Description	Qty	Remark
10	31G-36201-01	FUEL TANK CP	1	
30	043-05900-20	FUEL TANK CAP AY	1	
40	064-15400-11	FUEL FILTER	1	54DX58DX48H
45	064-80015-00	FUEL GAUGE CP	1	

630 Fuel & Lubricant


064-20021-01
064-20114-00

50




064-20084-00

50




064-20036-01
064-20095-00
064-20107-00

50




064-20100-01

50



064-20064-00

50




263063002W00

630 Fuel & Lubricant

Ref	Part Number.	Description	Qty	Remark
50	064-20095-00	FUEL STRAINER AY	1	
-1	064-20095-10	FILTER	1	
-2	064-20030-30	RUBBER PACKING	1	
-3	064-20036-10	CUP	1	

642 Carburetor



642 Carburetor

Ref	Part Number.	Description	Qty	Remark
210	263-62385-10	CARBURETOR AY ¹	1	
-1	263-62535-08	VALVE, THROTTLE	1	
-2	261-62352-08	SCREW, VALVE SET	5	
-3	258-62525-08	VALVE, CHOKE	1	
-4	258-62555-08	SCREW SET (VALVE)	2	
-5	258-62420-08	JET (SLOW)	1	
-8	263-62523-08	SHAFT ASSY, CHOKE	1	
-11	263-62534-08	SHAFT ASSY, THROTTLE	1	
-13	258-62551-08	RING (CHOKE LEVER)	1	
-14	226-62501-08	VALVE, FLOAT	1	
-15	258-62515-08	FLOAT PIN	1	
-18	280-62545-08	GASKET, AIR HORN	1	
-19	280-62505-08	FLOAT	1	
-22	263-62400-08	JET, MAIN	1	
-28	215-62353-08	SCREW, DRAIN	1	
-29	215-62446-08	SPRING, DRAIN	1	
-38	258-62556-08	SCREW SET (FLOAT PIN)	1	
-40	263-62451-08	SCREW, THRO. ADJUST	1	
-41	258-62445-08	SPRING (ADJUST SCREW)	1	
-57	258-62450-08	SCREW SET (AIR HORN)	2	
-58	263-62584-08	SCREW, OPENER SET	2	
-59	263-62560-08	O-RING, AIR HORN	1	
-61	280-62551-08	COLLAR, CHOKE	1	
-62	258-62554-08	FILTER (CHOKE)	1	
-93	263-62527-08	LEVER ASSY, CHOKE	1	
-94	263-62447-08	SPRING, CHOKE	1	
-102	226-62580-08	FILTER, AIR	1	
-103	258-62570-08	COLLAR (THRO. SHAFT)	1	
-125	263-62556-08	VALVE CP, (SOLENOID)	1	
-126	258-62546-08	GASKET, MAIN PASSAGE	1	
-129	258-62566-08	CLAMP (SOLENOID) WIRE	1	
-136	263-62555-08	GASKET	1	
-195	263-62552-08	PLUG	1	
-202	263-62506-08	ARM, CHOKE	1	
-204	263-62591-08	FILTER, AIR	1	
-207	161-62345-08	SCREW, LEVER SET	1	

Footnotes

1: INTERCHANGEABLE W/263-62385-00

642 Carburetor


Ref	Part Number.	Description	Qty	Remark
-210	263-62360-08	OPENER AY, CHOKE	1	
-211	263-62566-08	PIPE, RUBBER	1	
-213	263-62583-08	BINDER, CORD	1	
-216	263-62353-08	ROD, CHOKE PISTON	1	
-218	263-62596-08	WASHER, ROD	2	
-219	107-62377-08	E-RING, ROD	2	
-380	107-62376-08	COVER ASSY, THERMO	1	
-382	107-62373-08	GASKET, THERMO, CASE	1	
-384	107-62375-08	PLATE, BI-METAL SET	1	
-390	263-62562-08	HOLDER CP BI-METAL	1	
-392	263-62589-08	SCREW, HOLDER SET	2	

Footnotes

1: INTERCHANGEABLE W/263-62385-00

This Page Intentionally Left Blank

700 Electric Device




263070002W00

700 Electric Device

Ref	Part Number.	Description	Qty	Remark
10	263-77206-01	FLYWHEEL CP	1	
11	263-78202-21	IGNITION COIL CP	2	
15	263-79403-D1	CHARGE COIL CP	1	
20	263-71002-H3	RING GEAR	1	
30	001-14062-50	BOLT AND WASHER AY	4	M6X1.0X25L W/W,SW
35	001-16052-00	BOLT & WASHER AY	4	
55	263-73016-01	WIRE 4 CP	1	L=300 BLACK/WHITE
56	263-73017-01	WIRE 5 CP	1	L=480 BLACK
95	X65-91000-10	PLUG TERMINAL	2	
100	065-01402-80	SPARK PLUG	2	NGK BPR5ES
110	X65-51000-10	SPARK PLUG CAP	2	
130	011-00801-00	FLANGE BOLT	2	M8X1.25X17DX65L
170	206-75501-01	CLAMP CP	1	10DXM6X12BX0.6T
216	002-38080-00	FLANGE NUT	1	M8X1.25X17DX7.5H
220	066-00003-30	SWITCH	1	
-1	006-00099-80	KEY, SWITCH	2	MARK 103
291	263-71903-A1	REGULATOR CP	1	
301	011-00601-40	FLANGE BOLT	2	M6X1.0X14DX18L
345	263-73112-01	WIRE 6 CP	1	L=350 RED
384	056-30000-10	WIRE BAND	4	4.5BX1.2TX200L
410	056-60002-50	CLAMP	3	6.5DX10BX95LX0.6T
760	263-73102-11	WIRE AY(OIL PRE.SW.)	1	L=900 GRAY
770	206-75501-01	CLAMP CP	1	10DXM6X12BX0.6T


731 Electric Device



731 Electric Device

Ref	Part Number.	Description	Qty	Remark
120	263-70504-J0	STARTING MOTOR AY	1	
-15	263-70516-H8	SOLENOID SWITCH	1	

900 Accessory



EH65/64/63

263090000W01

900 Accessory

Ref	Part Number.	Description	Qty	Remark
10	227-90301-H0	ACCESSORY TOOL KIT	1.00	Start Date: 9/22/2004 0:00:00. Start Date: 12/31/9999 0:00:00.

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
001-04061-20	5	085-10613-40	5	263-32610-A1	15	263-70516-H8	35
001-04081-60	5	085-10619-41	5	263-32630-03	15	263-71002-H3	33
001-05084-00	11	085-10620-51	5	263-32640-01	15	263-71903-A1	33
001-14061-60	21	085-11000-00	5	263-33301-A3	13	263-73016-01	33
001-14062-50	33	107-62373-08	30	263-33401-H3	13	263-73017-01	33
001-14063-00	19	107-62375-08	30	263-33502-H3	13	263-73102-11	33
001-14082-00	13	107-62376-08	30	263-35333-01	13	263-73112-01	33
001-16052-00	33	107-62377-08	30	263-35341-03	7	263-77206-01	33
002-27050-00	19	132-11AA1-10	7	263-35513-03	13	263-78202-21	33
002-35060-00	19	159-65401-03	7	263-35801-03	13	263-79403-D1	33
002-38080-00	5, 13, 33	161-62345-08	29	263-37001-H1	13	263-91721-03	13
002-41060-00	5	206-75501-01	23, 33	263-37002-A3	13	263-99001-47	8
003-10080-00	19	215-62353-08	29	263-37302-H3	17	267-35701-03	13
003-10180-00	11	215-62446-08	29	263-37321-H2	17	267-36102-03	13
003-70140-00	23	226-62501-08	29	263-42201-A3	19	267-62201-10	23
005-11060-01	19	226-62580-08	29	263-42301-B3	19	270-35201-01	13
005-32054-01	11	227-43501-13	19	263-42505-13	19	277-41902-01	7
006-00099-80	33	227-90301-H0	37	263-42701-13	19	277-45002-03	19
006-90308-00	23	235-15421-03	7	263-42801-13	19	280-14411-01	8
010-50802-90	7	246-33611-03	13	263-43301-A3	19	280-19001-03	8
011-00600-20	13, 19, 21, 23	246-33711-13	13	263-45004-11	7	280-31701-13	13
011-00600-30	8, 13, 21, 23	246-35501-03	13	263-45011-A2	19	280-32602-00	15
011-00601-01	8	248-65801-10	23	263-46214-03	7	280-32625-01	15
011-00601-40	33	248-76102-H1	7	263-46215-A3	7	280-33001-J3	13
011-00603-50	21	258-62420-08	29	263-51121-H2	21	280-62505-08	29
011-00801-00	33	258-62445-08	29	263-52622-01	21	280-62545-08	29
011-00801-10	23	258-62450-08	29	263-52724-01	21	280-62551-08	29
011-00802-20	7	258-62515-08	29	263-52802-A3	21	280-63602-A1	23
011-01000-70	7	258-62525-08	29	263-52922-02	21	31F-32001-13	5
011-50500-20	19	258-62546-08	29	263-54101-H2	21	31F-33001-01	5
017-00601-10	13	258-62551-08	29	263-55601-03	7	31F-35004-01	5
018-01800-10	11	258-62554-08	29	263-62353-08	30	31F-39002-03	5
018-60600-20	19	258-62555-08	29	263-62360-08	30	31G-36201-01	25
021-11400-20	7	258-62556-08	29	263-62385-10	29	31G-36501-00	5
021-70600-30	19	258-62566-08	29	263-62400-08	29	31G-39501-00	5
023-00603-30	5	258-62570-08	29	263-62447-08	29	31G-49501-03	5
031-00600-20	7	261-62352-08	29	263-62451-08	29	391-48301-01	5
031-00801-10	7	263-10111-21	7	263-62506-08	29	420-35AE0-10	5
040-11400-30	7	263-11101-71	7	263-62523-08	29	978-21611-20	5
043-05900-20	25	263-13211-11	7	263-62527-08	29	KU3-11055-01	5
044-00800-10	7	263-13311-11	7	263-62534-08	29	KU3-11062-51	5
044-03501-70	23	263-14211-03	7	263-62535-08	29	X23-00801-50	19
044-04200-30	7	263-14301-03	8	263-62552-08	29	X24-08900-30	23
056-11100-20	5	263-15021-41	7	263-62555-08	29	X65-51000-10	33
056-11100-30	5	263-15121-31	7	263-62556-08	29	X65-91000-10	33
056-11300-10	5	263-15503-03	7	263-62560-08	29	X85-10616-30	23
056-12000-20	13	263-15505-03	7	263-62562-08	30	X85-10616-60	23
056-30000-10	33	263-15805-03	7	263-62566-08	30		
056-30000-60	5	263-15901-03	7	263-62583-08	30		
056-51000-50	7	263-16002-A3	7	263-62584-08	29		
056-52100-20	11	263-16007-03	8	263-62589-08	30		
056-60001-70	5	263-16111-03	7	263-62591-08	29		
056-60002-50	21, 33	263-18003-03	13	263-62596-08	30		
056-61500-20	5	263-21211-11	11	263-62653-B1	23		
064-15400-11	25	263-22601-30	11	263-63603-01	23		
064-20030-30	27	263-22602-20	11	263-63904-H3	23		
064-20036-10	27	263-23301-33	11	263-63905-H3	23		
064-20095-00	27	263-23421-J3	11	263-64002-01	23		
064-20095-10	27	263-23422-J3	11	263-64302-02	23		
064-80015-00	25	263-23423-J3	11	263-64414-A3	23		
065-01402-80	33	263-23501-37	11	263-65001-13	23		
066-00003-30	33	263-23502-37	11	263-65002-A3	23		
073-20045-10	5	263-23503-37	11	263-65011-A3	23		
073-20048-60	5	263-25012-A3	11	263-66001-03	23		
073-20050-80	5	263-25013-A3	11	263-66201-A3	23		
073-20058-60	5	263-25014-A3	11	263-68501-03	23		
085-10301-10	23	263-30102-L1	17	263-70504-J0	35		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

A

ACCESSORY TOOL KIT.....37
AIR CLEANER AY.....15
ARM, CHOKE.....29

B

BATTERY STAY CP.....5
BATTERY TERMINAL.....5
BINDER, CORD.....30
BLIND PLUG.....7
BLOWER HOUSING UN.....21
BOLT.....19
BOLT & WASHER AY.....33
BOLT AND WASHER AY.....13, 19, 21, 33
BOLT(PIVOT).....13
BRACKET UN(SPD CTL).....19
BRACKET(FUEL PUMP).....23
BRACKET(MUFFLER).....13
BREATHER COVER.....8
BREATHER PLATE CP.....8

C

CAM SHAFT.....13
CANISTER AY.....5
CARBURETOR AY.....29
CHARGE COIL CP.....33
CLAMP.....5, 21, 33
CLAMP AY.....17
CLAMP CP.....23, 33
CLAMP(15).....5
CLAMP(SOLENOID)WIRE.....29
CLEANER BASE CP.....15
CLEANER COVER.....15
CLEANER ELEMENT CP.....15
CLIP.....7, 11
COLLAR(THRO.SHAFT).....29
COLLAR,CHOKE.....29
COLLET-VALVE.....13
CONNECTING ROD AY.....11
CONNECTOR CAP.....5
COOLING BLOWER UN.....21
COVER ASSY, THERMO.....30
CRANK CASE CP.....7
CRANK SHAFT CP.....11
CUP.....27
CYLINDER BAFFLE 1 CP.....21
CYLINDER BAFFLE 2 CP.....21
CYLINDER BAFFLE 3.....21
CYLINDER BAFFLE 4 UN.....21
CYLINDER HEAD 1 CP.....7
CYLINDER HEAD 2 CP.....7

D

DOWEL PIN.....7

E

E-RING, ROD.....30
ECU(O/S & R/C) CP.....5
EXHAUST VALVE.....13

F

FILTER.....27
FILTER(CHOKE).....29
FILTER, AIR.....29
FLANGE BOLT.....5, 7-8, 11, 13, 19, 21, 23, 33
FLANGE NUT.....5, 11, 13, 33
FLOAT.....29
FLOAT PIN.....29
FLYWHEEL CP.....33
FRICTION WASHER.....19
FUEL FILTER.....25
FUEL GAUGE CP.....25
FUEL PUMP AY.....23
FUEL STRAINER AY.....27
FUEL TANK CAP AY.....25
FUEL TANK CP.....25

G

GASKET.....7, 29
GASKET (M.B COVER).....7
GASKET 1 (CYL HEAD).....7
GASKET 2 (CYL HEAD).....7
GASKET CP (MUFFLER).....13
GASKET SET.....8
GASKET(BREATHERPLATE).....8
GASKET(CARBURETOR).....23
GASKET(IN MANIFOLD).....13
GASKET(ROCKER COVER).....7
GASKET, THERMO, CASE.....30
GASKET,AIR HORN.....29
GASKET,ALUMINUM.....23
GASKET,MAIN PASSAGE.....29
GOVERNOR GEAR CP.....7
GOVERNOR LEVER.....19
GOVERNOR ROD.....19
GOVERNOR SHAFT.....19
GOVERNOR SLEEVE.....7
GOVERNOR SPRING.....19
GUIDE PLATE.....13

H

HOLDER CP BI-METAL.....30
HOOK.....8
HOSE CLAMP.....5, 13, 23

I

IDLE CONTROL UN CP.....5
IGNITION COIL CP.....33
INNER ROTOR.....23
INTAKE MANIFOLD.....13

INTAKE VALVE.....13

J

JET(SLOW).....29
JET,MAIN.....29

K

KEY, SWITCH.....33

L

LABEL(F,STRAINER).....5
LABEL(HOT & GAS).....5
LABEL(SYMBOL-TANK).....5
LABEL(TRADE MARK).....13
LABEL(WARNING).....5
LEVER ASSY,CHOKE.....29

M

MAIN BEARING.....7
MAINBEARING COVER CP.....7
MOUNT CP.....5
MUFFLER CP.....17

N

NUT.....13, 19

O

O RING.....23
O-RING,AIR HORN.....29
OIL FILLER CAP CP.....23
OIL FILTER AY.....23
OIL GAUGE CP.....23
OIL PUMP COVER CP.....23
OIL PUMP FILTER UN.....23
OIL SEAL.....7, 23
OPENER AY, CHOKE.....30
OUTER ROTOR.....23

P

PIPE.....7
PIPE(PULSE).....7
PIPE, RUBBER.....30
PISTON.....11
PISTON PIN.....11
PISTON RING SET.....11
PIVOT.....13
PLATE, BI-METAL SET.....30
PLUG.....7, 29
PLUG TERMINAL.....33
PLUG(OIL RELIEF).....23
PULSE PIPE CP.....23
PURSE LOCK.....5
PUSH ROD CP.....13

R

REGULATOR CP.....33

Part Description Index (continued)

RELAY(CA) AY.....5
RETAINER PLATE.....7
RING GEAR.....33
RING(CHOKE LEVER).....29
ROCKER ARM.....13
ROCKER COVER.....7
ROD SPRING.....19
ROD(BATTERY).....5
ROD, CHOKE PISTON.....30
RUBBER PACKING.....27
RUBBER PIPE.....5, 13, 23

S

SCREW SET(AIR HORN).....29
SCREW SET(FLOAT PIN).....29
SCREW SET(VALVE).....29
SCREW, HOLDER SET.....30
SCREW, LEVER SET.....29
SCREW, OPENER SET.....29
SCREW,DRAIN.....29
SCREW,THRO.ADJUST.....29
SCREW,VALVE SET.....29
SEAL-INT VALVE.....7
SELF LOCK NUT.....19
SHAFT ASSY,CHOKE.....29
SHAFT ASSY,THROTTLE.....29
SNAP PIN.....19
SOLENOID SWITCH.....35
SPACER.....5, 11, 19
SPARK ARRESTER.....17
SPARK PLUG.....33
SPARK PLUG CAP.....33
SPEED CONTROL LEVER.....19
SPRING RETAINER.....13
SPRING WASHER.....19
SPRING(ADJUST SCREW).....29
SPRING(RELIEF VALVE).....23
SPRING,CHOKE.....29
SPRING,DRAIN.....29
STARTING MOTOR AY.....35
STEEL BALL.....23
STOP PLATE.....19
STOPPER AY.....5
STUD.....7
SWITCH.....33
SWITCH OIL PRESSURE.....7

T

TAPPET.....13
THRUST BEARING.....7

U

UNION.....7

V

VALVE CP,(SOLENOID).....29
VALVE GUIDE.....7
VALVE SPRING.....13
VALVE,CHOKE.....29
VALVE,FLOAT.....29
VALVE,THROTTLE.....29

W

WASHER.....7, 11, 19
WASHER, ROD.....30
WING NUT.....5, 15
WIRE 4 CP.....33
WIRE 5 CP.....33
WIRE 6 CP.....33
WIRE AY(OIL PRE.SW.).....33
WIRE BAND.....5, 33
WOODRUFF KEY.....11

This Page Intentionally Left Blank

PRINTED IN THE USA

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047

Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com