

EH180V00053	N_EX,S HI-WHEEL 98/99
261A00230G	CRANK CASE GROUP
26110101A1	CRANK CASE CP
2611010112	CRANK CASE UN
2611010014	CRANK CASE UN.
2611010109	CRANK CASE
2271380103	CYLINDER LINER
2271380105	CYLINDER LINER
440250150	OIL SEAL
600250010	BALL BEARING
X310060020	DOWEL PIN
26111002A0	MAINBEARING COVER AY
2611100201	MAINBEARING COVER CP
2611100203	MAIN BEARING COVER
2274620103	GOVERNOR GEAR SHAFT
440250070	OIL SEAL
600250010	BALL BEARING
2616500103	OIL JET
26145401C1	GOVERNOR GEAR CP
26145003B3	GOVERNOR GEAR
2634160103	FLYWEIGHT
307300070	PIN
2054190103	GOVERNOR SLEEVE
2616510103	OIL SHELTER PLATE
X110060020	FLANGE BOLT
2616390111	OIL PUMP (INNER)CP
2616390103	OIL PUMP(INNER)
2616395003	OIL PUMP SHAFT
2616390203	OIL PUMP(OUTER)
2616530203	OIL PUMP COVER
2616540113	O RING
2616570201	OIL DRAIN PLUG
2616540303	O RING(OIL DRAIN)
2611310111	CYLINDER HEAD CP
2611310112	CYLINDER HEAD UN
2611310103	CYLINDER HEAD
2611310004	CYLINDER HEAD.
2381400103	INTAKE VALVE SEAT
2381400105	INTAKE VALVE SEAT
2381410103	EXHAUST VALVE SEAT
2381410105	EXHAUST VALVE SEAT
2611420103	VALVE GUIDE
2611420105	VALVE GUIDE BALNK
105060140	STUD
X310060020	DOWEL PIN

2611500113	GASKET (HEAD)
2271600213	GASKET(BEARING COV)
2611700103	LEAF VALVE
2611701103	RETAINER PLATE
2611430101	TAPPET COVER CP
2611610101	BREATHER PLATE CP
2611610103	BREATHER PLATE
2271600303	LEAF VALVE
2271600403	RETAINER PLATE
2261620103	OIL SHELTER PLATE
57120051	RIVET
2611600603	GASKET(TAPPET COVER)
2611600703	GASKET(BREATHER PLA)
2611550111	ROCKER COVER CP
2611550113	ROCKER COVER
26116005A3	GASKET(ROCKER COVER)
26110801A3	RUBBER PIPE
X561110030	HOSE CLAMP
X130060040	BOLT AND WASHER AY
X110060030	FLANGE BOLT
X110080100	FLANGE BOLT
X110060020	FLANGE BOLT
X110060020	FLANGE BOLT
261B00040G	CRANKSHAFT,PISTON GR
2612600111	CRANK SHAFT CP
2612600113	CRANK SHAFT
261260N014	CRANK SHAFT.
2272230203	CRANKSHAFT GEAR
2272230204	CRANK SHAFT GEAR.
2272250310	CONNECTING ROD AY
2272250101	CONNECTING ROD CP
2272251005	CONROD CP
2272300113	CONNECTING ROD BOLT
2142330113	PISTON PIN
2272340103	PISTON
2612360103	TOP RING
2612370103	SECOND RING
2612390101	OIL RING CP
565140010	CLIP
X230250180	SPACER
X230250190	SPACER
X230250200	SPACER
21814000	NUT
32014000	SPRING WASHER
323030010	WOODRUFF KEY
261C00200G	INTAKE EXHAUST GROUP
2613170111	CAMSHAFT CP

2613170103	CAMSHAFT
2533170014	CAMSHAFT.
2273640113	RELEASE LEVER
2273870103	RETURN SPRING
2273860123	PIN (SPRING)
31522000	SNAPRING (OUTER)
51904100	SPRING PIN
26133301A3	TAPPET
2613340103	INTAKE VALVE
2613350113	EXHAUST VALVE
2613360103	VALVE SPRING
2693370103	SPRING RETAINER
13210KA031	COLLET-VALVE
2613530203	PUSH ROD
26136001A3	ROCKER ARM
2613580113	BOLT(PIVOT)
2673570103	PIVOT
170060110	NUT
26136501A3	GUIDE PLATE
2613010101	MUFFLER CP
26134203A1	MUFFLER COVER CP
26134202A2	MUFFLER COVER UN
2613520101	GASKET(EXHAUST)CP
2613260110	AIR CLEANER AY
2613510101	AIR CLEANER COVER
26138001A1	BRACKET (A/C) CP
26138002A1	BRACKET(A/C.COVE)CP
2273290113	INSULATOR
2613590403	GASKET 2 (INSULATOR)
26135901A3	GASKET(INNER VENT)
X130080030	BOLT AND WASHER ASSY
11008160	BOLT & WASHER AY
X152050010	TAPPING SCREW
23806000	FLANGE NUT
X110060020	FLANGE BOLT
X110060030	FLANGE BOLT
X152060010	TAPPING BOLT
261D00030G	GOVERNOR,OPERATION G
2614230103	GOVERNOR LEVER
2274220103	GOVERNOR SHAFT
26142502A3	GOVERNOR SPRING
26142701B3	GOVERNOR ROD
2614280103	ROD SPRING
26145101B3	CHOKE ROD
26146001A1	BRACKET(SPEED C.)CP
26143301A1	SPEED CONT. LEVER CP
26143801A1	CHOKE LEVER CP

2614520103	RETURN SPRING
2614530103	SPACER
2614310101	LINK PIVOT
2614310103	LINK PIVOT
2614390103	CLAMP
2267270611	STOP SWITCH
26146101A3	SIDE GUARD
31306000	CLIP
11406250	BOLT AND WASHER AY
X186060020	NUT
X110060020	FLANGE BOLT
23806000	FLANGE NUT
2374500423	SPRING (ADJUST)
43105200	SCREW,PANHEAD
11705300	BOLT AND WASHER AY
X110060020	FLANGE BOLT
43704120	SCREW AND WASHER AY
261E00370G	COOLING,STARTING GRP
2615121331	BLOWER HOUSING CP
2615121411	BLOWER HOUSING CP2
901080610	BLACK
2615121112	BLOWER HOUSING UN
2639200103	LABEL(WARNING)
26195207A3	LABEL(EMISSION CONT)
26191704A3	LABEL(TRADE MARK)
2615040200	RECOIL STARTER AY
901080610	BLACK
2275260103	CYLINDER BAFFLE
X110060020	FLANGE BOLT
X110060030	FLANGE BOLT
X110060010	FLANGE BOLT
X110060010	FLANGE BOLT
261F00190G	FUEL LUBRICANT GROUP
2266140210	FUEL TANK AY
2266140113	FUEL TANK
430440132	FUEL TANK CAP CP
435440031	OUTER CAP
434180012	INNER CAP
841260020	SPONGE
210260050	GASKET(TANK CAP)
232420012	PARTITION PLATE
642004402	FUEL STRAINER AY
641420040	FUEL FILTER
213310020	GASKET(FILTER)
2616200121	FUEL TANK BRACKET CP
2616200122	FUEL TANK BRACKET UN
2616580101	BRACKET (FUEL TANK)

26162601C1	FUEL PIPE CP
X851061190	RUBBER PIPE
X561100060	HOSE CLAMP
2616230120	CARBURETOR AY
2616370103	OIL FILLER
62610190	O RING
26165301A1	BRACKET(OIL FILL.)CP
2616520103	CLAMP (OIL FILLER)
213180010	GASKET
2616360111	OIL GAUGE CP
26165501A3	OIL FILTER BRACKET
2616560113	GASKET (O.F.BRACKET)
2486580100	OIL FILTER AY
2616570101	OIL DRAIN PLUG
211140020	GASKET
566000250	CLAMP
2266501101	TANK BAND 1
2266501103	TANK BAND 1
2266501201	TANK BAND 2
2266501203	TANK BAND 2
2266510503	BAND 1
2266510603	BAND 2
X110060170	FLANGE BOLT
X110060020	FLANGE BOLT
X110060020	FLANGE BOLT
X110060020	FLANGE BOLT
X110060020	FLANGE BOLT
261G00070G	ELECTRIC DEVICE GROU
2617020130	MAGNETO AY
2617920111	FLYWHEEL CP
2617940121	IGNITION COIL CP
X650141030	SPARK PLUG
X655100010	SPARK PLUG CAP
X659100010	PLUG TERMINAL
26173102A1	WIRE 2 CP
566000250	CLAMP
2147900601	CLAMP CP
2147900609	INSULATOR
2147900501	CLAMP
2147900503	CLAMP
11406300	BOLT AND WASHER AY
XXXH90090G	GROUP
732999989	LABEL(N.P.C)
261J00030G	ACCESSORIES LABEL GR
2ZZ9020087	EH18V