

PARTS MANUAL

MODEL
EX13
Engine

EX130D50175

09/15



SUBARU

Industrial Power Products

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047 - Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com


© 2012 Subaru Industrial Power Products

Group Index

Group Name	Page
100 Crankcase.....	4
200 Crankshaft.....	6
300 Intake & Exhaust.....	8
315 Intake & Exhaust.....	12
400 Governor.....	14
500 Cooling & Starting.....	16
520 Cooling & Starting.....	18
600 Fuel & Lubricant.....	20
640 Carburetor.....	22
700 Electric Device.....	24
770 Electric Device.....	26
900 Accessory.....	28
 Part Number Index.....	 30
Part Description Index.....	31

100 Crankcase

FIG. 100



EX13


276010001W00

100 Crankcase

Ref	Part Number.	Description	Qty	Remark
10	276-10102-41	CRANK CASE CP	1.00	Remarks: W/OIL SENSOR.
20	237-14202-03	VALVE GUIDE	2.00	Remarks: 5.5DX9.5DX27L.
26	277-16010-01	STEM SEAL	1.00	Remarks: 5.5DX9.5DX15DX7.8B.
30	044-02502-00	OIL SEAL	1.00	Remarks: 25DX38DX7B.
40	060-02800-21	BALL BEARING	1.00	Remarks: 28DX58DX16B.
50	277-15011-03	PIPE KNOCK	2.00	Remarks: 10.3DX8.5DX14L.
60	010-50802-50	STUD	2.00	Remarks: M8X1.25X25L.
70	010-50603-51	STUD	2.00	Remarks: M6X1.0X98L.
75	044-00600-20	OIL SEAL	1.00	Remarks: 6DX10DX2.5B.
80	040-11400-30	PLUG	1.00	Remarks: M14X1.5X20DX12L.
90	021-11400-20	GASKET	1.00	Remarks: 14.1DX19DX2.3T.
210	277-11002-31	MAIN BEARING COVER C	1.00	Remarks: FLANGE 4-5/16-24UNF.
220	044-02502-10	OIL SEAL	1.00	Remarks: 25DX41.25DX6B.
230	060-02501-40	BALL BEARING	1.00	Remarks: 25DX52DX15B.
250	277-45004-K1	GOVERNOR GEAR CP	1.00	Remarks: 53DX29.1T N=33.
260	277-41902-03	GOVERNOR SLEEVE	1.00	Remarks: 6DX7.6DX16DX26L.
270	277-63601-13	OIL GAUGE	2.00	Remarks: M18X1.5 L=70+18.
280	021-31600-20	GASKET	1.00	Remarks: 16DX23DX1.2T RUBBER.
300	001-04083-50	FLANGE BOLT	6.00	
610	276-13001-11	CYLINDER HEAD CP	1.00	
620	276-15001-33	GASKET (HEAD)	1.00	Remarks: T=0.2.
630	011-00802-40	FLANGE BOLT	4.00	Remarks: M8X1.25X16DX68L.
631	011-00803-10	FLANGE BOLT	1.00	Remarks: M8X1.25X16DX33L.
680	277-15503-02	ROCKER COVER CP	1.00	
690	277-16001-13	GASKET(ROCKER COVER)	1.00	Remarks: T=0.5.
700	277-15011-03	PIPE KNOCK	2.00	Remarks: 10.3DX8.5DX14L.
710	011-00600-20	FLANGE BOLT	4.00	Remarks: M6X1.0X14DX12L.
960	276-99001-27	GASKET SET	1.00	

200 Crankshaft

FIG. 200




EX13

276020000W01

200 Crankshaft

Ref	Part Number.	Description	Qty	Remark
10	276-20901-41	CRANKSHAFT CP	1.00	Remarks: L=260 DU 19.05DX58.5.
50	018-01400-20	FLANGE NUT	1.00	Remarks: M14X1.5X28DX12H.
70	032-30300-10	WOODRUFF KEY	1.00	Remarks: 3BX6HX16D.
80	206-26001-13	KEY	1.00	Remarks: 4.7BX4.7HX35L.
310	276-22501-10	CONNECTING ROD AY	1.00	Remarks: 80.2CDX25B 30D-13D.
311	276-22502-00	CONNECTING ROD AY	1.00	Remarks: 0.25 U.S..
320	277-23001-03	CONNECTING ROD BOLT	2.00	Remarks: M6X1.0X13DX33L.
350	276-23301-13	PISTON PIN	1.00	Remarks: 13DX9DX44L.
360	276-23401-H3	PISTON	1.00	Remarks: STD (58DX35H).
370	276-23531-07	PISTON RING SET	1.00	Remarks: STD OIL EXPANDER.
380	215-25004-03	CLIP	2.00	Remarks: 14.1DX1.2D.

300 Intake & Exhaust



300 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
10	277-31601-41	CAM SHAFT CP	1.00	Remarks: 85DX2.9B N=40.
25	277-35101-03	PIN(CAM SHAFT)	1.00	Remarks: 9DX78.5L.
27	024-00600-30	O RING	1.00	Remarks: 5.8DX9.6D.
34	277-38601-03	PIN(SPRING)	1.00	Remarks: 4DX8DX9L.
35	277-36401-03	RELEASE LEVER	1.00	
37	277-36501-03	CLIP	1.00	Remarks: 13.8DX20.3DX0.4T.
38	277-38703-03	RETURN SPRING	1.00	Remarks: 5.1DX0.6DX4.4L N=7.
60	279-33601-03	VALVE SPRING	2.00	Remarks: 19.2DX2.3DX27.4L.
70	269-33701-03	SPRING RETAINER	2.00	
80	276-33401-H3	INTAKE VALVE	1.00	Remarks: 22DX5.5DX68L.
90	276-33501-H3	EXHAUST VALVE	1.00	Remarks: 18.5DX5.5DX68L.
95	132-10KA0-31	COLLET-VALVE	4.00	
150	276-35602-H1	TIMING CHAIN CP	1.00	Remarks: 86 LINK.
160	277-36911-03	TENTIONER	1.00	
163	277-37101-03	SPRING(TENTIONER)	1.00	Remarks: 10DX1.8DX14L N=4.5.
166	277-36902-03	PIN(TENTIONER)	1.00	Remarks: 6DX13DX34L.
170	277-36913-13	CHAIN GUIDE	1.00	
200	277-35004-01	PIN(ROCKER) CP	1.00	Remarks: 6DX46L.
202	003-13050-00	CLIP	1.00	
220	277-36201-00	ROCKER ARM(IN) AY	1.00	
225	277-36202-00	ROCKER ARM(EX) AY	1.00	
230	014-90500-20	ADJUST SCREW	1.00	Remarks: M5X0.5X23L.
231	014-90500-20	ADJUST SCREW	1.00	Remarks: M5X0.5X23L.
240	017-00500-30	NUT	1.00	Remarks: M5X0.5X4.1H.
241	017-00500-30	NUT	1.00	Remarks: M5X0.5X4.1H.
290	011-00600-10	FLANGE BOLT	1.00	Remarks: M6X1.0X14DX12L.
310	276-30112-J1	MUFFLER CP	1.00	
315	277-37601-01	SPARK ARRESTER CP	1.00	
317	015-00400-60	TAPPING SCREW	1.00	Remarks: M4X6L.
320	276-34201-01	MUFFLER COVER CP	1.00	
340	277-35201-13	GASKET(MUFFLER)	1.00	Remarks: T=0.2 26D 9DX58P.
350	002-38080-00	FLANGE NUT	2.00	
360	015-20600-90	TAPPING BOLT	2.00	Remarks: M6X13DX10L.
361	011-00600-10	FLANGE BOLT	1.00	Remarks: M6X1.0X14DX8L.
365	011-00803-20	FLANGE BOLT	1.00	Remarks: M8X1.25X16DX12L.
385	277-37203-H1	SCREEN CP	1.00	
387	015-00400-60	TAPPING SCREW	2.00	Remarks: M4X6L.
540	277-32902-J1	INSULATOR CP	1.00	
550	277-35903-J3	GASKET2(INSULATOR)	1.00	Remarks: T=0.5.

300 Intake & Exhaust


Ref	Part Number.	Description	Qty	Remark
560	277-35902-J3	GASKET1(INSULATOR)	1.00	Remarks: T=0.5.
570	002-38060-00	FLANGE NUT	2.00	
580	001-04062-00	FLANGE BOLT	1.00	Remarks: M6X1.0X13DX20L.

This Page Intentionally Left Blank


315 Intake & Exhaust

FIG. 315


URETHANE FOAM



DUAL ELEMENT



PRE CLEANER




EX13

276031500W02

315 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
510	277-32615-20	AIR CLEANER AY	1.00	
510-200	277-32630-18	BASE CP	1.00	
510-210	277-32610-08	PACKING	1.00	
510-220	277-32604-08	PACKING	1.00	
510-250	277-32640-08	COVER CP	1.00	
510-260	277-32609-08	LABEL	1.00	
510-270	277-32741-18	WING NUT	1.00	
510-272	277-32607-08	WING NUT	1.00	
510-520	277-32611-07	ELEMENT SET	1.00	Remarks: DUAL.


400 Governor



400 Governor

Ref	Part Number.	Description	Qty	Remark
10	277-42301-23	GOVERNOR LEVER	1.00	
20	277-42201-33	GOVERNOR SHAFT	1.00	
30	279-42701-11	GOVERNOR ROD CP	1.00	
40	277-42801-23	ROD SPRING	1.00	Remarks: 7DX0.5DX182L N=16.
50	003-13050-00	CLIP	1.00	
60	001-14062-50	BOLT AND WASHER AY	1.00	Remarks: M6X1.0X25L W/TWO W.
70	018-60600-20	NUT	1.00	Remarks: M6X1.0X4.9H SQUARE.
80	279-42505-43	GOVERNOR SPRING	1.00	Remarks: 7.5DX0.7DX115L N=16.
310	277-43303-03	SPEED CONTROL LEVER	1.00	
340	277-43502-03	STOP PLATE	1.00	
350	277-44501-03	WASHER	1.00	
355	021-70600-70	FRICTION WASHER	1.00	Remarks: 6.5DX24DX0.8T NYLON.
360	004-31062-50	SCREW	1.00	
365	237-45004-23	SPRING (ADJUST)	1.00	Remarks: 6.9DX0.9DX20L N=7.
435	277-46002-02	SPEED CONT.BRKT UN	1.00	
450	002-35060-00	SELF LOCK NUT	1.00	
485	011-00600-20	FLANGE BOLT	2.00	Remarks: M6X1.0X14DX12L.

500 Cooling & Starting




500 Cooling & Starting


Ref	Part Number.	Description	Qty	Remark
10	276-51202-01	BLOWER HOUSING CP	1.00	Remarks: BLACK.
20	276-91702-13	LABEL(WACKER)	1.00	
40	011-00600-30	FLANGE BOLT	4.00	Remarks: M6X1.0X14DX14L.
60	20A-52711-01	BAFFLE 1(CASE) CP	1.00	
61	277-52702-03	BAFFLE 2(HEAD)	1.00	
80	001-04061-40	FLANGE BOLT	1.00	
81	011-00600-20	FLANGE BOLT	1.00	Remarks: M6X1.0X14DX12L.
220	013-00602-81	FLANGE BOLT	4.00	Remarks: M6X1.0X14DX8L.

520 Cooling & Starting

FIG. 520



RESIN




EX13

276052000W01

520 Cooling & Starting

Ref	Part Number.	Description	Qty	Remark
210	276-50301-20	RECOIL STARTER AY	1.00	Remarks: D 160PD.
210-1	270-50115-08	SPIRAL SPRING	1.00	
210-11	268-50145-18	STARTER PULLEY	1.00	
210-2	269-50120-08	REEL	1.00	
210-3	282-50111-18	STARTER ROPE	1.00	
210-4	261-50100-08	STARTER KNOB	1.00	
210-5	270-50125-08	RATCHET	2.00	
210-6	227-50131-08	FRICTION SPRING	1.00	
210-7	227-50135-08	RETURN SPRING	2.00	
210-8	270-50261-08	RATCHET GUIDE	1.00	
210-49	227-50152-08	SET SCREW	1.00	

600 Fuel & Lubricant




600 Fuel & Lubricant

Ref	Part Number.	Description	Qty	Remark
10	276-60102-01	FUEL TANK CP	1.00	Remarks: 2.7L BLACK.
30	X43-04401-43	FUEL TANK CAP CP	1.00	Remarks: 43DX68DX14H BLACK.
40	X64-13600-10	FUEL FILTER	1.00	
48	050-51200-20	UNION	1.00	Remarks: M12X4DX78L W/FILTER.
60	002-38060-00	FLANGE NUT	2.00	
63	011-00601-30	FLANGE BOLT	1.00	Remarks: M6X1.0X14DX25L.
70	276-62603-01	FUEL PIPE CP	1.00	
90	X56-11100-20	HOSE CLAMP	2.00	End Code: 6971. Remarks: 10.5DX8BX0.7T.
90	056-11100-50	HOSE CLAMP	2.00	Start Code: 6972.
224	277-43801-01	CHOKE LEVER CP	1.00	

640 Carburetor

FIG. 640



EX13


276064000W02

640 Carburetor

Ref	Part Number.	Description	Qty	Remark
210	276-62302-40	CARBURETOR AY	1.00	
210-1	106-62538-08	THROTTLE VALVE	1.00	Remarks: #200.
210-2	209-62351-08	SCREW	1.00	
210-3	277-62525-08	CHOKE VALVE	1.00	
210-5	246-62420-08	PILOT JET	1.00	Remarks: #40.
210-8	277-62520-08	CHOKE LEVER	1.00	
210-11	276-62531-18	THROTTLE SHAFT-A	1.00	
210-12	227-62451-08	BOLT	1.00	
210-14	277-62500-08	NEEDLE	1.00	
210-15	277-62515-08	PIN	1.00	
210-16	277-62506-08	FLOAT BODY AY	1.00	
210-17	214-62450-08	PACKING	1.00	
210-18	214-62540-08	CHAMBER PACKING	1.00	
210-19	226-62506-08	FLOAT	1.00	
210-20	276-62440-08	MAIN NOZZLE	1.00	
210-22	252-62405-08	MAIN JET	1.00	Remarks: #68.8.
210-24	226-62701-18	CLIP	1.00	
210-28	277-62360-08	BOLT	1.00	
210-40	106-62556-08	SCREW	1.00	
210-41	283-62357-08	SPRING	1.00	
210-44	207-62410-08	AIR JET	1.00	
210-45	106-62410-08	AIR JET(PILOT)	1.00	
210-62	236-62680-08	SEAL	1.00	
210-79	236-62541-08	PACKING	1.00	
210-102	246-62390-08	SEAL	1.00	
210-144	277-62553-08	NUT	1.00	
210-300	279-62103-20	COCK BODY-A	1.00	
210-302	277-62110-18	PACKING	1.00	
210-303	277-62100-18	CUP	1.00	
210-325	277-62552-08	O-RING	1.00	
210-327	165-62377-08	SCREW	2.00	

700 Electric Device

FIG. 700




EX13

276070000W01

700 Electric Device

Ref	Part Number.	Description	Qty	Remark
10	276-79230-21	FLYWHEEL CP	1.00	
11	277-79431-01	IGNITION COIL CP	1.00	Remarks: MARK BM3790.
30	001-04062-00	BOLT AND WASHER AY	2.00	
50	277-73102-H1	WIRE 2 CP	1.00	Remarks: L=360 BLACK.
60	066-00004-71	SWITCH AY	1.00	
70	015-00400-90	TAPPING SCREW	2.00	Remarks: M4X12L.
100	065-01401-50	SPARK PLUG	1.00	Remarks: NGK BR6HS.
110	065-50002-70	SPARK PLUG CAP	1.00	

770 Electric Device




EX13

276077000W02

770 Electric Device

Ref	Part Number.	Description	Qty	Remark
700	277-76301-21	OIL SENSOR CP	1.00	
705	KU3-11043-11	FLOAT C/U CP3	1.00	
740	001-14061-60	BOLT AND WASHER AY	2.00	
741	015-20500-10	TAPPING SCREW	1.00	Remarks: M5X10DX10L.

900 Accessory



900 Accessory

Ref	Part Number.	Description	Qty	Remark
10	277-90301-H0	ACCESSORY TOOL KIT	1.00	

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page
001-04061-40	17	246-62420-08	23	277-41902-03	5
001-04062-00	10, 25	252-62405-08	23	277-42201-33	15
001-04083-50	5	261-50100-08	19	277-42301-23	15
001-14061-60	27	268-50145-18	19	277-42801-23	15
001-14062-50	15	269-33701-03	9	277-43303-03	15
002-35060-00	15	269-50120-08	19	277-43502-03	15
002-38060-00	10, 21	270-50115-08	19	277-43801-01	21
002-38080-00	9	270-50125-08	19	277-44501-03	15
003-13050-00	9, 15	270-50261-08	19	277-45004-K1	5
004-31062-50	15	276-10102-41	5	277-46002-02	15
010-50603-51	5	276-13001-11	5	277-52702-03	17
010-50802-50	5	276-15001-33	5	277-62100-18	23
011-00600-10	9	276-20901-41	7	277-62110-18	23
011-00600-20	5, 15, 17	276-22501-10	7	277-62360-08	23
011-00600-30	17	276-22502-00	7	277-62500-08	23
011-00601-30	21	276-23301-13	7	277-62506-08	23
011-00802-40	5	276-23401-H3	7	277-62515-08	23
011-00803-10	5	276-23531-07	7	277-62520-08	23
011-00803-20	9	276-30112-J1	9	277-62525-08	23
013-00602-81	17	276-33401-H3	9	277-62552-08	23
014-90500-20	9	276-33501-H3	9	277-62553-08	23
015-00400-60	9	276-34201-01	9	277-63601-13	5
015-00400-90	25	276-35602-H1	9	277-73102-H1	25
015-20500-10	27	276-50301-20	19	277-76301-21	27
015-20600-90	9	276-51202-01	17	277-79431-01	25
017-00500-30	9	276-60102-01	21	277-90301-H0	29
018-01400-20	7	276-62302-40	23	279-33601-03	9
018-60600-20	15	276-62440-08	23	279-42505-43	15
021-11400-20	5	276-62531-18	23	279-42701-11	15
021-31600-20	5	276-62603-01	21	279-62103-20	23
021-70600-70	15	276-79230-21	25	282-50111-18	19
024-00600-30	9	276-91702-13	17	283-62357-08	23
032-30300-10	7	276-99001-27	5	KU3-11043-11	27
040-11400-30	5	277-11002-31	5	X43-04401-43	21
044-00600-20	5	277-15011-03	5	X56-11100-20	21
044-02502-00	5	277-15503-02	5	X64-13600-10	21
044-02502-10	5	277-16001-13	5		
050-51200-20	21	277-16010-01	5		
056-11100-50	21	277-23001-03	7		
060-02501-40	5	277-31601-41	9		
060-02800-21	5	277-32604-08	13		
065-01401-50	25	277-32607-08	13		
065-50002-70	25	277-32609-08	13		
066-00004-71	25	277-32610-08	13		
106-62410-08	23	277-32611-07	13		
106-62538-08	23	277-32615-20	13		
106-62556-08	23	277-32630-18	13		
132-10KA0-31	9	277-32640-08	13		
165-62377-08	23	277-32741-18	13		
206-26001-13	7	277-32902-J1	9		
207-62410-08	23	277-35004-01	9		
209-62351-08	23	277-35101-03	9		
20A-52711-01	17	277-35201-13	9		
214-62450-08	23	277-35902-J3	10		
214-62540-08	23	277-35903-J3	9		
215-25004-03	7	277-36201-00	9		
226-62506-08	23	277-36202-00	9		
226-62701-18	23	277-36401-03	9		
227-50131-08	19	277-36501-03	9		
227-50135-08	19	277-36902-03	9		
227-50152-08	19	277-36911-03	9		
227-62451-08	23	277-36913-13	9		
236-62541-08	23	277-37101-03	9		
236-62680-08	23	277-37203-H1	9		
237-14202-03	5	277-37601-01	9		
237-45004-23	15	277-38601-03	9		
246-62390-08	23	277-38703-03	9		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

A

ACCESSORY TOOL KIT.....29
ADJUST SCREW.....9
AIR CLEANER AY.....13
AIR JET.....23
AIR JET(PILOT).....23

B

BAFFLE 1(CASE) CP.....17
BAFFLE 2(HEAD).....17
BALL BEARING.....5
BASE CP.....13
BLOWER HOUSING CP.....17
BOLT.....23
BOLT AND WASHER AY.....15, 25, 27

C

CAM SHAFT CP.....9
CARBURETOR AY.....23
CHAIN GUIDE.....9
CHAMBER PACKING.....23
CHOKE LEVER.....23
CHOKE LEVER CP.....21
CHOKE VALVE.....23
CLIP.....7, 9, 15, 23
COCK BODY-A.....23
COLLET-VALVE.....9
CONNECTING ROD AY.....7
CONNECTING ROD BOLT.....7
COVER CP.....13
CRANK CASE CP.....5
CRANKSHAFT CP.....7
CUP.....23
CYLINDER HEAD CP.....5

E

ELEMENT SET.....13
EXHAUST VALVE.....9

F

FLANGE BOLT.....5, 9-10, 15, 17, 21
FLANGE NUT.....7, 9-10, 21
FLOAT.....23
FLOAT BODY AY.....23
FLOAT C/U CP3.....27
FLYWHEEL CP.....25
FRICTION SPRING.....19
FRICTION WASHER.....15
FUEL FILTER.....21
FUEL PIPE CP.....21
FUEL TANK CAP CP.....21
FUEL TANK CP.....21

G

GASKET.....5
GASKET (HEAD).....5

GASKET SET.....5
GASKET(MUFFLER).....9
GASKET(ROCKER COVER).....5
GASKET1(INSULATOR).....10
GASKET2(INSULATOR).....9
GOVERNOR GEAR CP.....5
GOVERNOR LEVER.....15
GOVERNOR ROD CP.....15
GOVERNOR SHAFT.....15
GOVERNOR SLEEVE.....5
GOVERNOR SPRING.....15

H

HOSE CLAMP.....21

I

IGNITION COIL CP.....25
INSULATOR CP.....9
INTAKE VALVE.....9

K

KEY.....7

L

LABEL.....13
LABEL(WACKER).....17

M

MAIN BEARING COVER C.....5
MAIN JET.....23
MAIN NOZZLE.....23
MUFFLER COVER CP.....9
MUFFLER CP.....9

N

NEEDLE.....23
NUT.....9, 15, 23

O

O RING.....9
O-RING.....23
OIL GAUGE.....5
OIL SEAL.....5
OIL SENSOR CP.....27

P

PACKING.....13, 23
PILOT JET.....23
PIN.....23
PIN(CAM SHAFT).....9
PIN(ROCKER) CP.....9
PIN(SPRING).....9
PIN(TENTIONER).....9
PIPE KNOCK.....5
PISTON.....7
PISTON PIN.....7

PISTON RING SET.....7
PLUG.....5

R

RATCHET.....19
RATCHET GUIDE.....19
RECOIL STARTER AY.....19
REEL.....19
RELEASE LEVER.....9
RETURN SPRING.....9, 19
ROCKER ARM(EX) AY.....9
ROCKER ARM(IN) AY.....9
ROCKER COVER CP.....5
ROD SPRING.....15

S

SCREEN CP.....9
SCREW.....15, 23
SEAL.....23
SELF LOCK NUT.....15
SET SCREW.....19
SPARK ARRESTER CP.....9
SPARK PLUG.....25
SPARK PLUG CAP.....25
SPEED CONT.BRKT UN.....15
SPEED CONTROL LEVER.....15
SPIRAL SPRING.....19
SPRING.....23
SPRING (ADJUST).....15
SPRING RETAINER.....9
SPRING(TENTIONER).....9
STARTER KNOB.....19
STARTER PULLEY.....19
STARTER ROPE.....19
STEM SEAL.....5
STOP PLATE.....15
STUD.....5
SWITCH AY.....25

T

TAPPING BOLT.....9
TAPPING SCREW.....9, 25, 27
TENTIONER.....9
THROTTLE SHAFT-A.....23
THROTTLE VALVE.....23
TIMING CHAIN CP.....9

U

UNION.....21

V

VALVE GUIDE.....5
VALVE SPRING.....9

W

WASHER.....15
WING NUT.....13

Part Description Index (continued)

WIRE 2 CP.....25
WOODRUFF KEY.....7

This Page Intentionally Left Blank

PRINTED IN THE USA

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047

Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com