

PARTS MANUAL

MODEL
EH03

EH035V2B401

12/15



SUBARU

Industrial Power Products

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047 - Phone 847-540-7300 - Fax 847-438-5012



e-mail: sales@subarupower.com - www.subarupower.com

© 2015 Subaru Industrial Power Products

Group Index

Group Name	Page
Accessories.....	4
Carburetor.....	6
Engine.....	8
Intake.....	12
Part Number Index.....	14
Part Description Index.....	15

Accessories




EH 0000 004

Accessories

Ref	Part Number.	Description	Qty	Remark
1	196134-6	TOOL SET	1	
2	-----	MANUAL	1	

Carburetor




EH 0000 006

Carburetor

Ref	Part Number.	Description	Qty	Remark
1	593-60110-00	CARBURETOR	2	
3	325922-6	SWIVEL	1	
4	413140-9	WASHER	1	
5	257964-1	STOP RING E-3	1	
6	234183-6	SPRING	1	
7	213538-8	O RING - 2	1	
8	325924-2	JET	1	
9	442155-9	GASKET, PUMP	1	
10	168575-6	DIAPHRAGM, PUMP	1	
11	593-60150-20	PUMP BODY ASSY	1	
12	WJ0-00963-64	SCREEN	1	
13	442154-1	GASKET, METERING DIAPHRAGM	1	
14	168574-8	DIAPHRAGM, METERING	1	
15	140438-8	AIR PURGE BODY	1	
16	424314-7	BULB, PURGE	1	
17	346270-0	COVER, PURGE BULB	1	
18	266582-4	SCREW - 3X24	2	

Engine



EH 0000 005

Engine

Ref	Part Number.	Description	Qty	Remark
1	593-10380-02	CYLINDER BLOCK SET	1	Includes ITEMS 2-5
2	424200-2	SPACER	2	
3	424201-0	VALVE, CHECK	2	
4	266812-3	BOLT - M5X16	1	
5	266573-5	BOLT - M5X33	1	
6	346083-9	LEAD VALVE	1	
7	593-15013-00	RETAINER PLATE	1	
8	266810-7	BOLT - M4X10	1	
9	593-65006-00	TUBE, OIL	1	
10	325666-8	WEIGHT	1	
11	266811-5	BOLT - M5X14	4	
12	593-65008-00	CASE, OIL	4	
13	004-31060-80	SCREW -M6×8	4	
14	346305-7	GASKET	3	
15	593-65004-00	GASKET	1	
16	424100-6	GASKET	4	
17	450565-6	GAUGE, OIL	1	
18	168401-9	PLUG, SPARK -CMR6A	1	
19	593-15016-00	GASKET, ROCKER COVER	1	
20	593-15014-00	COVER, ROCKER	1	
21	266811-5	BOLT - M5X14	1	
22	318614-4	HOUSING, BLOWER	1	
23	266813-1	BOLT - M5X16	1	
24	266800-0	BOLT - M8X24	4	
25	168563-3	SHOE, CLUTCH	1	
26	267424-5	WASHER - 8	1	
27	531-80040-10	SPRING, CLUTCH	1	
28	265577-4	BOLT - M6X16	1	
29	593-70120-21	FLYWHEEL	1	
30	593-70120-10	COIL, IGNITION	1	
31	011-90499-70	BOLT - M4X20	1	
32	444021-6	TUBE	2	
33	324891-8	TERMINAL, SPARK PLUG CAP	1	
34	424105-6	CAP, PLUG	1	
35	638665-4	LEAD UNIT	2	
36	638784-6	WIRE	1	
37	266811-5	BOLT - M5X14	1	
38	593-15015-00	COVER, CAM GEAR	1	
39	593-15017-00	GASKET, COVER CAM GEAR	2	


Engine

Ref	Part Number.	Description	Qty	Remark
40	268238-5	PIN - 5X21.8	2	
41	593-30070-00	CAM GEAR ASSY	1	
42	313169-4	LIFTER	2	
43	268239-3	PIN - 4×15.8	2	
44	256866-8	ROD - 2.5	1	
45	125554-7	ROCKER ARM ASSY	1	
46	325912-9	RETAINER, SPRING	1	
47	234181-0	SPRING - 13	1	
48	256200-2	PIN - 5×31.8	2	
49	325913-7	VALVE, EXHAUST	1	
50	325914-5	VALVE, INTAKE	1	
51	266808-4	SCREW - M5X12	1	
52	593-55022-00	COVER, CYLINDER	1	
53	266440-4	BOLT - M5X40	1	
54	593-30140-01	MUFFLER	1	
55	345916-5	GASKET, EXHAUST	1	
56	195141-6	PISTON RING SET	1	
57	233983-1	CLIP	1	
58	318613-6	PISTON	1	
59	257796-6	PIN, PISTON	4	
60	212085-6	NEEDLE CAGE1014	1	
61	254040-2	KEY - 3	1	
62	213537-0	SEAL, OIL - 12	1	
63	267425-3	WASHER - 26	3	
64	142170-0	CRANKSHAFT CP	1	
65	213682-1	SEAL, OIL - 12	1	
66	266809-2	SCREW - M5X14	1	
67	593-50040-01	COVER STARTER ASSY	1	Includes ITEMS 68-76
68	168483-1	PULLEY	1	
69	266585-8	SCREW - 5X12 (TAPPING)	1	
70	325923-4	ARM, SWING	1	
71	451938-6	COLLAR	1	
72	451937-8	REEL	1	
73	232258-5	SPRING	1	
74	444036-3	ROPE, STARTER	2	
75	424317-1	KNOB, STARTER	1	
76	424360-0	STOPPER, ROPE	1	
77	593-95012-01	LABEL, MODEL	1	
78	163447-0	FILTER, FUEL	1	

Engine

Ref	Part Number.	Description	Qty	Remark
79	345920-4	CLAMP, HOSE	1	
80	168862-3	TUBE	1	
81	424102-2	PLATE	1	
82	424103-0	PLATE	2	
83	455360-9	TANK, FUEL	2	
84	424104-8	DAMPER	1	
85	140435-4	CAP, FUEL TANK	2	

Intake



EH 0000 007

Intake

Ref	Part Number.	Description	Qty	Remark
19	325915-3	PIPE, INTAKE	4	
20	413166-1	GASKET	1	
21	213063-9	O-RING - 10	1	
22	451874-6	INSULATOR	1	
23	014-90699-40	SCREW	1	
24	265A04-7	BOLT - M5×16	1	
25	442177-9	GASKET	1	
26	345918-1	CLAMP, HOSE	1	
27	422055-9	PIPE, BREATHER - 8.5X4.5	2	
28	422070-3	PIPE - 7X3X60	1	
29	125468-0	CLEANER PLATE ASSY	1	Includes ITEMS 30-38
30	451925-5	LEVER, CHOKE	1	
31	213540-1	O RING - 15	1	
32	140814-6	AIR CLEANER PLATE CP	1	
33	424316-3	VALVE, CHECK	1	
34	213539-6	O RING - 14	1	
35	451924-7	PLATE, CHECK VALVE	1	
36	424315-5	VALVE, CHECK	1	
37	168577-2	GASKET	1	
38	168576-4	PLATE	1	
39	450560-6	PLATE, CHOKE	1	
40	423376-2	GASKET	1	
41	345919-9	PLATE	1	
42	265188-5	SCREW - M5X68	1	
43	443140-5	ELEMENT, AIR CLEANER	1	
44	443141-3	ELEMENT, AIR CLEANER	1	
45	450561-4	COVER, AIR CLEANER	1	
46	266809-2	SCREW - M5X14	1	

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page
-----	5	345916-5	10
004-31060-80	9	345918-1	13
011-90499-70	9	345919-9	13
014-90699-40	13	345920-4	11
125468-0	13	346083-9	9
125554-7	10	346270-0	7
140435-4	11	346305-7	9
140438-8	7	413140-9	7
140814-6	13	413166-1	13
142170-0	10	422055-9	13
163447-0	10	422070-3	13
168401-9	9	423376-2	13
168483-1	10	424100-6	9
168563-3	9	424102-2	11
168574-8	7	424103-0	11
168575-6	7	424104-8	11
168576-4	13	424105-6	9
168577-2	13	424200-2	9
168862-3	11	424201-0	9
195141-6	10	424314-7	7
196134-6	5	424315-5	13
212085-6	10	424316-3	13
213063-9	13	424317-1	10
213537-0	10	424360-0	10
213538-8	7	442154-1	7
213539-6	13	442155-9	7
213540-1	13	442177-9	13
213682-1	10	443140-5	13
232258-5	10	443141-3	13
233983-1	10	444021-6	9
234181-0	10	444036-3	10
234183-6	7	450560-6	13
254040-2	10	450561-4	13
256200-2	10	450565-6	9
256866-8	10	451874-6	13
257796-6	10	451924-7	13
257964-1	7	451925-5	13
265188-5	13	451937-8	10
265577-4	9	451938-6	10
265A04-7	13	455360-9	11
266440-4	10	531-80040-10	9
266573-5	9	593-10380-02	9
266582-4	7	593-15013-00	9
266585-8	10	593-15014-00	9
266800-0	9	593-15015-00	9
266808-4	10	593-15016-00	9
266809-2	10, 13	593-15017-00	9
266810-7	9	593-30070-00	10
266811-5	9	593-30140-01	10
266812-3	9	593-50040-01	10
266813-1	9	593-55022-00	10
267424-5	9	593-60110-00	7
267425-3	10	593-60150-20	7
268238-5	10	593-65004-00	9
268239-3	10	593-65006-00	9
313169-4	10	593-65008-00	9
318613-6	10	593-70120-10	9
318614-4	9	593-70120-21	9
324891-8	9	593-95012-01	10
325666-8	9	638665-4	9
325912-9	10	638784-6	9
325913-7	10	WJ0-00963-64	7
325914-5	10		
325915-3	13		
325922-6	7		
325923-4	10		
325924-2	7		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

A

AIR CLEANER PLATE CP.....13
AIR PURGE BODY.....7
ARM, SWING.....10

B

BOLT - M4X10.....9
BOLT - M4X20.....9
BOLT - M5×16.....13
BOLT - M5X14.....9
BOLT - M5X16.....9
BOLT - M5X33.....9
BOLT - M5X40.....10
BOLT - M6X16.....9
BOLT - M8X24.....9
BULB, PURGE.....7

C

CAM GEAR ASSY.....10
CAP, FUEL TANK.....11
CAP, PLUG.....9
CARBURETOR.....7
CASE, OIL.....9
CLAMP, HOSE.....11, 13
CLEANER PLATE ASSY.....13
CLIP.....10
COIL, IGNITION.....9
COLLAR.....10
COVER STARTER ASSY.....10
COVER, AIR CLEANER.....13
COVER, CAM GEAR.....9
COVER, CYLINDER.....10
COVER, PURGE BULB.....7
COVER, ROCKER.....9
CRANKSHAFT CP.....10
CYLINDER BLOCK SET.....9

D

DAMPER.....11
DIAPHRAGM, METERING.....7
DIAPHRAGM, PUMP.....7

E

ELEMENT, AIR CLEANER.....13

F

FILTER, FUEL.....10
FLYWHEEL.....9

G

GASKET.....9, 13
GASKET, COVER CAM GEAR.....9
GASKET, EXHAUST.....10
GASKET, METERING DIAPHRAGM.....7
GASKET, PUMP.....7

GASKET, ROCKER COVER.....9
GAUGE, OIL.....9

H

HOUSING, BLOWER.....9

I

INSULATOR.....13

J

JET.....7

K

KEY - 3.....10
KNOB, STARTER.....10

L

LABEL, MODEL.....10
LEAD UNIT.....9
LEAD VALVE.....9
LEVER, CHOKE.....13
LIFTER.....10

M

MANUAL.....5
MUFFLER.....10

N

NEEDLE CAGE1014.....10

O

O RING - 14.....13
O RING - 15.....13
O RING - 2.....7
O-RING - 10.....13

P

PIN - 4×15.8.....10
PIN - 5×31.8.....10
PIN - 5X21.8.....10
PIN, PISTON.....10
PIPE - 7X3X60.....13
PIPE, BREATHER - 8.5X4.5.....13
PIPE, INTAKE.....13
PISTON.....10
PISTON RING SET.....10
PLATE.....11, 13
PLATE, CHECK VALVE.....13
PLATE, CHOKE.....13
PLUG, SPARK -CMR6A.....9
PULLEY.....10
PUMP BODY ASSY.....7

R

REEL.....10

RETAINER PLATE.....9
RETAINER, SPRING.....10
ROCKER ARM ASSY.....10
ROD - 2.5.....10
ROPE, STARTER.....10

S

SCREEN.....7
SCREW.....13
SCREW - 3X24.....7
SCREW - 5X12 (TAPPING).....10
SCREW - M5X12.....10
SCREW - M5X14.....10, 13
SCREW - M5X68.....13
SCREW -M6×8.....9
SEAL, OIL - 12.....10
SHOE, CLUTCH.....9
SPACER.....9
SPRING.....7, 10
SPRING - 13.....10
SPRING, CLUTCH.....9
STOP RING E-3.....7
STOPPER, ROPE.....10
SWIVEL.....7

T

TANK, FUEL.....11
TERMINAL, SPARK PLUG CAP.....9
TOOL SET.....5
TUBE.....9, 11
TUBE, OIL.....9

V

VALVE, CHECK.....9, 13
VALVE, EXHAUST.....10
VALVE, INTAKE.....10

W

WASHER.....7
WASHER - 26.....10
WASHER - 8.....9
WEIGHT.....9
WIRE.....9

PRINTED IN THE USA

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047

Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com