

EH650DC0350

263A00110G	CRANK CASE GROUP
26310101F1	CRANK CASE CP
2631010152	CRANK CASE UN
2631010044	CRANK CASE UN
2631010149	CRANK CASE
2631380103	CYLINDER LINER
2631380105	CYLINDER LINER BLNK
2631580203	MAIN BEARING
X310080080	DOWEL PIN
2635560103	PIPE
1596540103	PIPE(PULSE)
26315911A1	BLIND PLUG CP
2121500813	BLIND PLUG
440080010	OIL SEAL
2631590103	UNION
450120010	STEEL BALL
2487630101	SWITCH OIL PRESSURE
26311001D0	MAINBEARING COVER AY
26311001D1	MAINBEARING COVER CP
26311001B2	MAINBEARING COVER UN
2631100109	MAINBEARING COVER
26315602A3	BEARING HOLDER
X600450010	BALL BEARING
440420030	OIL SEAL
26346202A3	GOVERNOR GEAR SHAFT
26345001C1	GOVERNOR GEAR CP
26145003B3	GOVERNOR GEAR
2634160102	FLYWEIGHT UN
26345008A3	PIN
2774190103	GOVERNOR SLEEVE
26346215A3	THRUST BEARING
26346214A3	WASHER
26313001B1	CYLINDER HEAD 1 CP
2631300122	CYLINDER HEAD 1 UN
2631300123	CYLINDER HEAD 1
2631300024	CYLINDER HEAD 1.
2461400103	INTAKE VALVE SEAT
2461410113	EXHAUST VALVE SEAT
2631420203	VALVE GUIDE
105080290	STUD
13207AA050	SEAL-INT VALVE
565100050	CLIP
X450060010	STEEL BALL
2631620103	PLUG
2633534103	RETAINER PLATE
26313101B1	CYLINDER HEAD 2 CP
2631310122	CYLINDER HEAD 2 UN
2631310123	CYLINDER HEAD 2
2631310024	CYLINDER HEAD 2.

2461400103	INTAKE VALVE SEAT
2461410113	EXHAUST VALVE SEAT
2631420203	VALVE GUIDE
105080290	STUD
13207AA050	SEAL-INT VALVE
565100050	CLIP
X450060010	STEEL BALL
2633534103	RETAINER PLATE
2461550101	ROCKER COVER CP
2461600213	GASKET(ROCKER COV)
2631500113	GASKET 1 (CYL HEAD)
2631510113	GASKET 2 (CYL HEAD)
26316001A3	GASKET (M.B COVER)
2631600603	GASKET(BREATHERPLATE
2631430103	BREATHER COVER
2631440101	BREATHER PLATE CP
26319001A3	LIFT HOOK
2631800303	RUBBER PIPE
561200020	HOSE CLAMP
X310060020	DOWEL PIN
X401140030	PLUG
211140020	GASKET
X110100030	FLANGE BOLT
X110080220	FLANGE BOLT
X110060030	FLANGE BOLT
263B00100G	CRANK,PISTON GROUP
26321101D1	CRANK SHAFT CP
2632110123	CRANK SHAFT
263211A114	CRANK SHAFT.
26322303A3	CRANK SHAFT GEAR
X450060010	STEEL BALL
2632250100	CONNECTING ROD AY
2632250101	CONNECTING ROD CP
2632250114	CONNECTING ROD
2462300113	CONNECTING ROD BOLT
26323411A3	PISTON
2632330123	PISTON PIN
2632360103	TOP RING
26323701A3	SECOND RING
2632390101	OIL RING CP
565210020	CLIP
26325011A3	SPACER
26325012A3	SPACER
26325013A3	SPACER
21818000	NUT
31018000	WASHER
32018000	SPRING WASHER
53205401	WOODRUFF KEY
263C00070G	INTAKE,EXHAUST GROUP
2633300103	INTAKE MANIFOLD

2633170113	CAM SHAFT
2633170014	CAM SHAFT.
26333301A3	TAPPET
2633340103	INTAKE VALVE
2633350213	EXHAUST VALVE
2463361103	VALVE SPRING
2463550103	COLLET-VALVE
2463371113	SPRING RETAINER
2393500103	ROCKER SHAFT
2633531101	PUSH ROD CP
2633531103	PUSH ROD
2533530203	CAP
2463610110	ROCKER ARM AY
2463610103	ROCKER ARM
149080021	ADJUSTING SCREW
170080090	NUT
26335503A3	GASKET(IN MANIFOLD)
2633260100	AIR CLEANER AY
26332610A1	CLEANER ELEMENT CP
2633262001	CLEANER BASE CP
2633263003	CLEANER COVER
2633264001	WING NUT
2639170103	LABEL(TRADE MARK)
2634600103	CHOKE CONTROL LINK
26346011A3	CHOKE CONTROL ROD
26343901A3	CHOKE KNOB
2634601003	CLAMP(CHOKE KNOB)
2614520103	RETURN SPRING
2264310101	LINK PIVOT
2264310103	LINK PIVOT
32210000	WAVED WASHER
X152050010	TAPPING SCREW
23808000	FLANGE NUT
X101050010	FLANGE BOLT
263D00070G	GOVERNOR GROUP
26342301B3	GOVERNOR LEVER
26342201A3	GOVERNOR SHAFT
26342501A3	GOVERNOR SPRING
26342701A3	GOVERNOR ROD
2634280103	ROD SPRING
26343301A3	SPEED CONTROL LEVER
2274350113	STOP PLATE
2634500203	SPRING WASHER
217060030	FRICTION WASHER
26345011A2	BRACKET UN(SPD CTL)
2614390103	CLAMP
51106001	SNAP PIN
X230080150	SPACER
11406300	BOLT AND WASHER AY
X186060020	NUT

X110060020	FLANGE BOLT
X115050020	BOLT
22705000	NUT
X176060020	SELF LOCK NUT
11705200	BOLT & WASHER AY
31008000	WASHER
263E00680G	COOLING,STARTING GR
26351103B2	BLOWER HOUSING UN
2639200103	LABEL(WARNING)
2635260101	CYLINDER BAFFLE 1 CP
X901080610	BLACK
2635260102	CYLINDER BAFFLE 1 UN
26395222A3	LABEL(EMISSION CONT)
26352704A1	CYLINDER BAFFLE 2 CP
X901080610	BLACK
26352704A2	CYLINDER BAFFLE 2 UN
26352802A3	CYLINDER BAFFLE 3
26352911B2	CYLINDER BAFFLE 4 UN
2635410102	COOLING BLOWER UN
X110060020	FLANGE BOLT
X110060140	FLANGE BOLT
11406160	BOLT AND WASHER AY
X110060030	FLANGE BOLT
263F00080G	FUEL LUBRICANT GROUP
2636390103	INNER ROTOR
2636390203	OUTER ROTOR
2636430202	OIL PUMP FILTER UN
26364001B1	OIL PUMP COVER CP
26364001A3	OIL PUMP COVER
440350170	OIL SEAL
X240890030	O RING
2636500113	PLUG(OIL RELIEF)
37014000	GASKET,ALUMINUM
2486560103	SPRING(RELIEF.VALVE)
69030800	STEEL BALL
2486580100	OIL FILTER AY
2636360301	OIL GAUGE CP
2636360203	OIL FILLER CAP
213160010	GASKET
26362606B1	FUEL PIPE 6 CP
X851061660	RUBBER PIPE
2636850103	HOSE CLAMP
2636230310	CARBURETOR AY
851030110	RUBBER PIPE
2067550101	CLAMP CP
2067550109	INSULATOR
566100021	CLAMP
26366201A3	GASKET(CARBURETOR)
2806220100	FUEL PUMP AY
26365002A3	BRACKET(FUEL PUMP)

26362653B1	PULSE PIPE CP
X851061630	RUBBER PIPE
2636850103	HOSE CLAMP
26365012A3	FILTER,FUEL
26362612B1	FUEL PIPE 11 CP
X851061381	RUBBER PIPE
2636850103	HOSE CLAMP
26365011A3	FLANGE BOLT
X110080110	FLANGE BOLT
X110060140	FLANGE BOLT
X110060020	FLANGE BOLT
263G00050G	ELECTRIC DEVICE GR
2637720311	FLYWHEEL CP
2637820301	IGNITION COIL CP
26379411A1	CHARGE COIL CP
2637100103	RING GEAR
26370502A0	STARTING MOTOR AY
2637190101	REGULATOR CP
26373126H1	WIRE CP(IG.COIL)
26373126H5	WIRE CP 26373126H1
X650140730	SPARK PLUG
X655100010	SPARK PLUG CAP
X659100010	PLUG TERMINAL
26373113B1	WIRING HARNESS
566000250	CLAMP
2637310211	WIRE AY(OIL PRE.SW.)
11406250	BOLT AND WASHER AY
11605200	BOLT AND WASHER AY
X110080100	FLANGE BOLT
X110060140	FLANGE BOLT
23808000	FLANGE NUT
X563000080	WIRE BAND
2067550101	CLAMP CP
2067550109	INSULATOR
566100021	CLAMP
263H00050G	REDUCTION,CLUTCH GR
732999989	LABEL(N.P.C)
X735000230	LABEL(AIR INDEX)
263J00080G	ACCESSORIES LABEL GR
2ZZ9020102	EH63,64,65
263J50490G	TANDOKU-HASSO-BUHIN
26355001A1	ROTATING SCREEN
43604200	SCREW AND WASHER