

EH650VC0014	
263A01000G	CRANK CASE GROUP
26310201D1	CRANK CASE CP
2631020122	CRANK CASE UN
2631020024	CRANK CASE UN
2631020119	CRANK CASE
2631380103	CYLINDER LINER
2631380105	CYLINDER LINER BLNK
2631580503	MAIN BEARING
X310080080	DOWEL PIN
2635560103	PIPE
1596540103	PIPE(PULSE)
26315911A1	BLIND PLUG CP
2121500813	BLIND PLUG
440080010	OIL SEAL
440350170	OIL SEAL
26317101B3	LEAF VALVE
26317201A3	RETAINER PLATE
43504100	SCREW AND WASHER AY
26311201B0	MAINBEARING COVER AY
26311021A1	MAIN BEARING CVR CP
26311201A3	MAIN BEARING COVER
440420030	OIL SEAL
26346202A3	GOVERNOR GEAR SHAFT
26345101C1	GOVERNOR GEAR CP
26145003B3	GOVERNOR GEAR
26341606A3	FLY WEIGHT
26345008A3	PIN
2774190201	GOVERNOR SLEEVE CP
2774190203	GOVERNOR SLEEVE
26346215A3	THRUST BEARING
26346214A3	WASHER
2636600103	SPRING(RELIEF VALVE)
69030800	STEEL BALL
26317301A3	RETAINER PLATE
X110060020	FLANGE BOLT
26364311A1	OIL PUMP FILTER
11305100	BOLT AND WASHER AY
26315911A1	BLIND PLUG CP
2121500813	BLIND PLUG
26317404A3	PLUG
26313201B1	CYLINDER HEAD 1 CP
2631320112	CYLINDER HEAD 1 UN
2631320113	CYLINDER HEAD 1
2631320024	CYLINDER HEAD 1

2461400103	INTAKE VALVE SEAT
2461410113	EXHAUST VALVE SEAT
2631420203	VALVE GUIDE
105080290	STUD
13211AA110	SEAL-EXH VALVE
2633900101	OIL SEAL EXH. VALVE
565100050	CLIP
2633534103	RETAINER PLATE
26313301B1	CYLINDER HEAD 2 CP
2631330112	CYLINDER HEAD 2 UN
2631330113	CYLINDER HEAD 2
2631330024	CYLINDER HEAD 2
2461400103	INTAKE VALVE SEAT
2461410113	EXHAUST VALVE SEAT
2631420203	VALVE GUIDE
105080290	STUD
13211AA110	SEAL-EXH VALVE
2633900101	OIL SEAL EXH. VALVE
565100050	CLIP
2633534103	RETAINER PLATE
26315501A3	ROCKER COVER
26316101A3	GASKET(ROCKER COVER)
2631502141	GASKET 1 (CYL HEAD)
2631512131	GASKET 2 (CYL HEAD)
26316011A3	GASKET(M.B.COVER)
2631600603	GASKET(BREATHERPLATE
2631430103	BREATHER COVER
26314411A1	BREATHER PLATE CP
26314411A3	BREATHER PLATE
26314412A3	RETAINER PLATE
26314413A3	LEAF VALVE
26314414A3	OIL SHELTER PLATE
57120051	RIVET
240009000	O RING
2631800303	RUBBER PIPE
26368512A3	HOSE CLAMP
X310060020	DOWEL PIN
26319101A3	LIFT HOOK 1
26319102A3	LIFT HOOK 2
X110100070	FLANGE BOLT
X110080090	FLANGE BOLT
10408750	FLANGE BOLT
X110060030	FLANGE BOLT
X110060101	FLANGE BOLT
X110060020	FLANGE BOLT
263B01080G	CRANK,PISTON GROUP
26321911B1	CRANK SHAFT CP

2632191113	CRANK SHAFT
2632180004	CRANK SHAFT
26322303A3	CRANK SHAFT GEAR
X450060010	STEEL BALL
2632260130	CONNECTING ROD AY
2632260131	CONNECTING ROD CP
10508400	FLANGE BOLT
26323421J3	PISTON
2632330133	PISTON PIN
2632360103	TOP RING
26323701A3	SECOND RING
2632390101	OIL RING CP
565210020	CLIP
26325011A3	SPACER
26325012A3	SPACER
26325013A3	SPACER
X180180010	FLANGE NUT
31018000	WASHER
53205401	WOODRUFF KEY
263C01740G	INTAKE,EXHAUST GROUP
26333051H1	INTAKE MANIFOLD CP
26333051H3	INTAKE MANIFOLD
X105060270	STUD
2633180113	CAM SHAFT
2633170014	CAM SHAFT.
26333301A3	TAPPET
2633340103	INTAKE VALVE
2633350213	EXHAUST VALVE
2463361103	VALVE SPRING
2463550103	COLLET-VALVE
2463371113	SPRING RETAINER
26335322A1	PUSH ROD CP
2673610203	ROCKER ARM
2633580103	BOLT(PIVOT)
2673570103	PIVOT
X170060110	NUT
26337002A3	GUIDE PLATE
26335401A3	INSULATOR
26335501A3	GASKET(INSULATOR)
26335503A3	GASKET(IN MANIFOLD)
26332610A1	CLEANER ELEMENT CP
26332621A1	CLEANER BASE CP
2633263003	CLEANER COVER
2633264001	WING NUT
26335505A1	BRIDGE(CLEANER)
26335506A3	RETAINER(AIR CLEANER
26335502A3	GASKET(CLEANER)

26338001A3	SPACER(AIR CLEANER)
26391752A3	LABEL(TRADE MARK)
2703520101	GASKET CP (MUFFLER)
23808000	FLANGE NUT
23808000	FLANGE NUT
23806000	FLANGE NUT
263D00720G	GOVERNOR GROUP
26342301B3	GOVERNOR LEVER
26342201A3	GOVERNOR SHAFT
26342501A3	GOVERNOR SPRING
26342701A3	GOVERNOR ROD
2634280103	ROD SPRING
26345021A2	BRACKET(SPD CONTROL)
26343312A3	SPEED CONTROL LEVER
26346021B3	CHOKE LEVER
26346011A3	CHOKE CONTROL ROD
2614520103	RETURN SPRING
2614390103	CLAMP
22643101A1	LINK PIVOT
22643101A3	LINK PIVOT
51106001	SNAP PIN
X230080150	SPACER
11406300	BOLT AND WASHER AY
X186060020	NUT
X110060020	FLANGE BOLT
X115050020	BOLT
22705000	NUT
23806000	FLANGE NUT
2614530103	SPACER
11705200	BOLT & WASHER AY
31008000	WASHER
263E01690G	COOLING,STARTING GR
26351102B2	BLOWER HOUSING UN
732005760	LABEL(WARNING)
26352612A1	CYLINDER BAFFLE 1 CP
X901080610	BLACK
26352612A2	CYLINDER BAFFLE 1 UN
26395262A3	LABEL(EMISSION CONT)
2635270101	CYLINDER BAFFLE 2 CP
X901080610	BLACK
2635270102	CYLINDER BAFFLE 2 UN
26352912A2	CYLINDER BAFFLE 4 UN
26353001A3	CYLINDER BAFFLE 5
26354001A3	SUPPORT(BLOWER HSG)
26354102A2	COOLING BLOWER UN
26355001A1	ROTATING SCREEN
X110060020	FLANGE BOLT

X110060020	FLANGE BOLT
X110060010	FLANGE BOLT
X110060030	FLANGE BOLT
X110060020	FLANGE BOLT
11406160	BOLT AND WASHER AY
43604200	SCREW AND WASHER
263F01320G	FUEL LUBRICANT GROUP
2636237110	CARBURETOR AY
2676220110	FUEL PUMP AY
26365012A3	FILTER,FUEL
X423060011	CAP(VINYL)
26367101A2	BRACKET(FUEL PUMP)
X851061721	RUBBER PIPE
X851061721	RUBBER PIPE
X851061630	RUBBER PIPE
2636850103	HOSE CLAMP
26367102A3	SPACER
26363921A3	INNER ROTER
26363931A3	OUTER ROTER
26363941A3	SHAFT(OIL PUMP)
26364011A3	OIL PUMP COVER
26364411A3	O RING
2636361101	OIL GAUGE CP
213180010	GASKET
26365101A2	OIL FILLER
240190000	O RING
2486580100	OIL FILTER AY
26376101H1	SWITCH(OIL PRESSURE)
X110060020	FLANGE BOLT
X110060140	FLANGE BOLT
X110060020	FLANGE BOLT
X110060030	FLANGE BOLT
X110060090	FLANGE BOLT
263G01030G	ELECTRIC DEVICE GR
2637720211	FLYWHEEL CP
2637820301	IGNITION COIL CP
26379411A1	CHARGE COIL CP
26371002H3	RING GEAR
2637050300	STARTING MOTOR AY
26371903A1	REGULATOR CP
26373126H1	WIRE CP(IG.COIL)
26373126H5	WIRE CP 26373126H1
X650140730	SPARK PLUG
X655100010	SPARK PLUG CAP
X659100010	PLUG TERMINAL
20675501A1	CLAMP CP
26373115C1	WIRING HARNESS

26373114A1	WIRE CP
2637310211	WIRE AY(OIL PRE.SW.)
566000320	CLAMP
26379901B3	BOLT(IG COIL)
11605200	BOLT AND WASHER AY
X110080100	FLANGE BOLT
X110060140	FLANGE BOLT
X563000080	WIRE BAND
23808000	FLANGE NUT
422000140	CAP(RUBBER)
263H00260G	REDUCTION,CLUTCH GR
X732999990	LABEL(N.P.C)
263J00660G	ACCESSORIES LABEL GR
2ZZ9990163	STATEMENT(EPA)
2ZZ9020146	EH63V,65V