


FIG. 100




EH092

284010003W00

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
10	20F-10109-01	CRANKCASE CP	1				
20	237-14201-03	VALVE GUIDE	2				
26	277-16010-01	STEM SEAL	1				
30	044-02000-70	OIL SEAL	1				
40	060-02001-40	BALL BEARING	1				
50	031-00600-20	DOWEL PIN	2				
70	X10-50604-90	STUD	2				
75	044-00600-20	OIL SEAL	1				
80	040-11400-30	PLUG	1				
90	021-11400-20	GASKET	2				
150	20F-16001-23	STIFFENER	1				
160	001-14083-00	BOLT AND WASHER AY	2				
161	001-14084-00	BOLT AND WASHER AY	4				
210	20F-11101-51	MAINBEARING COVER CP	1				
220	044-02001-10	OIL SEAL	1				
230	060-02001-40	BALL BEARING	1				
250	284-45003-01	GOVERNOR GEAR CP	1				
260	205-41901-03	GOVERNOR SLEEVE	1				
265	001-39085-00	STUD	4				
268	031-00600-20	DOWEL PIN	2				
270	20F-63601-11	OIL GAUGE CP	1				
280	021-31600-20	GASKET	1				
300	013-00602-00	BOLT AND WASHER AY	9				
430	20F-15001-23	ADAPTER(FLANGE)	1				
437	20F-18080-00	NUT	4				
438	X20-30800-30	SPRING WASHER	4				
439	20F-11080-00	WASHER	4				
610	20F-13001-31	CYLINDER HEAD CP	1				
620	284-15001-13	GASKET (HEAD)	1				
630	20F-00802-10	FLANGE BOLT	1				
631	010-00804-10	BOLT	1				
680	20F-15502-03	ROCKER COVER	1				
685	284-14502-03	OIL SHELTER PLATE 2	1				
690	284-16007-03	GASKET(ROCKER COVER)	1				
700	277-15011-03	PIPE KNOCK	2				
721	20F-15602-13	BREATHER PLATE	1				
722	284-16001-03	LEAF VALVE	1				
723	284-16002-03	RETAINER PLATE	1				
724	284-14501-03	OIL SHELTER PLATE 1	1				

725	013-10500-20	SCREW AND WASHER AY	2
726	013-10500-20	SCREW AND WASHER AY	1
810	284-17001-03	COVER (CASE)	1
830	284-16008-03	GASKET(TAPPET COVER)	2
860	001-14061-60	BOLT & WASHER ASSY (M6X16)	2
960	284-99003-17	GASKET SET	1


FIG. 200



EH10

20G020000W00


Ref #	Part #	Description	Qty	Context Note	Foot Note
10	20F-20301-01	CRANKSHAFT CP	1		
40	023-02001-00	SPACER	1		
41	023-02001-10	SPACER	1		
42	023-02001-20	SPACER	1		
50	002-18140-00	NUT	1		
60	X20-31400-20	SPRING WASHER	1		
70	005-32031-01	WOODRUFF KEY	1		
80	005-32042-01	WOODRUFF KEY	1		
105	017-31200-10	LOCK NUT	1		
310	20F-22501-30	CONNECTING ROD ASSY	1		
320	20F-23001-03	CONNECTING ROD BOLT	2		
350	20F-23301-03	PISTON PIN	1		
360	20F-23401-H3	PISTON	1		
370	284-23511-07	PISTON RING SET	1		
380	056-51100-10	CLIP	2		

FIG. 300

EH10


20G030001W00

Ref #	Part #	Description	Qty	Context Note	Foot Note
10	20F-31702-21	CAMSHAFT CP	1		
34	227-38601-23	PIN (SPRING)	1		
35	20F-36401-03	RELEASE LEVER	1		
36	005-19041-00	SPRING PIN	1		
37	20F-15170-00	SNAP RING OUT	1		
38	20F-38701-23	RETURN SPRING	1		
50	274-33301-03	TAPPET	2		
60	20F-33601-03	VALVE SPRING	2		
70	274-33702-03	SPRING RETAINER	2		
80	20F-33401-03	INTAKE VALVE	1		
90	274-33501-03	EXHAUST VALVE	1		
95	132-10KA0-31	VALVE COLLET	4		
210	274-35301-03	PUSH ROD	2		
220	20F-36001-13	ROCKER ARM	2		
230	269-35802-03	BOLT (PIVOT)	2		
240	017-00600-90	NUT	2		
260	274-36501-03	GUIDE PLATE	1		
310	20F-30105-01	MUFFLER CP	1		
320	20F-34201-23	MUFFLER COVER	1		
340	284-35201-03	GASKET (EXHAUST)	1		
350	002-38080-00	FLANGE NUT	2	M8X1.25	
357	020-00801-70	WASHER	1		
365	011-00604-60	FLANGE BOLT	2		
366	001-14081-60	BOLT AND WASHER ASSY (M8X16)	1		
366	013-00802-40	BOLT AND WASHER AY	1		
550	284-35903-03	GASKET(INTAKE 1)	1		
540	20F-32912-13	INSULATOR	1		
560	284-35904-03	GASKET(INTAKE 2)	2		
570	017-60600-20	SELF LOCK NUT	2		
850	20F-16104-01	RUBBER PIPE	1		




20G031500W00

Ref #	Part #	Description	Qty	Context Note	Foot Note
510	20F-32601-00	AIR CLEANER AY	1		
2	20F-32651-08	PACKING	1		
520	20F-32606-08	CLEANER ELEMENT	1		



20G040000W00


Ref #	Part #	Description	Qty	Context	Note	Foot	Note
10	284-42304-03	GOVERNOR LEVER	1				
20	230-42201-11	GOVERNOR SHAFT	1				
30	284-42702-03	GOVERNOR ROD	1				
35	284-45601-03	LINKAGE BUSHING	1				
40	293-42801-03	ROD SPRING	1				
50	003-13050-00	CLIP	1				
51	003-13050-00	CLIP	1				
60	20F-14063-00	BOLT AND WASHER AY	1				
70	20F-49002-01	WEIGHT CP	1				
80	284-42501-13	GOVERNOR SPRING	1				
200	230-43302-10	SPEED CONTROL AY	1				
201	284-45101-01	BASE PLATE CP	1				
207	20F-00600-10	FLANGE BOLT	2				
210	004-31041-40	SCREW, PANHEAD	1				
213	023-01000-40	SPACER	1				
215	226-45003-13	RETURN SPRING	1				
230	004-31063-00	SCREW	1				
240	002-27060-00	NUT	1				
255	021-71000-20	FRICTION WASHER	1				
260	014-00400-70	SCREW	1				
265	268-45001-13	CONTROL SPRING	1				
280	226-43103-01	LINK PIVOT CP	1				

FIG. 500


EH092

284050002W00


Ref #	Part #	Description	Qty	Context Note	Foot Note
10	20F-51102-13	BLOWER HOUSING CP	1		
20	284-95102-03	LABEL(MODEL)	1		
21	206-91701-03	LABEL(TRADE MARK)	1		
40	001-04083-50	FLANGE BOLT	2	M8X1.25X35	
41	20F-04082-00	FLANGE BOLT	2		
60	20F-52601-01	CYLINDER BAFFLE CP	1		
80	011-00600-10	FLANGE BOLT	1	M6X1.10X8	
110	20F-54101-03	COOLING BLOWER	1		
220	011-00600-10	FLANGE BOLT	3	M6X1.10X8	
230	011-00600-20	FLANGE BOLT	4	M6X1.0X12	




20G052000W00

Ref #	Part #	Description	Qty	Context Note	Foot Note
210	20F-50221-20	RECOIL STARTER AY	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
1	20F-50115-08	SPIRAL SPRING	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
2	20F-50120-18	REEL	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
3	20F-50112-18	STARTER ROPE	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
4	20F-50100-18	STARTER KNOB	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
5	20F-50125-08	RATCHET	2	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
6	274-50131-08	FRICTION SPRING	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
7	227-50135-08	RETURN SPRING	2	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
8	270-50261-08	RATCHET GUIDE	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
11	20F-50146-08	STARTER PULLEY	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
24	20F-50152-08	SLIDE PLATE B	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
25	20F-50150-08	SLIDE PLATE B	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	
49	227-50152-08	SET SCREW	1	End Code: 8126. Start Date: 4/1/2008 0:00:00. Start Date: 3/31/2009 0:00:00.	

FIG. 700




Ref #	Part #	Description	Qty	Context Note	Foot Note
10	20G-79330-01	FLY WHEEL CP	1		
11	20F-79430-31	IGNITION COIL CP	1		
30	20F-17062-50	BOLT & WASHER AY	2		
60	X66-00005-10	SWITCH AY	1		
70	20F-35041-20	SCREW AND WASHER AY	2		
75	056-60300-10	CLAMP	1		
100	065-01403-80	SPARK PLUG	1		
110	284-75102-03	SPARK PLUG CAP	1		



2000900000000

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
10	226-90307-10	ACCESSORY TOOL KIT	1				

6 FUEL LUBRICANT

FIG. 640

REF.	PART NUMBER	PART NAME	CODE NO.	QTY	REMARKS	INTERCHANGE
210	284-62372-00	CARBURETOR AY	-	1		284-62372-20
- 1	230-62536-08	THROTTLE VALVE	-	1		
- 2	277-62580-08	SCREW	-	1		
- 3	236-62528-08	CHOKE VALVE	-	1		
- 4	279-62356-08	SCREW	-	2		
- 5	279-62421-08	PILOT JET	-	1	#40	
- 7	230-62446-08	SPRING(CO)	-	2		
- 8	293-62520-08	CHOKE SHAFT BV15/309	-	1		
- 11	293-62530-08	TH.SHAFT BV15/1089	-	1		
- 12	237-62450-08	BOLT	-	1		
- 14	161-62352-08	NEEDLE	-	1		
- 15	214-62515-08	PIN	-	1		
- 16	293-62505-08	FLOAT.B AY BV15/308	-	1		
- 17	236-62450-08	PACKING	-	1		
- 18	236-62540-08	PACKING	-	1		
- 19	236-62505-08	FLOAT	-	1		
- 20	293-62440-18	NOZZLE805-82146-146B	-	1		
- 21	235-62425-08	GUIDE HOLDER	-	1		
- 22	276-62400-08	MAIN JET	-	1	#63.8	
- 28	224-62450-08	SCREW	-	1		
- 29	209-62445-08	SPRING	-	1		
- 40	246-62435-08	ADJUST SCREW	-	1		
- 95	284-45501-03	BUSH	-	1		
-142	236-62445-08	SPRING	-	1		
-151	106-62384-08	O-RING	-	1		
-153	293-62350-08	PLATE BV15/312	-	1		
-154	279-62351-08	SCREW	-	1		
-190	284-62360-08	HOSE	-	1		