

| PART NUMBER  | DESCRIPTION              |        |
|--------------|--------------------------|--------|
| 254-10103-21 | CRANK CASE CP            | N.L.A. |
| 044-03000-31 | OIL SEAL                 |        |
| 060-03000-20 | BALL BEARING             |        |
| 031-00600-20 | DOWEL PIN                |        |
| 254-11004-31 | MAIN BEARING COVER C     |        |
| 227-46201-03 | GOVERNOR GEAR SHAFT      | N.L.A. |
| 044-03000-31 | OIL SEAL                 |        |
| 060-03000-20 | BALL BEARING             |        |
| 270-45001-01 | GOVERNOR GEAR CP         |        |
| 270-45001-01 | GOVERNOR GEAR CP         |        |
| 220-41601-H3 | FLYWEIGHT                |        |
| 030-73000-70 | PIN                      |        |
| 205-41901-03 | GOVERNOR SLEEVE          |        |
| 254-17502-13 | OIL SHELTER              |        |
| 004-35051-00 | SCREW AND WASHER AY      |        |
| 282-63601-H1 | OIL GAUGE CP             |        |
| 021-31600-20 | GASKET                   |        |
| 254-13003-11 | CYLINDER HEAD CP         | N.L.A. |
| 010-50802-90 | STUD                     |        |
| 254-15001-13 | GASKET (HEAD)            |        |
| 254-16001-13 | GASKET B,COVER           |        |
| 040-11400-30 | PLUG                     |        |
| 021-11400-20 | GASKET                   |        |
| 270-15503-03 | ROKER COVER              |        |
| 254-14401-11 | BREATHER PLATE CP        |        |
| 205-16003-13 | LEAF VALVE               | N.L.A. |
| 254-14301-01 | BREATHER COVER CP        |        |
| 270-16008-03 | GASKET,ROKER COVER       |        |
| 246-16006-03 | GASKET,BREATHER COVE     |        |
| 246-16007-13 | GASKET(BREATHER PLAT     |        |
| 085-10800-00 | R PIPE 8X11XM            |        |
| 031-00600-20 | DOWEL PIN                |        |
| 001-13083-00 | BOLT AND WASHER AY       |        |
| 011-01000-40 | FLANGE BOLT              |        |
| 011-00600-20 | FLANGE BOLT              |        |
| 270-20791-01 | CRANK SHAFT CP           |        |
| 254-24301-03 | SPACER(GEAR)             | N.L.A. |
| 254-22501-10 | CONNECTING ROD AY        |        |
| 246-23001-13 | CONNECTING ROD BOLT      |        |
| 254-23301-03 | PISTON PIN               | N.L.A. |
| 254-23401-03 | PISTON STANDURD SIZE     |        |
| 254-23402-03 | PISTON 0.25 mm OVER SIZI | N.L.A. |
| 254-23403-03 | PISTON 0.5 mm OVER SIZE  | N.L.A. |
| 234-23601-03 | TOP RING                 | N.L.A. |
| 254-23701-03 | SECOND RING STD          | N.L.A. |
| 234-23901-03 | OIL RING                 | N.L.A. |
| 056-51800-10 | CLIP                     |        |
| 023-03001-70 | SPACER                   |        |
| 023-03001-80 | SPACER                   |        |
| 023-03001-90 | SPACER                   |        |
| 002-18180-00 | NUT                      |        |
| 003-20180-00 | SPRING WASHER            |        |
| 032-30300-10 | WOODRUFF KEY             |        |
| 254-31701-41 | CAM SHAFT CP             |        |
| 254-36401-23 | RELEASE LEVER            |        |
| 234-38701-03 | RETURN SPRING            |        |
| 227-38601-23 | PIN,SPRING               |        |
| 003-15220-00 | SNAP RING                |        |

|              |                    |        |
|--------------|--------------------|--------|
| 005-19041-00 | SPRING PIN         |        |
| 254-33301-03 | TAPPET             |        |
| 254-33401-03 | INTAKE VALVE       | N.L.A. |
| 254-33501-03 | EXHAUST VALVE      | N.L.A. |
| 254-33601-03 | VALVE SPRING       |        |
| 246-33701-13 | SPRING RETAINER    | N.L.A. |
| 239-35001-03 | ROCKER SHAFT       |        |
| 248-35301-11 | PUSH ROD CP        |        |
| 246-36101-10 | ROKER ARM AY       |        |
| 014-90800-21 | ADJUSTING SCREW    |        |
| 017-00800-90 | NUT EC50PM         |        |
| 254-36120-13 | SPACER(ROCKER S)   | N.L.A. |
| 254-33001-01 | INTAKE PIPE CP     |        |
| 010-50601-91 | STUD               |        |
| 246-36001-13 | GASKET (IN PIPE)   |        |
| 254-32612-20 | AIR CLEANER AY,ID  |        |
| 234-32901-03 | INSULATOR          |        |
| 234-35902-03 | GASKET2(INSULATOR) |        |
| 254-95301-13 | LABEL (CLENER ID)  | N.L.A. |
| 254-95302-13 | LABEL (CLENER ID)  | N.L.A. |
| 206-43901-11 | KNOB CP            |        |
| 001-13082-80 | BOLT AND WASHER AY |        |
| 226-39212-00 | NUT&WASHER AY      |        |
| 001-10061-60 | BOLT AND WASHER AY |        |
| 254-42301-33 | GOVERNOR LEVER     |        |
| 246-42201-23 | GOVERNOR SHAFT     |        |
| 254-42501-13 | GOVERNOR SPRING    |        |
| 254-42701-01 | GOVERNOR ROD       |        |
| 254-42801-03 | ROD SPRING         |        |
| 227-43310-13 | SPEED CONTROL      |        |
| 003-13060-00 | CLIP               |        |
| 004-31064-50 | SCREW,PANHEAD      |        |
| 220-48001-13 | CONTROL SPRING     |        |
| 001-14063-00 | BOLT AND WASHER AY |        |
| 018-60600-20 | NUT                |        |
| 001-14061-20 | BOLT AND WASHER AY |        |
| 254-53461-01 | BLOWER HOUSING     | N.L.A. |
| 073-20043-70 | LABEL,MAKITA       | N.L.A. |
| 073-20039-00 | LABEL,WARNING      |        |
| 254-95201-23 | LABEL (EMISSION)   | N.L.A. |
| 254-50201-10 | RECOIL STARTER AY  |        |
| 073-20043-50 | LABEL              | N.L.A. |
| 254-52702-03 | HEAD COVER         |        |
| 011-00600-20 | FLANGE BOLT        |        |
| 011-00600-10 | FLANGE BOLT        |        |
| 011-00600-30 | FLANGE BOLT        |        |
| 254-62542-10 | CARBURETOR AY      | N.L.A. |
| 001-15082-00 | BOLT & WASHER AY   |        |
| 234-70203-11 | FLYWHEEL CP        |        |
| 254-79430-51 | IGNITION COIL CP   |        |
| 227-79632-01 | CHARGE COIL CP     |        |
| 206-75501-01 | CLAMP CP           |        |
| 056-61000-21 | CLAMP              |        |
| 226-75501-03 | GROMMET            |        |
| 065-01401-50 | SPARK PLUG         |        |
| 065-50001-40 | SPARK PLUG CAP     |        |
| 065-90000-10 | PLUG TERMINAL EY14 |        |
| X66-00005-20 | SWITCH AY 120MM    |        |
| 056-60001-90 | CLAMP              |        |

|              |                      |        |
|--------------|----------------------|--------|
| KS3-11010-01 | OIL S CONTROL CP     |        |
| 254-73103-11 | WIRE 3CP             | N.L.A. |
| 214-73122-01 | WIRE 22 CP           |        |
| 227-75501-00 | SOLENOID AY          |        |
| 254-76513-01 | BRACKET 2(SOLENOID)  |        |
| 234-36003-03 | GASKET (AIR CLEANER) |        |
| 227-46901-13 | SPRING(S.D)          |        |
| 234-73118-11 | WIRE 18 CP           |        |
| 056-30000-40 | WIRE BAND            |        |
| 226-75101-03 | CLAMP                |        |
| 056-60003-00 | CLAMP                |        |
| 056-60001-70 | CLAMP                |        |
| 001-14062-50 | BOLT AND WASHER AY   |        |
| 015-00400-90 | TAPPING SCREW        |        |
| 004-31060-80 | SCREW,PANHEAD        |        |
| 011-00600-10 | FLANGE BOLT          |        |
| 001-10081-60 | BOLT & WASHER AY     |        |
| 004-35062-50 | SCREW & WASHER AY    |        |
| 073-99900-07 | LABEL,PRODUCT NO     | N.L.A. |