

PARTS MANUAL

MODEL
EH122D

EH122D46552

02/15



SUBARU

Industrial Power Products

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047 - Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com

© 2012 Subaru Industrial Power Products

Group Index

Group Name	Page
1000 Ship Loose.....	4
105 Crankcase.....	6
200 Crankshaft.....	10
300 Intake & Exhaust.....	12
315 Intake & Exhaust.....	16
331 Intake & Exhaust.....	18
420 Governor.....	20
500 Cooling & Starting.....	24
520 Cooling & Starting.....	26
640 Carburetor.....	28
700 Electric Device.....	32
900 Accessory.....	34
 Part Number Index.....	 36
Part Description Index.....	37

FIG. 1000

(Illustrations are excluded.)


(**FIG 1000**は単独発送部品につき、
イラストは省略します。)

1000 Ship Loose

Ref	Part Number.	Description	Qty	Remark
1	083-00000-10	COIL SPRING	1	
2	226-75101-03	CLAMP	1	
3	073-20045-20	LABEL(OIL CAUTION)	1	
4	073-20057-60	LABEL(WARNING)	1	
5	001-13081-80	BOLT AND WASHER	2	
9	073-20050-20	LABEL (CHOKE)	1	

105 Crankcase

FIG. 105



EH122

268010500W04

105 Crankcase

Ref	Part Number.	Description	Qty	Remark
10	252-10301-41	CRANK CASE CP	1	Start Date: 11/2/2009. Start Date: 12/31/9999. Remarks: RAMMER.
20	237-14201-03	VALVE GUIDE	2	Start Date: 12/31/9999. Remarks: 5.5DX9.5DX27L.
26	277-16010-01	STEM SEAL	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 5.5DX9.5DX15DX7.8B.
30	044-02501-50	OIL SEAL	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25DX38DX7B.
40	060-02501-00	BALL BEARING	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25DX52DX15B.
50	031-00600-20	DOWEL PIN	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6DX14.5L.
60	010-50804-80	STUD	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X35L.
70	010-50601-31	STUD	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X33L.
71	001-39066-00	STUD	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
75	044-00800-10	OIL SEAL	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 8DX14DX4B.
80	040-11400-30	PLUG	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M14X1.5X20DX12L.
90	021-11400-20	GASKET	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 14.1DX19DX2.3T.
210	252-11101-31	MAIN BEARING COVER C	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
220	044-02501-60	OIL SEAL	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25DX41DX7B.
230	060-02500-10	BALL BEARING	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25DX52DX15B.
250	227-45003-11	GOVERNOR GEAR CP ¹	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 52DX26T N=25.
260	205-41901-03	GOVERNOR SLEEVE	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6DX9DX16DX26L.
265	010-81000-20	STUD	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M10X1.5X60L.
270	268-63603-11	OIL GAUGE CP ²	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M18X1.5 L=76+18.

Footnotes

1: INTERCHANGEABLE 277-45003-01

2: INTERCHANGEABLE 268-63603-01

105 Crankcase

Ref	Part Number.	Description	Qty	Remark
280	021-31600-20	GASKET	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 16DX23DX1.2T RUBBER. Interchangeable with X21-31600-20.
294	252-17002-01	BRACKET(M.B.C) CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
295	252-17001-01	SUPPORT(M.B.C)	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
297	001-13081-60	BOLT AND WASHER AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X16L W/SW.
298	001-13081-60	BOLT AND WASHER AY	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X16L W/SW.
300	013-00602-00	BOLT AND WASHER AY	8	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X30L W/SW.
610	268-13101-21	CYLINDER HEAD CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: RAMMER.
620	253-15001-33	GASKET (HEAD)	1	Start Date: 4/1/2004. Start Date: 12/31/9999. Remarks: T=0.2.
630	011-00801-00	FLANGE BOLT	4	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X17DX65L.
675	056-60002-50	CLAMP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6.5DX10BX95LX0.6T.
677	011-00600-20	FLANGE BOLT	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X14DX12L.
680	252-15502-03	ROCKER COVER	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
690	269-16004-03	GASKET(ROCKER COVER)	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: T=2.0. Interchangeable with 269-16007-03.
700	031-00600-20	DOWEL PIN	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6DX14.5L.
710	011-00601-70	FLANGE BOLT	4	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X13DX40L.
720	252-15601-20	SPACER(BREATHER) AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
721	252-15601-13	SPACER(BREATHER)	1	Start Date: 10/23/1997. Start Date: 12/31/9999.

Footnotes

- 1: INTERCHANGEABLE 277-45003-01
 2: INTERCHANGEABLE 268-63603-01


105 Crankcase

Ref	Part Number.	Description	Qty	Remark
722	252-16001-03	LEAF VALVE	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
723	252-16101-03	RETAINER PLATE	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
724	252-14401-23	PLATE	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
725	011-00601-50	FLANGE BOLT	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X14DX10L.
726	004-35061-20	SCREW AND WASHER AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X12L W/SW.
830	268-16201-03	GASKET(BREATHER CVR)	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: T=1.2.
860	001-13061-60	BOLT AND WASHER AY	2	Start Date: 10/23/1997. Start Date: 12/31/9999.
960	268-99002-07	GASKET SET	1	Start Date: 12/31/9999.

Footnotes

- 1: INTERCHANGEABLE 277-45003-01
 2: INTERCHANGEABLE 268-63603-01

200 Crankshaft




200 Crankshaft

Ref	Part Number.	Description	Qty	Remark
10	268-21901-21	CRANKSHAFT CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: L=225 15DX18L+M12.
40	023-02501-10	SPACER	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25.3DX32DX0.6T.
41	023-02501-20	SPACER	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25.3DX32DX0.8T.
42	023-02501-30	SPACER	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 25.3DX32DX1.0T.
50	018-01400-20	FLANGE NUT	1	Start Date: 5/1/2006. Start Date: 12/31/9999. Remarks: M14X1.5X28DX12H.
65	020-01500-50	WASHER	1	Start Date: 5/1/2006. Start Date: 12/31/9999. Remarks: 15DX30DX3.2T.
70	032-30300-10	WOODRUFF KEY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 3BX6HX16D.
80	005-32042-01	WOODRUFF KEY	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
105	017-31200-10	LOCK NUT	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
310	252-22501-20	CONNECTING ROD AY	1	Start Date: 4/1/2005. Start Date: 12/31/9999.
320	277-23001-03	CONNECTING ROD BOLT	2	Start Date: 4/1/2005. Start Date: 12/31/9999. Remarks: M6X1.0X13DX33L.
350	268-23301-13	PISTON PIN	1	Start Date: 4/1/2005. Start Date: 12/31/9999. Remarks: 13DX8DX44L.
360	268-23401-J3	PISTON	1	Start Date: 2/1/2008. Start Date: 12/31/9999.
370	252-23501-17	PISTON RING SET	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: STD (60D).
371	252-23502-17	PISTON RING SET	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 0.25 O.S.(60D).
372	252-23503-17	PISTON RING SET	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 0.50 O.S.(60D).
380	215-25004-03	CLIP	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 14.1DX1.2D.

300 Intake & Exhaust

FIG. 300



EH122

268030001W00

300 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
10	253-31701-11	CAMSHAFT CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: L=116 89DX8B N=44.
34	227-38601-23	PIN(SPRING)	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 3.8DX7.5DX14L.
35	227-36401-13	RELEASE LEVER	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
36	005-19041-00	SPRING PIN	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 4.4DX10LX0.8T.
37	003-15220-00	SNAPRING (OUTER)	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
38	227-38701-03	RETURN SPRING	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 5DX0.7DX5.5L N=6.8.
50	239-33301-13	TAPPET	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 26DX8DX48L.
60	253-33601-03	VALVE SPRING	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 19.1DX2.3DX27L N=5.5.
70	269-33701-03	SPRING RETAINER	2	Start Date: 10/23/1997. Start Date: 12/31/9999.
80	268-33401-03	INTAKE VALVE	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 21DX5.5DX66.8L.
90	268-33501-03	EXHAUST VALVE	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 19DX5.5DX66.8L.
95	132-10KA0-31	COLLET-VALVE	4	Start Date: 10/23/1997. Start Date: 12/31/9999.
210	268-35302-03	PUSH ROD ¹	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 5.6DX118.5L.
220	269-36002-33	ROCKER ARM ²	2	Start Date: 4/1/2008. Start Date: 12/31/9999.
230	269-35802-03	BOLT (PIVOT)	2	Start Date: 6/1/2009. Start Date: 12/31/9999.
240	017-00600-90	NUT	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X0.75X5.1H.
260	269-36501-03	GUIDE PLATE	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
340	253-35201-03	GASKET(MUFFLER)	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: T=0.2.
350	017-60800-20	SELF LOCK NUT	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X13H.

Footnotes

1: INTERCHANGEABLE 268-35301-03

2: INTERCHANGEABLE 269-36002-23

300 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
500	268-33003-11	INTAKE PIPE CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
505	010-50602-30	STUD	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X80L.
540	106-32912-03	INSULATOR	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: T=5 20D 6.5DX42P.
555	282-35901-03	GASKET(INSULATOR)	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: T=0.5 25D 6.5DX42P.
556	001-14064-00	BOLT AND WASHER AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X40L W/W,SW.
560	157-35001-03	GASKET (INSULATOR)	2	Start Date: 4/1/2008. Start Date: 12/31/9999. Remarks: T=0.3 20D 6.5DX42P.
570	017-60600-20	SELF LOCK NUT	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X13DX6.9H.
577	020-00800-80	WASHER	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 8.4DX17DX3.2T.
580	001-13081-80	BOLT AND WASHER AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X18L W/SW.
585	252-36502-03	PLATE(AIR CLEANER)	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
590	002-38060-00	FLANGE NUT	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X13DX6H.
850	252-18002-03	RUBBER PIPE	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 8DX11D FORMED.



Footnotes

- 1: INTERCHANGEABLE 268-35301-03
 2: INTERCHANGEABLE 269-36002-23

This Page Intentionally Left Blank

315 Intake & Exhaust

FIG. 315




EH122

268031500W01

315 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
510	252-32711-40	AIR CLEANER AY	1	Start Date: 4/1/2008. Start Date: 12/31/9999.
510	284-32621-08	PACKING	1	Start Date: 4/1/2008. Start Date: 12/31/9999.
510	252-32602-07	ELEMENT SET	1	Start Date: 4/1/2008. Start Date: 12/31/9999.
510	252-32614-08	ELEMENT	1	Start Date: 4/1/2008. Start Date: 12/31/9999.

331 Intake & Exhaust




331 Intake & Exhaust

Ref	Part Number.	Description	Qty	Remark
310	252-30401-11	MUFFLER CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
330	252-37001-11	BRACKET CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
345	252-36501-23	SPACER (EXHAUST)	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: T=9.
365	001-13081-60	BOLT AND WASHER AY	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X16L W/SW.
366	001-14081-60	BOLT AND WASHER AY	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X16L W/W,SW.

420 Governor

FIG. 420



EH122

268042001W00

420 Governor

Ref	Part Number.	Description	Qty	Remark
10	252-42303-03	GOVERNOR LEVER	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
20	227-42201-03	GOVERNOR SHAFT ¹	1	Start Date: 6/9/2001. Start Date: 12/31/9999.
26	003-11080-00	WASHER	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 8.5DX18DX1.6T.
30	254-42701-01	GOVERNOR ROD	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
40	254-42801-03	ROD SPRING	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6DX0.5DX102L N=13.
50	003-13060-00	CLIP	1	Start Date: 6/9/2001. Start Date: 12/31/9999. Remarks: 6DX12DX0.8T.
51	003-13060-00	CLIP	1	Start Date: 4/23/2001. Start Date: 12/31/9999. Remarks: 6DX12DX0.8T.
60	001-14063-00	BOLT AND WASHER AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X30L W/W,SW.
70	018-60600-20	NUT	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X4.9H SQUARE.
80	252-42503-23	GOVERNOR SPRING	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6.8DX0.9DX47L N=10.5.
200	252-43402-30	SPEED CONTROL AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
210	011-60400-30	BOLT	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M4X0.7X8L.
230	004-31052-50	SCREW,PANHEAD	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M5X0.8X25L.
231	004-31042-50	SCREW	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M4X0.7X25L.
235	268-45001-13	CONTROL SPRING	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 5.3DX0.8DX14.5L N=7.
240	002-17050-00	NUT	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M5X0.8X4H.
280	226-43101-01	LINK PIVOT	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
290	268-44202-01	WIRE BRACKET CP	1	Start Date: 8/1/2006. Start Date: 12/31/9999.
293	011-00600-30	FLANGE BOLT	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X14DX14L.

Footnotes

1: INTERCHANGEABLE 277-42201-01

420 Governor


Ref	Part Number.	Description	Qty	Remark
710	252-42801-11	PROTECTOR(GOV) CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999.
715	001-13081-60	BOLT AND WASHER AY	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M8X1.25X16L W/SW.
716	011-00600-30	FLANGE BOLT	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X14DX14L.

Footnotes

1: INTERCHANGEABLE 277-42201-01

This Page Intentionally Left Blank

500 Cooling & Starting



EH122


268050000W01

500 Cooling & Starting

Ref	Part Number.	Description	Qty	Remark
10	252-51652-21	BLOWER HOUSING CP 2	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: RAMMER BLACK.
20	268-95101-03	LABEL(MODEL)	1	Start Date: 6/1/2005. Start Date: 12/31/9999. Remarks: 50X95.
35	268-91860-03	LABEL(ENGINE NAME)	1	Start Date: 6/1/2005. Start Date: 12/31/9999. Remarks: 38X34 ENGLISH.
40	001-14065-50	BOLT AND WASHER AY	4	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X55L W/W,SW.
90	268-52703-03	HEAD COVER	1	Start Date: 7/1/2003. Start Date: 12/31/9999.
95	011-00601-40	FLANGE BOLT	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X14DX18L.
220	011-00600-10	FLANGE BOLT	4	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X14DX8L.

520 Cooling & Starting

FIG. 520





EH122

268052000W01

520 Cooling & Starting

Ref	Part Number.	Description	Qty	Remark
210	268-50201-40	RECOIL STARTER AY	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	270-50115-08	SPIRAL SPRING	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	269-50120-08	REEL	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	282-50111-18	STARTER ROPE	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	261-50100-18	STARTER KNOB	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	270-50125-08	RATCHET	2	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	227-50131-08	FRICTION SPRING	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	227-50135-08	RETURN SPRING	2	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	270-50261-08	RATCHET GUIDE	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	268-50145-18	STARTER PULLEY	1	Start Date: 9/1/2009. Start Date: 12/31/9999.
210	227-50152-08	SET SCREW	1	Start Date: 9/1/2009. Start Date: 12/31/9999.

FIG. 640



EH122

268064000W01

640 Carburetor

Ref	Part Number.	Description	Qty	Remark
210-0	252-62551-40	CARBURETOR AY ¹	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-1	252-62535-08	THROTTLE VALVE	1	Start Date: 12/1/2003. Start Date: 12/31/9999. Remarks: #180.
210-2	237-62451-08	SCREW	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-3	236-62528-08	CHOKE VALVE	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-5	252-62421-08	PILOT JET	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-8	252-62521-08	CHOK SHAFT AY	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-11	161-62530-08	SHAFT AY (THROTTLE)	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-12	236-62451-08	BOLT	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-14	161-62352-08	NEEDLE	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-15	214-62515-08	PIN	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-16	236-62552-08	FLOAT CHAMBERBODY AY	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-17	236-62450-08	PACKING	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-18	236-62540-08	PACKING	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-19	236-62505-08	FLOAT	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-20	252-62440-08	MAIN NOZZLE	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-21	235-62425-08	GUIDE HOLDER	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-22	252-62405-08	MAIN JET	1	Start Date: 12/1/2003. Start Date: 12/31/9999. Remarks: #68.8.
210-26	161-62353-08	HOSE	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-28	236-62350-08	SCREW	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-40	246-62435-08	ADJUST SCREW	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-41	230-62446-08	SPRING	1	Start Date: 12/1/2003. Start Date: 12/31/9999.

Footnotes

1: INTERCHANGEABLE 252-62551-20

640 Carburetor


Ref	Part Number.	Description	Qty	Remark
210-79	236-62541-08	PACKING	1	Start Date: 12/1/2003. Start Date: 12/31/9999.
210-142	236-62445-08	SPRING	1	Start Date: 12/1/2003. Start Date: 12/31/9999.

Footnotes

1: INTERCHANGEABLE 252-62551-20

This Page Intentionally Left Blank

700 Electric Device




700 Electric Device

Ref	Part Number.	Description	Qty	Remark
10	268-79332-01	FLYWHEEL CP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: MARK MF5210.
11	269-79430-31	IGNITION COIL CP ¹	1	Start Date: 4/10/2008. Start Date: 12/31/9999.
30	001-14062-50	BOLT AND WASHER AY	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M6X1.0X25L W/W,SW.
60	066-00004-81	SWITCH AY	1	Start Date: 8/1/2009. Start Date: 12/31/9999.
70	015-00400-90	TAPPING SCREW	2	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: M4X12L.
75	056-60300-10	CLAMP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 3.5DXM4X8BX0.8T.
90	056-60002-50	CLAMP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Remarks: 6.5DX10BX95LX0.6T.
95	X65-51000-10	SPARK PLUG CAP	1	Start Date: 10/23/1997. Start Date: 12/31/9999. Interchangeable with 065-90000-10.
100	065-01405-80	SPARK PLUG	1	Start Date: 8/11/1998. Start Date: 12/31/9999. Remarks: NGK BR6ES.

Footnotes

1: INTERCHANGEABLE 269-

900 Accessory



EH122

268090000W01

900 Accessory

Ref	Part Number.	Description	Qty	Remark
10	282-90301-H0	ACCESSORY TOOL KIT ¹	1	Start Date: 10/23/1997. Start Date: 12/31/9999.

Footnotes

1: INTERCHANGEABLE 277-90301-10

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page
001-13061-60	9	161-62530-08	29	254-42801-03	21
001-13081-60	8, 19, 22	205-41901-03	7	261-50100-18	27
001-13081-80	5, 14	214-62515-08	29	268-13101-21	8
001-14062-50	33	215-25004-03	11	268-16201-03	9
001-14063-00	21	226-43101-01	21	268-21901-21	11
001-14064-00	14	226-75101-03	5	268-23301-13	11
001-14065-50	25	227-36401-13	13	268-23401-J3	11
001-14081-60	19	227-38601-23	13	268-33003-11	14
001-39066-00	7	227-38701-03	13	268-33401-03	13
002-17050-00	21	227-42201-03	21	268-33501-03	13
002-38060-00	14	227-45003-11	7	268-35302-03	13
003-11080-00	21	227-50131-08	27	268-44202-01	21
003-13060-00	21	227-50135-08	27	268-45001-13	21
003-15220-00	13	227-50152-08	27	268-50145-18	27
004-31042-50	21	230-62446-08	29	268-50201-40	27
004-31052-50	21	235-62425-08	29	268-52703-03	25
004-35061-20	9	236-62350-08	29	268-63603-11	7
005-19041-00	13	236-62445-08	30	268-79332-01	33
005-32042-01	11	236-62450-08	29	268-91860-03	25
010-50601-31	7	236-62451-08	29	268-95101-03	25
010-50602-30	14	236-62505-08	29	268-99002-07	9
010-50804-80	7	236-62528-08	29	269-16004-03	8
010-81000-20	7	236-62540-08	29	269-33701-03	13
011-00600-10	25	236-62541-08	30	269-35802-03	13
011-00600-20	8	236-62552-08	29	269-36002-33	13
011-00600-30	21-22	237-14201-03	7	269-36501-03	13
011-00601-40	25	237-62451-08	29	269-50120-08	27
011-00601-50	9	239-33301-13	13	269-79430-31	33
011-00601-70	8	246-62435-08	29	270-50115-08	27
011-00801-00	8	252-10301-41	7	270-50125-08	27
011-60400-30	21	252-11101-31	7	270-50261-08	27
013-00602-00	8	252-14401-23	9	277-16010-01	7
015-00400-90	33	252-15502-03	8	277-23001-03	11
017-00600-90	13	252-15601-13	8	282-35901-03	14
017-31200-10	11	252-15601-20	8	282-50111-18	27
017-60600-20	14	252-16001-03	9	282-90301-H0	35
017-60800-20	13	252-16101-03	9	284-32621-08	17
018-01400-20	11	252-17001-01	8	X65-51000-10	33
018-60600-20	21	252-17002-01	8		
020-00800-80	14	252-18002-03	14		
020-01500-50	11	252-22501-20	11		
021-11400-20	7	252-23501-17	11		
021-31600-20	8	252-23502-17	11		
023-02501-10	11	252-23503-17	11		
023-02501-20	11	252-30401-11	19		
023-02501-30	11	252-32602-07	17		
031-00600-20	7-8	252-32614-08	17		
032-30300-10	11	252-32711-40	17		
040-11400-30	7	252-36501-23	19		
044-00800-10	7	252-36502-03	14		
044-02501-50	7	252-37001-11	19		
044-02501-60	7	252-42303-03	21		
056-60002-50	8, 33	252-42503-23	21		
056-60300-10	33	252-42801-11	22		
060-02500-10	7	252-43402-30	21		
060-02501-00	7	252-51652-21	25		
065-01405-80	33	252-62405-08	29		
066-00004-81	33	252-62421-08	29		
073-20045-20	5	252-62440-08	29		
073-20050-20	5	252-62521-08	29		
073-20057-60	5	252-62535-08	29		
083-00000-10	5	252-62551-40	29		
106-32912-03	14	253-15001-33	8		
132-10KA0-31	13	253-31701-11	13		
157-35001-03	14	253-33601-03	13		
161-62352-08	29	253-35201-03	13		
161-62353-08	29	254-42701-01	21		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

A

ACCESSORY TOOL KIT.....35
ADJUST SCREW.....29
AIR CLEANER AY.....17

B

BALL BEARING.....7
BLOWER HOUSING CP 2.....25
BOLT.....21, 29
BOLT (PIVOT).....13
BOLT AND WASHER.....5
BOLT AND WASHER AY.....8-9, 14, 19, 21-22, 25, 33
BRACKET CP.....19
BRACKET(M.B.C) CP.....8

C

CAMSHAFT CP.....13
CARBURETOR AY.....29
CHOK SHAFT AY.....29
CHOKE VALVE.....29
CLAMP.....5, 8, 33
CLIP.....11, 21
COIL SPRING.....5
COLLET-VALVE.....13
CONNECTING ROD AY.....11
CONNECTING ROD BOLT.....11
CONTROL SPRING.....21
CRANK CASE CP.....7
CRANKSHAFT CP.....11
CYLINDER HEAD CP.....8

D

DOWEL PIN.....7-8

E

ELEMENT.....17
ELEMENT SET.....17
EXHAUST VALVE.....13

F

FLANGE BOLT.....8-9, 21-22, 25
FLANGE NUT.....11, 14
FLOAT.....29
FLOAT CHAMBERBODY AY.....29
FLYWHEEL CP.....33
FRICTION SPRING.....27

G

GASKET.....7-8
GASKET (HEAD).....8
GASKET (INSULATOR).....14
GASKET SET.....9
GASKET(BREATHING CVR).....9
GASKET(INSULATOR).....14

GASKET(MUFFLER).....13
GASKET(ROCKER COVER).....8
GOVERNOR GEAR CP.....7
GOVERNOR LEVER.....21
GOVERNOR ROD.....21
GOVERNOR SHAFT.....21
GOVERNOR SLEEVE.....7
GOVERNOR SPRING.....21
GUIDE HOLDER.....29
GUIDE PLATE.....13

H

HEAD COVER.....25
HOSE.....29

I

IGNITION COIL CP.....33
INSULATOR.....14
INTAKE PIPE CP.....14
INTAKE VALVE.....13

L

LABEL (CHOKE).....5
LABEL(ENGINE NAME).....25
LABEL(MODEL).....25
LABEL(OIL CAUTION).....5
LABEL(WARNING).....5
LEAF VALVE.....9
LINK PIVOT.....21
LOCK NUT.....11

M

MAIN BEARING COVER C.....7
MAIN JET.....29
MAIN NOZZLE.....29
MUFFLER CP.....19

N

NEEDLE.....29
NUT.....13, 21

O

OIL GAUGE CP.....7
OIL SEAL.....7

P

PACKING.....17, 29-30
PILOT JET.....29
PIN.....29
PIN(SPRING).....13
PISTON.....11
PISTON PIN.....11
PISTON RING SET.....11
PLATE.....9
PLATE(AIR CLEANER).....14
PLUG.....7

PROTECTOR(GOV) CP.....22
PUSH ROD.....13

R

RATCHET.....27
RATCHET GUIDE.....27
RECOIL STARTER AY.....27
REEL.....27
RELEASE LEVER.....13
RETAINER PLATE.....9
RETURN SPRING.....13, 27
ROCKER ARM.....13
ROCKER COVER.....8
ROD SPRING.....21
RUBBER PIPE.....14

S

SCREW.....21, 29
SCREW AND WASHER AY.....9
SCREW,PANHEAD.....21
SELF LOCK NUT.....13-14
SET SCREW.....27
SHAFT AY (THROTTLE).....29
SNAPRING (OUTER).....13
SPACER.....11
SPACER (EXHAUST).....19
SPACER(BREATHING).....8
SPACER(BREATHING) AY.....8
SPARK PLUG.....33
SPARK PLUG CAP.....33
SPEED CONTROL AY.....21
SPIRAL SPRING.....27
SPRING.....29-30
SPRING PIN.....13
SPRING RETAINER.....13
STARTER KNOB.....27
STARTER PULLEY.....27
STARTER ROPE.....27
STEM SEAL.....7
STUD.....7, 14
SUPPORT(M.B.C).....8
SWITCH AY.....33

T

TAPPET.....13
TAPPING SCREW.....33
THROTTLE VALVE.....29

V

VALVE GUIDE.....7
VALVE SPRING.....13

W

WASHER.....11, 14, 21
WIRE BRACKET CP.....21
WOODRUFF KEY.....11

PRINTED IN THE USA

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047

Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com