

EH650DA7000	
263A00610G	CRANK CASE GROUP
26310111B1	CRANK CASE CP
2631011112	CRANK CASE UN
2631011004	CRANK CASE UN
2631011109	CRANK CASE
2631380103	CYLINDER LINER
2631380105	CYLINDER LINER BLNK
2631580203	MAIN BEARING
X310080080	DOWEL PIN
2635560103	PIPE
1596540103	PIPE(PULSE)
26315911A1	BLIND PLUG CP
2121500813	BLIND PLUG
440080010	OIL SEAL
2631590103	UNION
450120010	STEEL BALL
2487630101	SWITCH OIL PRESSURE
X423060011	CAP(VINYL)
26311001D0	MAINBEARING COVER AY
26311001D1	MAINBEARING COVER CP
26311001B2	MAINBEARING COVER UN
2631100109	MAINBEARING COVER
26315602A3	BEARING HOLDER
X600450010	BALL BEARING
440420030	OIL SEAL
26346202A3	GOVERNOR GEAR SHAFT
26345001C1	GOVERNOR GEAR CP
26145003B3	GOVERNOR GEAR
2634160102	FLYWEIGHT UN
26345008A3	PIN
2774190103	GOVERNOR SLEEVE
26346215A3	THRUST BEARING
26346214A3	WASHER
26313211A1	CYLINDER HEAD 1 CP
2631321102	CYLINDER HEAD 1 UN
2631321103	CYLINDER HEAD 1
2631320024	CYLINDER HEAD 1
2461400103	INTAKE VALVE SEAT
2461410113	EXHAUST VALVE SEAT
2631420203	VALVE GUIDE
105080290	STUD
13207AA050	SEAL-INT VALVE
565100050	CLIP

X450060010	STEEL BALL
2633534103	RETAINER PLATE
26313311A1	CYLINDER HEAD 2CP
2631331102	CYLINDER HEAD 2 UN
2631331103	CYLINDER HEAD 2
2631330024	CYLINDER HEAD 2
2461400103	INTAKE VALVE SEAT
2461410113	EXHAUST VALVE SEAT
2631420203	VALVE GUIDE
105080290	STUD
13207AA050	SEAL-INT VALVE
565100050	CLIP
X450060010	STEEL BALL
2633534103	RETAINER PLATE
26315501A3	ROCKER COVER
28015501A3	ROCKER COVER
26316101A3	GASKET(ROCKER COVER)
2631502121	GASKET 1 (CYL HEAD)
2631512111	GASKET 2 (CYL HEAD)
26316001A3	GASKET (M.B COVER)
2631600603	GASKET(BREATHERPLATE
2631430103	BREATHER COVER
28014401A1	BREATHER PLATE CP
28014401A2	BREATHER PLATE UN
26314412A3	RETAINER PLATE
26314413A3	LEAF VALVE
26314414A3	OIL SHELTER PLATE
57120051	RIVET
28019001A3	HOOK
2421500701	ENGINE HANGER
2421500703	ENGINE HANGER
11408200	BOLT AND WASHER AY
2631800303	RUBBER PIPE
561200020	HOSE CLAMP
X310060020	DOWEL PIN
X401140030	PLUG
211140020	GASKET
X110100030	FLANGE BOLT
X110080220	FLANGE BOLT
X110060030	FLANGE BOLT
X110060101	FLANGE BOLT
263B00490G	CRANK,PISTON GROUP
26320801B1	CRANK SHAFT CP
2632080113	CRANK SHAFT
263207A114	CRANK SHAFT.
26322303A3	CRANK SHAFT GEAR
X450060010	STEEL BALL

2632260110	CONNECTING ROD AY
2632260111	CONNECTING ROD CP
10508400	FLANGE BOLT
26323411A3	PISTON
2632330123	PISTON PIN
2632360103	TOP RING
26323701A3	SECOND RING
2632390101	OIL RING CP
565210020	CLIP
26325011A3	SPACER
26325012A3	SPACER
26325013A3	SPACER
21818000	NUT
31018000	WASHER
32018000	SPRING WASHER
53205401	WOODRUFF KEY
263C00920G	INTAKE,EXHAUST GROUP
28033001C3	INTAKE MANIFOLD
2803170113	CAM SHAFT
2633170014	CAM SHAFT.
26333301A3	TAPPET
2633340103	INTAKE VALVE
2633350213	EXHAUST VALVE
2463361103	VALVE SPRING
2463550103	COLLET-VALVE
2463371113	SPRING RETAINER
26335321B1	PUSH ROD CP
2673610203	ROCKER ARM
2633580103	BOLT(PIVOT)
2673570103	PIVOT
170060110	NUT
26337001A3	GUIDE PLATE
26335503A3	GASKET(IN MANIFOLD)
28032602A0	AIR CLEANER AY
26332610A1	CLEANER ELEMENT CP
28032625A1	CLEANER BASE CP
2633263003	CLEANER COVER
2633264001	WING NUT
26395303A3	LABEL(MODEL NUMBER)
2634602101	CHOKE LEVER CP
26346021B3	CHOKE LEVER
2064330211	SWIVEL
2064330213	SWIVEL
31006000	WASHER
26346011A3	CHOKE CONTROL ROD
2614520103	RETURN SPRING
2264310101	LINK PIVOT

2264310103	LINK PIVOT
X152050010	TAPPING SCREW
23808000	FLANGE NUT
X110060020	FLANGE BOLT
43104080	SCREW
263D00430G	GOVERNOR GROUP
26342301B3	GOVERNOR LEVER
26342201A3	GOVERNOR SHAFT
26342503A3	GOVERNOR SPRING
26342701A3	GOVERNOR ROD
2634280103	ROD SPRING
2634331201	SPEED CONT. LEVER CP
26343312A3	SPEED CONTROL LEVER
2064330211	SWIVEL
2064330213	SWIVEL
31006000	WASHER
26347001A3	BRACKET(RETURN SP.)
26345021A2	BRACKET(SPD CONTROL)
2614390103	CLAMP
51106001	SNAP PIN
X230080150	SPACER
11406300	BOLT AND WASHER AY
X186060020	NUT
X110060020	FLANGE BOLT
X115050020	BOLT
22705000	NUT
23806000	FLANGE NUT
2614530103	SPACER
11705200	BOLT & WASHER AY
31008000	WASHER
43104080	SCREW
263E00860G	COOLING,STARTING GR
26351102A2	BLOWER HOUSING UN
2639200103	LABEL(WARNING)
26355001A1	ROTATING SCREEN
43604200	SCREW AND WASHER
26352602A1	CYLINDER BAFFLE 1 CP
X901080610	BLACK
26352602A2	CYLINDER BAFFLE 1 UN
26395222C3	LABEL(EMISSION CONT)
26352704A1	CYLINDER BAFFLE 2 CP
X901080610	BLACK
26352704A2	CYLINDER BAFFLE 2 UN
26352802A3	CYLINDER BAFFLE 3
26352911B2	CYLINDER BAFFLE 4 UN
2635410102	COOLING BLOWER UN
X110060020	FLANGE BOLT

X110060140	FLANGE BOLT
11406160	BOLT AND WASHER AY
X110060030	FLANGE BOLT
263F00680G	FUEL LUBRICANT GROUP
2636390103	INNER ROTOR
2636390203	OUTER ROTOR
2636430202	OIL PUMP FILTER UN
26364001B1	OIL PUMP COVER CP
26364001A3	OIL PUMP COVER
440350170	OIL SEAL
X240890030	O RING
2636500113	PLUG(OIL RELIEF)
37014000	GASKET,ALUMINUM
2486560103	SPRING(RELIEF.VALVE)
69030800	STEEL BALL
2486580100	OIL FILTER AY
2636360301	OIL GAUGE CP
28063602A1	OIL FILLER CAP CP
28063602A3	OIL FILLER CAP
26364414A3	O RING
26362606B1	FUEL PIPE 6 CP
X851061660	RUBBER PIPE
2636850103	HOSE CLAMP
563000040	WIRE BAND
2636258110	CARBURETOR AY
851030110	RUBBER PIPE
2067550101	CLAMP CP
2067550109	INSULATOR
566100021	CLAMP
26366201A3	GASKET(CARBURETOR)
26365011A3	FLANGE BOLT
X110080110	FLANGE BOLT
X110060140	FLANGE BOLT
X110060020	FLANGE BOLT
263G00470G	ELECTRIC DEVICE GR
2637720311	FLYWHEEL CP
2637820211	IGNITION COIL CP
26379402B1	CHARGE COIL CP
2637100103	RING GEAR
26370502A0	STARTING MOTOR AY
26371902A1	REGULATOR CP
KU31105221	STOP DIODE CP
X650140730	SPARK PLUG
X655100010	SPARK PLUG CAP
X659100010	PLUG TERMINAL
26373113B1	WIRING HARNESS
566000250	CLAMP

2637310211	WIRE AY(OIL PRE.SW.)
11406250	BOLT AND WASHER AY
11605250	BOLT & WASHER AY
X110080100	FLANGE BOLT
X110060010	FLANGE BOLT
X110060140	FLANGE BOLT
23808000	FLANGE NUT
X563000080	WIRE BAND
2067550101	CLAMP CP
2067550109	INSULATOR
566100021	CLAMP
263H00120G	REDUCTION,CLUTCH GR
732999989	LABEL(N.P.C)
263J00430G	ACCESSORIES LABEL GR
2279030110	ACCESSORY TOOL KIT
712140051	BOX WRENCH
714090010	WRENCH HANDLE
700000060	TOOL BAG
2ZZ9990085	EH63,64,65,EH72
263J50660G	TANDOKU-HASSO-BUHIN
26335201A1	GASKET EXHAUST
X180080010	FLANGE NUT
2806220100	FUEL PUMP AY
26365002A3	BRACKET(FUEL PUMP)
X735000280	LABEL(AIR INDEX)
X110060020	FLANGE BOLT
26395222C3	LABEL(EMISSION CONT)
2264500213	RETURN SPRING