




Ref #	Part #	Description	Qty	Context Note	Foot Note
10	254-31701-41	CAM SHAFT CP	1		
34	227-38601-23	PIN(SPRING)	1		
35	254-36401-23	RELEASE LEVER	1	Start Code: 4474.	
35	254-36401-13	RELEASE LEVER	1	End Code: 4473.	
36	005-19041-00	SPRING PIN	1		
37	003-15220-00	SNAPRING (OUTER)	1		
38	234-38701-03	RETURN SPRING	1		
50	239-33301-13	TAPPET	2		
60	246-33611-03	VALVE SPRING	2		
70	246-33711-03	SPRING RETAINER	2		
80	270-33401-03	INTAKE VALVE	1		
90	270-33501-03	EXHAUST VALVE	1		
95	246-35501-03	VALVE COLLET	4		
210	270-35301-03	PUSH ROD	2		
220	261-36001-A3	ROCKER ARM	2	End Code: 4839.	
220	269-36001-03	ROCKER ARM	2	Start Code: 4840.	
230	269-35801-03	BOLT (PIVOT)	2		
240	017-00600-90	NUT	2		
260	270-36501-03	GUIDE PLATE	1		
310	270-30101-01	MUFFLER CP	1		
320	254-34201-11	MUFFLER COVER	1		
340	246-35201-03	GASKET(MUFFLER)	1		
350	017-00800-30	NUT	2		
360	015-20600-90	TAPPING BOLT	4	M6X10	
361	015-20601-00	TAPPING BOLT	1		
365	001-10081-60	BOLT & WASHER AY	1		
430	270-34801-03	EXHAUST PIPE COVER	1		
440	246-37001-01	DEFLECTOR CP	1		
445	015-00400-10	TAPPING SCREW	3		
500	254-33001-01	INTAKE PIPE CP	1		
505	010-50601-91	STUD	2		
510	207-32690-08	GROMMET	1	End Code: 4749.	

510	234-36003-08	PACKING	1	End Code: 4749.
510	254-32613-10	AIR CLEANER AY	1	End Code: 4749.
510	207-32690-08	GROMMET	1	Start Code: 4750.
510	234-36003-08	PACKING	1	Start Code: 4750.
510	254-32613-20	AIR CLEANER AY	1	Start Code: 4750.
520	234-32604-07	ELEMENT SET	1	
540	234-32901-03	INSULATOR	1	
550	234-35902-03	GASKET2(INSULATOR)	2	Remarks: T=0.2.
555	246-36001-13	GASKET(IN.PIPE)	1	
556	001-13082-80	BOLT AND WASHER AY	3	
570	226-39212-00	NUT AND WASHER AY	2	
580	001-10061-20	BOLT AND WASHER AY	1	
650	230-43901-01	KNOB CP	1	