

PARTS MANUAL

MODEL
EX27
Engine

EX270D10240

06/16



SUBARU

Industrial Power Products

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047 - Phone 847-540-7300 - Fax 847-438-5012


e-mail: sales@subarupower.com - www.subarupower.com

© 2015 Subaru Industrial Power Products

Group Index

Group Name	Page
100 Crankcase.....	4
200 Crankshaft.....	6
300 Intake & Exhaust.....	8
315 Air Cleaner.....	10
330 Muffler.....	12
400 Governor.....	14
500 Cooling & Starting.....	16
520 Recoil Starter.....	18
600 Fuel Tank.....	20
640 Carburetor.....	22
700 Electric Device.....	24
770 Electric Device.....	26
900 Accessories.....	28
 Part Number Index.....	 30
Part Description Index.....	31


100 Crankcase



100 Crankcase

Ref	Part Number.	Description	Qty	Remark
10	279-10122-01	CRANKCASE CP	1	
20	237-14202-03	VALVE GUIDE	2	5.5DX9.5DX27L
26	277-16010-01	STEM SEAL	1	5.5DX9.5DX15DX7.8B
30	044-03001-60	OIL SEAL	1	25DX38DX7B
40	060-03003-70	BALL BEARING	1	28DX58DX16B
50	277-15011-03	PIPE KNOCK	2	
60	010-50802-50	STUD (M8X1.25X25)	2	
70	010-50604-10	STUD (M6X1X107)	2	
75	044-00600-20	OIL SEAL	1	
80	040-11400-30	OIL DRAIN PLUG	2	
90	021-11400-20	GASKET 14	2	
210	279-11101-41	MAIN BEARING COVER CP	1	
220	044-03001-60	OIL SEAL	1	
230	060-03003-70	BALL BEARING	1	
250	277-45004-K1	GOVERNOR GEAR CP	1	
260	277-41902-01	GOVERNOR SLEEVE	4	
270	279-63601-30	OIL GAUGE ASSY	2	
300	001-04083-50	FLANGE BOLT (M8X35)	7	
610	279-13001-21	CYLINDER HEAD CP	1	
620	279-15001-33	GASKET (HEAD)	1	
630	011-00802-40	FLANGE BOLT (M8X68)	4	
631	011-00803-10	FLANGE BOLT (M8X33)	1	
680	277-15503-01	ROCKER COVER CP	1	
690	277-16001-13	GASKET	1	
700	277-15011-03	PIPE KNOCK	2	
710	011-00600-20	FLANGE BOLT (M6X12)	4	
960	279-99001-37	GASKET SET	1	

200 Crankshaft




0200 0018 000

200 Crankshaft

Ref	Part Number.	Description	Qty	Remark
10	279-20301-51	CRANKSHAFT CP	1	
50	018-01800-10	FLANGE NUT (M18)	1	
70	032-30300-10	WOODRUFF KEY (3X6X16)	1	
310	279-22501-30	CONNECTING ROD ASSY	1	104.5CDX26B 34.5D-18
320	279-23001-03	BOLT (M7X40)	2	
350	279-23301-13	PISTON PIN (18X13X53)	1	
360	279-23401-H3	PISTON	1	STANDARD
360	279-23403-H3	PISTON	1	0.25 OVERSIZED
360	279-23404-H3	PISTON	1	0.50 OVERSIZED
370	279-23501-27	PISTON RING SET	1	STANDARD
370	279-23502-27	PISTON RING SET	1	0.25 OVERSIZED
370	279-23503-27	PISTON RING SET	1	0.50 OVERSIZED
380	056-51800-10	CLIP	2	18.9DX1.6D

300 Intake & Exhaust



0300 0022 000

300 Intake & Exhaust


Ref	Part Number.	Description	Qty	Remark
10	279-31601-31	CAMSHAFT CP ¹	1	
10	279-31601-41	CAMSHAFT CP ²	1	
23	277-35101-01	CAMSHAFT PIN CP	1	
27	024-00600-30	O-RING	1	
31	277-38703-33	RETURN SPRING	1	
34	277-38601-03	SPRING PIN	1	
35	279-36401-13	RELEASE LEVER	1	
37	277-36501-03	CLIP	1	13.8DX20.3DX0.4T
60	279-33601-03	VALVE SPRING	2	19.2DX2.3DX27.4L
70	269-33701-03	SPRING RETAINER	2	
80	279-33401-H3	INTAKE VALVE	1	28.5DX5.5DX67.8L
90	279-33501-H3	EXHAUST VALVE	1	26.5DX5.5DX67.8L
95	132-10KA0-31	VALVE COLLET	4	
150	279-35602-H1	TIMING CHAIN CP (100 LINK)	1	
160	20A-36911-03	TENTIONER	1	
163	277-37101-03	TENTIONER SPRING	1	
166	277-36902-03	TENTIONER PIN	1	6DX13DX34L
170	20A-36913-03	CHAIN GUIDE	1	
200	277-35004-01	ROCKER PIN CP	1	
202	003-13050-00	CLIP	1	5DX11DX0.6T
220	277-36201-00	INTAKE ROCKER ARM ASSY	1	
225	277-36202-00	EXHAUST ROCKER ARM ASSY	1	
230	014-90500-20	ADJUST SCREW (M5X23)	1	
231	014-90500-20	ADJUST SCREW (M5X23)	1	
240	017-00500-30	NUT (M5)	1	
241	017-00500-30	NUT (M5)	1	
290	011-00600-10	FLANGE BOLT (M6X8)	1	

Footnotes

1: Serial Number: 00000 - 10325

2: Serial Number: 10326 - 99999

315 Air Cleaner




0315 0011 000

315 Air Cleaner

Ref	Part Number.	Description	Qty	Remark
200	279-32630-28	CASE	1	
220	279-32650-18	GASKET	1	
250	279-32640-08	COVER	1	
260	279-32730-08	LABEL	1	
510	279-32611-30	AIR CLEANER AY	1	
520	279-32603-08	ELEMENT	1	
540	279-32902-J1	INSULATOR CP	1	
550	279-35903-J3	INTAKE GASKET	1	
560	279-35902-J3	INTAKE GASKET	1	
570	002-38060-00	FLANGE NUT (M6)	2	
580	001-04062-00	FLANGE BOLT (M6X20)	1	
850	279-32760-08	BREATHER PIPE (8X11X115)	1	

330 Muffler




0330 0002 000

330 Muffler

Ref	Part Number.	Description	Qty	Remark
310	279-30111-L1	MUFFLER CP	1	
315	279-37601-01	SPARK ARRESTER CP	1	
317	015-00400-60	TAPPING SCREW (M4X6)	1	
320	279-34201-31	MUFFLER COVER CP	1	
340	277-35201-13	EXHAUST GASKET	1	
350	002-38080-00	FLANGE NUT (M8)	2	
360	015-20600-90	TAPPING BOLT (M6X10)	2	
365	011-00803-20	FLANGE BOLT (M8X12)	1	
361	011-00600-10	FLANGE BOLT (M6X8)	1	
385	277-37203-H1	SCREEN CP	1	
387	015-00400-60	TAPPING SCREW (M4X6)	2	

400 Governor




0400 0019 000

400 Governor

Ref	Part Number.	Description	Qty	Remark
13	279-42301-60	GOVERNOR LEVER AY	1	
20	277-42201-33	GOVERNOR SHAFT	1	
30	279-42701-23	GOVERNOR ROD	1	
40	277-42801-23	ROD SPRING	1	
50	003-13050-00	CLIP	1	5DX11DX0.6T
60	001-14062-50	BOLT & WASHER ASSY (M6X25)	1	
70	018-60600-20	SQUARE NUT (M6)	1	
310	277-43303-03	SPEED CONTROL LEVER	1	
80	279-42502-73	GOVERNOR SPRING	1	
340	277-43502-03	STOP PLATE	1	
350	277-44501-03	WASHER	1	T=0.4
355	021-70600-70	FRICTION WASHER	1	6.5DX24DX0.8T NYLON
360	004-31062-50	SCREW (M6X25)	1	
365	237-45004-23	ADJUST SPRING	1	
435	277-46002-02	SPEED CONTROL BRACKET	1	
450	002-35060-00	LOCKNUT (M6)	1	
485	011-00600-20	FLANGE BOLT (M6X12)	2	

500 Cooling & Starting




0500 0017 000

500 Cooling & Starting

Ref	Part Number.	Description	Qty	Remark
10	279-51202-01	BLOWER HOUSING CP (BLACK)	1	
20	073-20058-20	LABEL (TRADE MARK)	1	
40	011-00600-30	FLANGE BOLT (M6X14)	4	
60	279-52711-11	CASE BAFFLE 1 CP	1	
61	279-52702-13	HEAD BAFFLE 2	1	
80	001-65081-20	BOLT (M8X12)	1	
81	011-00600-20	FLANGE BOLT (M6X12)	1	
220	013-00602-81	BOLT & WASHER ASSY (M6X14)	4	

520 Recoil Starter




0520 0002 000

520 Recoil Starter

Ref	Part Number.	Description	Qty	Remark
210	279-50301-30	RECOIL STARTER AY	1	
1	226-50716-08	SPIRAL SPRING	1	
2	277-50121-08	REEL	1	
3	279-50110-08	STARTER ROPE	1	
4	277-50409-18	STARTER HANDLE	1	
5	281-50325-08	RATCHET	2	
6	281-50330-08	FRICTION SPRING	1	
8	281-50340-08	FRICTION PLATE	1	
11	279-50148-08	STARTER PULLEY	1	
49	281-50351-08	CENTER SCREW	1	

600 Fuel Tank




0600 0015 000

600 Fuel Tank

Ref	Part Number.	Description	Qty	Remark
10	279-60102-11	FUEL TANK CP (BLACK)	1	6.1 LITRE
20	073-20057-60	LABEL (WARNING)	1	
23	279-95112-03	LABEL (MODEL)	1	
30	X43-04401-62	FUEL TANK CAP CP	1	
40	X64-13600-10	FUEL FILTER	1	
48	X50-51200-20	UNION	1	M12X4DX78L W/FILTER
60	002-38080-00	FLANGE NUT (M8)	2	
63	011-00802-50	FLANGE BOLT (M8X25)	2	
70	279-62602-11	FUEL PIPE CP	1	
80	X85-10615-81	RUBBER PIPE (6.4X12.7X195)	1	
90	X56-11100-60	HOSE CLAMP	2	11.5DX8BX0.7T
224	277-43801-01	CHOKE LEVER CP	1	

640 Carburetor




0640 0015 000

640 Carburetor

Ref	Part Number.	Description	Qty	Remark
210	279-62361-20	CARBURETOR AY	1	
1	279-62536-08	THROTTLE VALVE	1	
2	209-62351-08	SCREW	1	
3	279-62527-08	CHOKE VALVE	1	
5	279-62421-08	PILOT JET (#40)	1	
8	279-62522-08	CHOKE LEVER	1	
11	279-62532-08	THROTTLE SHAFT ASSY	1	
12	150-62358-08	BOLT	1	
14	224-62305-08	NEEDLE VALVE	1	
15	214-62515-08	PIN	1	
16	279-62506-08	FLOAT BODY ASSY	1	
17	207-62345-08	INSERT WASHER	1	
18	206-62540-08	PACKING	1	
19	234-62506-08	FLOAT ASSY	1	
22	279-62406-08	MAIN JET (#91.3)	1	
24	226-62701-18	CLIP	1	
28	279-62361-08	BOLT	1	
40	106-62556-08	SCREW	1	
41	283-62357-08	SPRING	1	
79	279-62541-08	WASHER	1	
102	246-62390-08	SEAL	1	
103	279-62551-08	RING	1	
151	106-62384-08	O-RING	1	
153	279-62360-08	PLATE	1	
154	279-62351-08	SCREW	1	
300	279-62103-20	COCK BODY ASSY	1	
302	277-62110-18	PACKING	1	
303	277-62100-18	CUP	1	
325	277-62552-08	O-RING	1	
327	165-62377-08	SCREW	2	

700 Electric Device




0700 0020 000

700 Electric Device

Ref	Part Number.	Description	Qty	Remark
10	279-79230-21	FLYWHEEL CP	1	
11	279-79430-11	IGNITION COIL CP	1	
30	001-04062-00	FLANGE BOLT (M6X20)	2	
50	277-73102-H1	WIRE 2 CP ¹	1	L=360 BLACK
50	277-73115-01	WIRE 2 CP ²	1	
60	066-00004-91	SWITCH AY	1	
70	015-00400-90	TAPPING SCREW (M4X12)	2	
100	X65-01430-50	SPARK PLUG	1	TORCH E6RC
110	X65-50002-70	SPARK PLUG CAP	1	
Footnotes				
1: SERIAL NUMBER: 00000 - 10221				
2: SERIAL NUMBER: 10222 - 99999				

770 Electric Device




0770 0012 000

770 Electric Device

Ref	Part Number.	Description	Qty	Remark
700	279-76301-61	OIL SENSOR CP	1	
701	277-76350-08	O-RING	1	
705	KU3-11043-11	FLOAT C/U CP3	1	
740	001-04061-40	FLANGE BOLT	2	
741	011-00600-10	FLANGE BOLT (M6X8)	1	
770	279-75501-23	WIRE CLAMP	1	
775	015-20600-50	TAPPING BOLT	1	

900 Accessories



2900 0004 000

900 Accessories

Ref	Part Number.	Description	Qty	Remark
10	277-90301-J0	ACCESSORY TOOL KIT	1	

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page
001-04061-40	27	277-36202-00	9	279-52711-11	17
001-04062-00	11, 25	277-36501-03	9	279-60102-11	21
001-04083-50	5	277-36902-03	9	279-62103-20	23
001-14062-50	15	277-37101-03	9	279-62351-08	23
001-65081-20	17	277-37203-H1	13	279-62360-08	23
002-35060-00	15	277-38601-03	9	279-62361-08	23
002-38060-00	11	277-38703-33	9	279-62361-20	23
002-38080-00	13, 21	277-41902-01	5	279-62406-08	23
003-13050-00	9, 15	277-42201-33	15	279-62421-08	23
004-31062-50	15	277-42801-23	15	279-62506-08	23
010-50604-10	5	277-43303-03	15	279-62522-08	23
010-50802-50	5	277-43502-03	15	279-62527-08	23
011-00600-10	9, 13, 27	277-43801-01	21	279-62532-08	23
011-00600-20	5, 15, 17	277-44501-03	15	279-62536-08	23
011-00600-30	17	277-45004-K1	5	279-62541-08	23
011-00802-40	5	277-46002-02	15	279-62551-08	23
011-00802-50	21	277-50121-08	19	279-62602-11	21
011-00803-10	5	277-50409-18	19	279-63601-30	5
011-00803-20	13	277-62100-18	23	279-75501-23	27
013-00602-81	17	277-62110-18	23	279-76301-61	27
014-90500-20	9	277-62552-08	23	279-79230-21	25
015-00400-60	13	277-73102-H1	25	279-79430-11	25
015-00400-90	25	277-73115-01	25	279-95112-03	21
015-20600-50	27	277-76350-08	27	279-99001-37	5
015-20600-90	13	277-90301-J0	29	281-50325-08	19
017-00500-30	9	279-10122-01	5	281-50330-08	19
018-01800-10	7	279-11101-41	5	281-50340-08	19
018-60600-20	15	279-13001-21	5	281-50351-08	19
021-11400-20	5	279-15001-33	5	283-62357-08	23
021-70600-70	15	279-20301-51	7	KU3-11043-11	27
024-00600-30	9	279-22501-30	7	X43-04401-62	21
032-30300-10	7	279-23001-03	7	X50-51200-20	21
040-11400-30	5	279-23301-13	7	X56-11100-60	21
044-00600-20	5	279-23401-H3	7	X64-13600-10	21
044-03001-60	5	279-23403-H3	7	X65-01430-50	25
056-51800-10	7	279-23404-H3	7	X65-50002-70	25
060-03003-70	5	279-23501-27	7	X85-10615-81	21
066-00004-91	25	279-23502-27	7		
073-20057-60	21	279-23503-27	7		
073-20058-20	17	279-30111-L1	13		
106-62384-08	23	279-31601-31	9		
106-62556-08	23	279-31601-41	9		
132-10KA0-31	9	279-32603-08	11		
150-62358-08	23	279-32611-30	11		
165-62377-08	23	279-32630-28	11		
206-62540-08	23	279-32640-08	11		
207-62345-08	23	279-32650-18	11		
209-62351-08	23	279-32730-08	11		
20A-36911-03	9	279-32760-08	11		
20A-36913-03	9	279-32902-J1	11		
214-62515-08	23	279-33401-H3	9		
224-62305-08	23	279-33501-H3	9		
226-50716-08	19	279-33601-03	9		
226-62701-18	23	279-34201-31	13		
234-62506-08	23	279-35602-H1	9		
237-14202-03	5	279-35902-J3	11		
237-45004-23	15	279-35903-J3	11		
246-62390-08	23	279-36401-13	9		
269-33701-03	9	279-37601-01	13		
277-15011-03	5	279-42301-60	15		
277-15503-01	5	279-42502-73	15		
277-16001-13	5	279-42701-23	15		
277-16010-01	5	279-50110-08	19		
277-35004-01	9	279-50148-08	19		
277-35101-01	9	279-50301-30	19		
277-35201-13	13	279-51202-01	17		
277-36201-00	9	279-52702-13	17		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

A

ACCESSORY TOOL KIT.....29
ADJUST SCREW (M5X23).....9
ADJUST SPRING.....15
AIR CLEANER AY.....11

B

BALL BEARING.....5
BLOWER HOUSING CP (BLACK).....17
BOLT.....23
BOLT & WASHER ASSY (M6X14).....17
BOLT & WASHER ASSY (M6X25).....15
BOLT (M7X40).....7
BOLT (M8X12).....17
BREATHING PIPE (8X11X115).....11

C

CAMSHAFT CP.....9
CAMSHAFT PIN CP.....9
CARBURETOR AY.....23
CASE.....11
CASE BAFFLE 1 CP.....17
CENTER SCREW.....19
CHAIN GUIDE.....9
CHOKE LEVER.....23
CHOKE LEVER CP.....21
CHOKE VALVE.....23
CLIP.....7, 9, 15, 23
COCK BODY ASSY.....23
CONNECTING ROD ASSY.....7
COVER.....11
CRANKCASE CP.....5
CRANKSHAFT CP.....7
CUP.....23
CYLINDER HEAD CP.....5

E

ELEMENT.....11
EXHAUST GASKET.....13
EXHAUST ROCKER ARM ASSY.....9
EXHAUST VALVE.....9

F

FLANGE BOLT.....27
FLANGE BOLT (M6X12).....5, 15, 17
FLANGE BOLT (M6X14).....17
FLANGE BOLT (M6X20).....11, 25
FLANGE BOLT (M6X8).....9, 13, 27
FLANGE BOLT (M8X12).....13
FLANGE BOLT (M8X25).....21
FLANGE BOLT (M8X33).....5
FLANGE BOLT (M8X35).....5
FLANGE BOLT (M8X68).....5
FLANGE NUT (M18).....7
FLANGE NUT (M6).....11
FLANGE NUT (M8).....13, 21

FLOAT ASSY.....23
FLOAT BODY ASSY.....23
FLOAT C/U CP3.....27
FLYWHEEL CP.....25
FRICTION PLATE.....19
FRICTION SPRING.....19
FRICTION WASHER.....15
FUEL FILTER.....21
FUEL PIPE CP.....21
FUEL TANK CAP CP.....21
FUEL TANK CP (BLACK).....21

G

GASKET.....5, 11
GASKET (HEAD).....5
GASKET 14.....5
GASKET SET.....5
GOVERNOR GEAR CP.....5
GOVERNOR LEVER AY.....15
GOVERNOR ROD.....15
GOVERNOR SHAFT.....15
GOVERNOR SLEEVE.....5
GOVERNOR SPRING.....15

H

HEAD BAFFLE 2.....17
HOSE CLAMP.....21

I

IGNITION COIL CP.....25
INSERT WASHER.....23
INSULATOR CP.....11
INTAKE GASKET.....11
INTAKE ROCKER ARM ASSY.....9
INTAKE VALVE.....9

L

LABEL.....11
LABEL (MODEL).....21
LABEL (TRADE MARK).....17
LABEL (WARNING).....21
LOCKNUT (M6).....15

M

MAIN BEARING COVER CP.....5
MAIN JET (#91.3).....23
MUFFLER COVER CP.....13
MUFFLER CP.....13

N

NEEDLE VALVE.....23
NUT (M5).....9

O

O-RING.....9, 23, 27
OIL DRAIN PLUG.....5

OIL GAUGE ASSY.....5
OIL SEAL.....5
OIL SENSOR CP.....27

P

PACKING.....23
PILOT JET (#40).....23
PIN.....23
PIPE KNOCK.....5
PISTON.....7
PISTON PIN (18X13X53).....7
PISTON RING SET.....7
PLATE.....23

R

RATCHET.....19
RECOIL STARTER AY.....19
REEL.....19
RELEASE LEVER.....9
RETURN SPRING.....9
RING.....23
ROCKER COVER CP.....5
ROCKER PIN CP.....9
ROD SPRING.....15
RUBBER PIPE (6.4X12.7X195).....21

S

SCREEN CP.....13
SCREW.....23
SCREW (M6X25).....15
SEAL.....23
SPARK ARRESTER CP.....13
SPARK PLUG.....25
SPARK PLUG CAP.....25
SPEED CONTROL BRACKET.....15
SPEED CONTROL LEVER.....15
SPIRAL SPRING.....19
SPRING.....23
SPRING PIN.....9
SPRING RETAINER.....9
SQUARE NUT (M6).....15
STARTER HANDLE.....19
STARTER PULLEY.....19
STARTER ROPE.....19
STEM SEAL.....5
STOP PLATE.....15
STUD (M6X1X107).....5
STUD (M8X1.25X25).....5
SWITCH AY.....25

T

TAPPING BOLT.....27
TAPPING BOLT (M6X10).....13
TAPPING SCREW (M4X12).....25
TAPPING SCREW (M4X6).....13
TENSIONER.....9
TENSIONER PIN.....9
TENSIONER SPRING.....9

Part Description Index (continued)

THROTTLE SHAFT ASSY.....23
THROTTLE VALVE.....23
TIMING CHAIN CP (100 LINK).....9

U

UNION.....21

V

VALVE COLLET.....9
VALVE GUIDE.....5
VALVE SPRING.....9

W

WASHER.....15, 23
WIRE 2 CP.....25
WIRE CLAMP.....27
WOODRUFF KEY (3X6X16).....7

This Page Intentionally Left Blank

PRINTED IN THE USA

Subaru Industrial Power Products

905 Telser Road - Lake Zurich, IL 60047

Phone 847-540-7300 - Fax 847-438-5012

e-mail: sales@subarupower.com - www.subarupower.com